



Reference Guide

Avaya C360

Converged Stackable Switch

Software Version 4.3

650-100-704

Release 1
May 2004

**Copyright 2004, Avaya Inc.
All Rights Reserved**

Notice

Every effort was made to ensure that the information in this document was complete and accurate at the time of printing. However, information is subject to change.

Warranty

Avaya Inc. provides a limited warranty on this product. Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language as well as information regarding support for this product, while under warranty, is available through the following Web site: <http://www.avaya.com/support>.

Disclaimer

Avaya is not responsible for any modifications, additions or deletions to the original published version of this documentation unless such modifications, additions or deletions were performed by Avaya. Customer and/or End User agree to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation to the extent made by the Customer or End User.

How to Get Help

For additional support telephone numbers, go to the Avaya support Web site: <http://www.avaya.com/support>. If you are:

- Within the United States, click the *Escalation Management* link. Then click the appropriate link for the type of support you need.
- Outside the United States, click the *Escalation Management* link. Then click the *International Services* link that includes telephone numbers for the international Centers of Excellence.

Standards Compliance

Avaya Inc. is not responsible for any radio or television interference caused by unauthorized modifications of this equipment or the substitution or attachment of connecting cables and equipment other than those specified by Avaya Inc. The correction of interference caused by such unauthorized modifications, substitution or attachment will be the responsibility of the user. Pursuant to Part 15 of the Federal Communications Commission (FCC) Rules, the user is cautioned that changes or modifications not expressly approved by Avaya Inc. could void the user's authority to operate this equipment.

Product Safety Standards

This product complies with and conforms to the following international Product Safety standards as applicable:

Safety of Information Technology Equipment, IEC 60950, 3rd Edition, or IEC 60950-1, 1st Edition, including all relevant national deviations as listed in Compliance with IEC for Electrical Equipment (IECEE) CB-96A.

Safety of Information Technology Equipment, CAN/CSA-C22.2 No. 60950-00 / UL 60950, 3rd Edition, or CAN/CSA-C22.2 No. 60950-1-03 / UL 60950-1.

One or more of the following Mexican national standards, as applicable: NOM 001 SCFI 1993, NOM SCFI 016 1993, NOM 019 SCFI 1998.

The equipment described in this document may contain Class 1 LASER Device(s). These devices comply with the following standards:

- EN 60825-1, Edition 1.1, 1998-01
- 21 CFR 1040.10 and CFR 1040.11.

The LASER devices used in Avaya equipment typically operate within the following parameters:

Typical Center Wavelength	Maximum Output Power
830 nm - 860 nm	-1.5 dBm
1270 nm - 1360 nm	-3.0 dBm
1540 nm - 1570 nm	5.0 dBm

Luokan 1 Laserlaite

Klass 1 Laser Apparat

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposures. Contact your Avaya representative for more laser product information.

Electromagnetic Compatibility (EMC) Standards

This product complies with and conforms to the following international EMC standards and all relevant national deviations:

Limits and Methods of Measurement of Radio Interference of Information Technology Equipment, CISPR 22:1997 and EN55022:1998.

Information Technology Equipment – Immunity Characteristics – Limits and Methods of Measurement, CISPR 24:1997 and EN55024:1998, including:

- Electrostatic Discharge (ESD) IEC 61000-4-2
- Radiated Immunity IEC 61000-4-3
- Electrical Fast Transient IEC 61000-4-4
- Lightning Effects IEC 61000-4-5
- Conducted Immunity IEC 61000-4-6
- Mains Frequency Magnetic Field IEC 61000-4-8
- Voltage Dips and Variations IEC 61000-4-11

Power Line Emissions, IEC 61000-3-2: Electromagnetic compatibility (EMC) – Part 3-2: Limits – Limits for harmonic current emissions.

Power Line Emissions, IEC 61000-3-3: Electromagnetic compatibility (EMC) – Part 3-3: Limits – Limitation of voltage changes, voltage fluctuations and flicker in public low-voltage supply systems.

Federal Communications Commission Statement

Part 15:

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Canadian Department of Communications (DOC) Interference Information

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

European Union Declarations of Conformity



Avaya Inc. declares that the equipment specified in this document bearing the "CE" (*Conformité Européenne*) mark conforms to the European Union Electromagnetic Compatibility Directive (89/336/EEC) and Low Voltage Directive (73/23/EEC).

Copies of these Declarations of Conformity (DoCs) can be obtained by contacting your local sales representative and are available on the following Web site: <http://www.avaya.com/support>.

Japan

This is a Class A product based on the standard of the Voluntary Control Council for Interference by Information Technology Equipment (VCCI). If this equipment is used in a domestic environment, radio disturbance may occur, in which case, the user may be required to take corrective actions.

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

To order copies of this and other documents:

Call: Avaya Publications Center
Voice 1.800.457.1235 or 1.207.866.6701
FAX 1.800.457.1764 or 1.207.626.7269

Write: Globalware Solutions
200 Ward Hill Avenue
Haverhill, MA 01835 USA
Attention: Avaya Account Management

E-mail: totalware@gwsmail.com

For the most current versions of documentation, go to the Avaya support
Web site: <http://www.avaya.com/support>.

Contents

1	Using the CLI	19
	• CLI Architecture	19
	• Conventions Used	19
	• CLI Help	20
	• Command Line Prompt	20
	• Navigation, Cursor Movement and Shortcuts	21
	• Command Syntax	21
	Command Abbreviations	21
	• Universal Commands	21
	Top and Up commands	21
	Retstatus command	22
	Tree command	22
	• C360 Sessions	22
	• Security Levels	23
	Entering the Supervisor Level	23
	Entering the CLI	24
	Entering the Technician Level	24
	• Warranty	24
	• Notice	24
	• Avaya Support	25
2	Avaya C360 Layer 2 CLI Commands	27
	clear cam	27
	clear dot1x config	27
	clear dynamic vlans	27
	clear ip route	28
	clear log	28
	clear logging file	29
	clear logging server	29
	clear port mirror	29
	clear port static-vlan	30
	clear radius authentication server	30
	clear rmon statistics	31
	clear screen	31

Contents

clear snmp trap	31
clear ssh-client known-hosts	32
clear timezone	32
clear utilization cpu	32
clear vlan	33
configure	33
copy module-config scp	34
copy module-config tftp	34
copy scp module-config	35
copy scp stack-config	36
copy stack-config scp	37
copy stack-config tftp	38
copy tftp EW_Archive	38
copy tftp module-config	39
copy tftp stack-config	39
copy tftp SW_image	40
copy tftp SW_powerinline_image	41
crypto key generate DSA	42
dir	43
disconnect ssh	44
get time	45
help	45
hostname	46
ip http	46
ip icmp redirect	47
ip ssh	47
ip telnet	47
ip telnet-client	48
no hostname	48
no ip http	48
no ip icmp redirect	48
no ip ssh	48
no ip telnet	48
no ip telnet-client	48
no rmon alarm	49
no rmon event	49
no rmon history	49
no username	49

nvrAm initialize	49
ping	50
prompt-length	50
reset	51
reset mgp	52
reset module-and-powerinline	52
reset stack-and-powerinline	52
reset wan	53
retstatus	53
rmon alarm	54
rmon event	54
rmon history	55
session	56
set allowed managers	57
set allowed managers ip	57
set arp-aging-interval	58
set arp-tx-interval	58
set autopartition	59
set boot bank	59
set cascading	60
set device-mode	60
set dot1x max-req	61
set dot1x quiet-period	61
set dot1x re-authperiod	61
set dot1x server-timeout	62
set dot1x supp-timeout	62
set dot1x system-auth-control disable	63
set dot1x system-auth-control enable	63
set dot1x tx-period	64
set inband vlan	64
set intelligent-multicast	64
set intelligent-multicast client-port-pruning time	65
set intelligent-multicast group-filtering-delay time	65
set intelligent-multicast router-port-pruning time	66
set interface inband	66
set interface ppp	67
set interface ppp enable/enable-always/disable/off/reset	67
set intermodule port redundancy	68

set intermodule port redundancy off	69
set internal buffering	69
set ip route	70
set leaky-vlan	70
set license	71
set logging file condition	71
set logging file disable	73
set logging file enable	73
set logging server access level	74
set logging server condition	74
set logging server disable	75
set logging server enable	75
set logging server facility	76
set logging session condition	77
set logging session disable	78
set logging session enable	78
set logout	79
set mac-aging	79
set mac-aging-time	80
set port auto-negotiation-flowcontrol-advertisement	80
set port channel	81
set port classification	82
set port disable	82
set port dot1x initialize	83
set port dot1x max-req	83
set port dot1x port-control	83
set port dot1x quiet-period	84
set port dot1x re-authenticate	84
set port dot1x re-authentication	85
set port dot1x re-authperiod	85
set port dot1x server-timeout	85
set port dot1x supp-timeout	86
set port dot1x tx-period	86
set port duplex	87
set port edge admin state	87
set port enable	88
set port flowcontrol	88
set port level	89

set port mirror	90
set port name	90
set port negotiation	91
set port point-to-point admin status	92
set port powerinline	92
set port powerinline priority	93
set port redundancy	93
set port redundancy on/off	94
set port redundancy-intervals	94
set port security	95
set port spantree cost	95
set port spantree disable	96
set port spantree enable	96
set port spantree force-protocol-migration	97
set port spantree priority	97
set port speed	98
set port static-vlan	98
set port trap	99
set port vlan	99
set port vlan-binding-mode	100
set ppp authentication incoming	101
set ppp baud-rate	101
set ppp chap-secret	102
set ppp incoming timeout	102
set psu type	103
set queuing scheme	103
set radius authentication enable/disable	104
set radius authentication retry-number	104
set radius authentication retry-time	105
set radius authentication secret	105
set radius authentication server	106
set radius authentication udp-port	106
set security mode	106
set snmp community	107
set snmp retries	107
set snmp timeout	107
set snmp trap	108
set snmp trap auth	109

set spantree default-path-cost	109
set spantree disable	110
set spantree enable	110
set spantree forward-delay	111
set spantree hello-time	111
set spantree max-age	112
set spantree priority	112
set spantree tx-hold-count	113
set spantree version	113
set system contact	114
set system location	114
set system name	115
set terminal recovery password disable	115
set terminal recovery password	116
set time client	116
set time protocol	117
set time server	117
set timezone	118
set trunk	118
set utilization cpu	119
set vlan	119
set web aux-files-url	120
set welcome message	120
show allowed managers status	121
show allowed managers table	121
show arp-aging-interval	122
show arp-tx-interval	122
show autopartition	122
show boot bank	123
show cam	123
show cam mac	124
show cam vlan	124
show cascading fault-monitoring	125
show dev log file	126
show device-mode	126
show dot1x	126
show dot1x statistics	127
show download status	127

show image version	128
show intelligent-multicast	128
show intelligent-multicast hardware-support	129
show interface	129
show intermodule port redundancy	130
show internal buffering	130
show ip route	130
show ip ssh	131
show l2-module-config	132
show l2-stack-config	134
show leaky-vlan	135
show license	136
show log	136
show logging file condition	137
show logging file content	137
show logging server condition	139
show logging session condition	140
show logout	140
show mac-aging	141
show mac-aging-time	141
show module	141
show module-identity	142
show port	143
show port auto-negotiation-flowcontrol-advertisement	144
show port channel	144
show port classification	145
show port dot1x	146
show port dot1x statistics	148
show port edge state	148
show port flowcontrol	149
show port mirror	150
show port point-to-point status	150
show port redundancy	151
show port security	152
show port trap	152
show port vlan-binding-mode	153
show powerinline	153
show ppp authentication	154

show ppp baud-rate	154
show ppp configuration	155
show ppp incoming timeout	155
show ppp session	155
show protocol	156
show queuing scheme	156
show radius authentication	157
show rmon alarm	157
show rmon event	158
show rmon history	158
show rmon statistics	159
show secure current	160
show security mode	160
show serial-number	161
show snmp	161
show snmp retries	162
show snmp timeout	163
show spantree	163
show system	165
show tftp download software status	166
show time	166
show time parameters	167
show timeout	167
show timezone	167
show trunk	168
show upload status	169
show username	170
show utilization	170
show vlan	171
show web aux-files-url	172
stack health	172
sync time	173
tech	173
telnet	173
terminal length	174
terminal width	174
tree	174
username	175

3	Avaya C360 Layer 3 CLI Commands	177
	area	177
	arp	177
	arp timeout	178
	clear arp-cache	179
	clear fragment	179
	clear ip route	180
	clear ip traffic	180
	clear screen	180
	clear vlan	181
	configure	181
	copy running-config scp	181
	copy running-config startup-config	182
	copy running-config tftp	183
	copy scp startup-config	183
	copy startup-config scp	184
	copy startup-config tftp	185
	copy tftp startup-config	185
	default-metric	186
	disconnect ssh	186
	enable vlan commands	187
	erase startup-config	187
	event log	188
	exit	188
	fragment chain	189
	fragment size	189
	fragment timeout	190
	help	190
	hostname	191
	icmp in-echo-limit	192
	interface	192
	ip access-default-action	193
	ip access-group	193
	ip access-list	194
	ip access-list-cookie	195
	ip access-list-copy	195
	ip access-list-dscp name	196
	ip access-list-dscp operation	196

ip access-list-dscp trust	197
ip access-list-name	198
ip access-list-owner	198
ip address	199
ip admin-state	199
ip bootp-dhcp network	200
ip bootp-dhcp relay	200
ip bootp-dhcp server	201
ip broadcast-address	202
ip default-gateway	202
ip directed-broadcast	203
ip icmp-errors	203
ip max-arp-entries	204
ip max-route-entries	204
ip netbios-rebroadcast	205
ip netmask-format	206
ip ospf authentication-key	206
ip ospf cost	207
ip ospf dead-interval	207
ip ospf hello-interval	208
ip ospf priority	208
ip ospf router-id	209
ip proxy-arp	209
ip redirects	210
ip rip authentication key	210
ip rip authentication mode	210
ip rip default-route-mode	211
ip rip poison-reverse	212
ip rip rip-version	212
ip rip send-receive-mode	213
ip rip split-horizon	213
ip route	214
ip routing	215
ip routing-mode	215
ip simulate	216
ip vlan/ip vlan name	216
ip vrrp	217
ip vrrp address	217

ip vrrp auth-key	218
ip vrrp override addr owner	218
ip vrrp preempt	219
ip vrrp primary	219
ip vrrp priority	220
ip vrrp timer	221
network (OSPF context)	221
network (RIP context)	222
no arp	223
no arp timeout	223
no fragment chain	223
no fragment size	223
no fragment timeout	223
no hostname	223
no icmp in-echo-limit	223
no interface	223
no ip access-group	223
no ip access-list	223
no ip bootp-dhcp relay	224
no ip default-gateway	224
no ip icmp-errors	224
no ip max-arp-entries	224
no ip max-route-entries	224
no ip netmask-format	224
no ip ospf router-id	224
no ip route	224
no ip routing	224
no router ospf	224
no router rip	225
no router vrrp	225
passive-interface	225
ping	225
prompt-length	226
redistribute (OSPF context)	227
redistribute (RIP context)	227
reset	228
router ospf	228
router rip	228

router vrrp	229
session	229
set device-mode	230
set logout	231
set system contact	231
set system location	232
set system name	232
set vlan	233
show copy status	233
show device-mode	234
show download status	234
show erase status	235
show fragment	235
show ip access-group	236
show ip access-list-dscp	236
show ip access-list-summary	237
show ip arp	238
show ip icmp	238
show ip interface	239
show ip interface brief	240
show ip ospf	240
show ip ospf database	241
show ip ospf interface	241
show ip ospf neighbor	242
show ip protocols	242
show ip reverse-arp	243
show ip route	244
show ip route best-match	244
show ip route static	244
show ip route summary	245
show ip ssh	245
show ip traffic	246
show ip unicast cache	248
show ip unicast cache networks	249
show ip unicast cache networks detailed	250
show ip unicast cache nextHop	251
show ip unicast cache summary	251
show ip vrrp	252

show ip vrrp detail	252
show running-config	254
show startup-config	255
show system	255
show upload status	256
show vlan	257
tech	257
terminal length	257
terminal width	257
timers basic	258
timers spf	259
traceroute	259
tree	260
validate-group	261
4 Avaya C360 Layer 3 CLI Commands	263
• interface context	263
• ospf context	263
• rip context	264

1 Using the CLI

This chapter describes the C360 CLI architecture and conventions, and provides instructions for accessing the C360 for configuration purposes.

The configuration procedure involves establishing a Telnet session or a serial connection and then using the C360's internal CLI.

The CLI is command-line driven and does not have any menus. To activate a configuration option, you must type the desired command at the prompt and press Enter.

You can also configure your Avaya C360 using the C360 Device Manager with its graphical user interface. For details, see the *Avaya C360 Installation and Maintenance Guide* and the *Avaya C360 Device Manager User's Guide* on the *Avaya C360 Documentation and Utilities CD*.

CLI Architecture

The C360 supports both Layer 2 switching and Layer 3 routing (Layer 3 functionality depends on the module type).

The C360 CLI includes two CLI entities to support this functionality.

- The Switch CLI entity is used to manage Layer 2 switching of the entire stack. The Switch CLI entity is identical to the CLI of a C360 Layer 2 modules. CLI commands for managing Layer 2 switching are described in [Chapter 2, “Avaya C360 Layer 2 CLI Commands”](#).
- The Router CLI entity is used to manage Layer 3 routing of a single module. The Router CLI entity exists only in the C360-ML. CLI commands for managing Layer 3 routing are described in [Chapter 3, “Avaya C360 Layer 3 CLI Commands”](#).

If the Layer 3 module is the Stack Master, then the Switch CLI entity and the Router CLI entity co-exist on the same module.

To switch between the entities, use the **session** command.

Configuration of the **password** commands and **community** commands in one entity is automatically attributed to the other entity in the stack.

Initial access to the stack can be established via a serial connection or a Telnet connection to any one of the entities.

Conventions Used

The following conventions are used in this chapter to convey instructions and information:

- Mandatory keywords are in boldface.
- Variables that you supply are in pointed brackets < >.

- Optional keywords are in square brackets [].
- Alternative but mandatory keywords are grouped in braces { } and separated by a vertical bar |.
- If you enter an alphanumeric string of two words or more, enclose the string in inverted commas, e.g., “new york”.
- Information displayed on screen is displayed in `text` font.

CLI Help

The CLI has its own Help utility. Use the following key sequences to operate the CLI Help:

- To display all commands available in a context type a question mark.
Example: Router> `show ?`
- To display all commands starting with a certain string, type the first few letters followed by a question mark.
- To get help containing all commands parameters with their legal values as well as its syntax and an example, type a question mark at the end of command or at the stage where it is unique.
- Use the Tab key to complete an unambiguous command.

Command Line Prompt

- Host name of the CLI entity - the host name is used as the prefix of the command prompt.
- Module Number - counting from the bottom up used as part of the prefix. In this document the Module number in the prompt is generic and is represented by “N”.
- Security level - used as the suffix of the prompt (Refer to [Security Levels](#) on page 23.)
- Application context - used as body of the prompt, this part is not mandatory.

Example:

Host name of the router is NewYork

Router is module number three

Application context is OSPF

The command line prompt looks as follows:

```
NewYork-3(configure router:ospf)#
```

Navigation, Cursor Movement and Shortcuts

The CLI contains a simple text editor with these functions:

Table 1: Navigation, Cursor Movement and Shortcuts

Keyboard	Functions
Backspace	Deletes the previous character
Up arrow/Down arrow	Scrolls back and forward through the command history buffer
Left arrow/Right arrow	Moves the cursor left or right
Tab	Completes the abbreviated command. Type the minimum number of characters unique to the command. An exception is the Reset System command which you must type in full.
Enter	Executes a single-line command
“ ”	If you type a name with quotation marks, the marks are ignored.

Command Syntax

Commands are not case-sensitive. That is, uppercase and lowercase characters may be interchanged freely.

Command Abbreviations

All commands and parameters in the CLI can be truncated to an abbreviation of any length, as long as the abbreviation is not ambiguous. For example, `version` can be abbreviated `ver`.

For ambiguous commands, type the beginning letters on the command line and then use the Tab key to toggle through all the possible commands beginning with these letters.

Universal Commands

Universal commands are commands that can be issued anywhere in the hierarchical tree.

Top and Up commands

The `Up` command moves you up to the next highest level in the CLI command hierarchy. The `Top` command moves you to the highest level.

Retstatus command

Use the `retstatus` command to show whether the last CLI command you performed was successful. It displays the return status of the previous command.

The syntax for this command is: **retstatus**

Output Example:

```
C360 # set port negotiation 2/4 disable  
  
Link negotiation protocol disabled on port 2/4.  
  
Router(enable)# retstatus  
  
Succeeded
```

Tree command

The `tree` command displays the commands that are available at your current location in the CLI hierarchy.

The syntax for this command is: **tree**

C360 Sessions

You can use sessions to switch between the CLI of C360 modules or other stack entities or to switch between Layer 2 and Layer 3 commands.

To switch between C360 modules use the command:

```
session [<mod_num>] <mode>.
```

The `<mod_num>` is the number of the module in the stack, counting from the bottom up.

The `<mode>` can be either `switch`, `router`, `wan`, `atm`, or `mgp`.

Use `switch` mode to configure layer 2 commands.

Use `router` mode to configure routing commands.

Examples:

To configure router parameters in the module that you are currently logged into, type the following command:

```
session router.
```

To configure the switch parameters, on module 6, type the command:

```
session 6 switch.
```



Tip:

When you use the `session` command the security level stays the same.



Tip:

Use the `session` command without any parameters to identify the stack master and its slot number. It will list all the modules in the stack and their slot number with the master module marked with an asterisk.

Security Levels

There are four security access levels – User, Privileged, Configure and Supervisor.

- The User level is a general access level used to show system parameter values.
- The Privileged level is used by site personnel to access stack configuration options.
- The Configure level is used by site personnel for Layer 3 configuration.
- The Supervisor level is used to define user names, passwords, and access levels of up to ten local users.

A login name and password are always required to access the CLI and the commands. The login names and passwords, and security levels are established using the `username` command.

Switching between the entities, does not effect the security level since security levels are established specifically for each user. For example, if the operator with a privileged security level in the Switch entity switches to the Router entity the privileged security level is retained.

Entering the Supervisor Level

The Supervisor level is the level in which you first enter the CLI and establish user names for up to 10 local users. When you enter the Supervisor level, you are asked for a Login name. Type `root` as the Login name and the default password `root` (in lowercase letters):

```
Welcome to C360

Login: root

Password:****

Password accepted.

C360-N(super)#
```

Defining new users

Define new users and access levels using the `username` command in Supervisor Level.

Exiting the Supervisor Level

To exit the Supervisor level, type the command `exit`.

Entering the CLI

To enter the CLI, enter your username and password. Your access level is indicated in the prompt as follows:

The User level prompt is shown below:

```
C360-N>
```

The Privileged level prompt is shown below:

```
C360-N#
```

The Configure level prompt for Layer 3 configuration is shown below:

```
C360-N(configure)#
```

The Supervisor level prompt is shown below:

```
C360-N(super)#
```

Entering the Technician Level

This level is can only be accessed from the Privileged and Supervisor levels not from the User level.

This feature is not documented and is for use by Avaya Technical Support only.

Warranty

Avaya Inc. provides a limited warranty on this product. Refer to your sales agreement or other applicable documentation to establish the terms of the limited warranty. In addition, Avaya's standard warranty language as well as information regarding support for this product, while under warranty, is available through the following website: www.avaya.com/support

Notice

Every effort was made to ensure that the information in this document was complete and accurate at the time of printing. However, information is subject to change.

Avaya Support

Avaya provides a telephone number for you to use to report problems or to ask questions about your contact center. The support telephone number is 1-800-242-2121 in the United States. For additional support telephone numbers, see the Avaya Web site: www.avaya.com/support

2 Avaya C360 Layer 2 CLI Commands

This chapter describes all the C360 Layer 2 CLI commands and parameters in alphabetical order.

clear cam

User level: privileged, supervisor.

Use the `clear cam` command to delete all entries from the CAM table.

The syntax for this command is:

```
clear cam
```

Example:

```
C360-N# clear cam
CAM table cleared.
```

clear dot1x config

User level: supervisor

Use the `clear dot1x config` command to disable dot1x on all ports and return values to the default settings.

The syntax for this command is:

```
clear dot1x config
```

Example:

```
C360-N# clear dot1x config
Original Configuration was Restored
```

clear dynamic vlans

User level: privileged, supervisor.

Use the `clear dynamic vlans` command to clear dynamically learned VLANs. Only the VLANs learned by the switch from incoming traffic are cleared using this command.

The syntax for this command is:

```
clear dynamic vlans
```

Example:

```
C360-N# clear dynamic vlans
This command will delete all the vlans that were dynamically
learned by the device - do you want to continue (Y/N)? y

Dynamic vlans were deleted from device tables
```

clear ip route

User level: privileged, supervisor.

Use the `clear ip route` command to delete the IP routing table entries.

The syntax for this command is:

```
clear ip route <destination> <gateway>
```

destination	IP address of the network, or specific host to be removed
gateway	IP address of the gateway

Example:

```
C360-N# clear ip route 134.12.3.0 255.255.255.0

Route deleted.
```

clear log

User level: privileged, supervisor.

Use the `clear log` command to delete the log file of a switch.

The syntax for this command is:

```
clear log [<module>]
```

module (Optional)	Number of switch (1 to 10)
----------------------	----------------------------

Example:

```
C360-N# clear log 1

Cleared logfile of module 1.
```

clear logging file

User level: privileged, supervisor.

Use the `clear logging file` command to delete the log file and open an empty one.

The syntax for this command is:

```
clear logging file
```

Example:

```
C360-N> clear logging file
Done!
```

clear logging server

User level: privileged, supervisor.

Use the `clear logging server` command to delete a Syslog server from the Syslog server table.

The syntax for this command is:

```
clear logging server <ip-address>
```

ip-address	The IP address of the Syslog server.
------------	--------------------------------------

Example:

```
C360-N# clear logging server 149.49.38.22
Done!
```

clear port mirror

User level: privileged, supervisor.

Use the `clear port mirror` command to cancel port mirroring.

The syntax for this command is:

```
clear port mirror [<source module>/<source port>/<dest module>/<dest port>]
```

source module	Source module number (optional)
source port	Source port number (optional)
dest module	Destination module number (optional)
dest port	Destination port number (optional)

Example:

```
C360-N# clear port mirror
this command will delete the port mirror entry
- do you want to continue (Y/N)? y
Mirroring packets from port 1/2 to port 1/4 is cleared
```

clear port static-vlan

User level: privileged, supervisor.

Use the `clear port static-vlan` command to delete VLANs statically configured on a port.

The syntax for this command is:

```
clear port static-vlan [module/port range][vlan num]
```

module/port range	Port range
vlan num	The VLAN to unbind from the port

Example:

```
C360-N# clear port static-vlan 3/10 5
VLAN 5 is unbound from port 3/10
```

clear radius authentication server

User level: supervisor

Removes a primary or secondary RADIUS authentication server.

The syntax for this command is:

```
clear radius authentication server[{primary|secondary}]
```

primary	Remove primary RADIUS server
secondary	Remove secondary RADIUS server

Example:

```
C360-1(super)# clear radius authentication server secondary
```

clear rmon statistics

User level: privileged, supervisor.

Use the `clear rmon statistics` command to clear the RMON statistics counter.

The syntax for this command is:

```
clear rmon statistics
```

Example:

```
C360-N# clear rmon statistics
cleared device counters
```

clear screen

User level: user, privileged, supervisor

Use the `clear screen` command to clear the current terminal display.

The syntax for this command is:

```
clear screen
```

clear snmp trap

User level: privileged, supervisor.

Use the `clear snmp trap` command to clear an entry from the SNMP trap receiver table.

The syntax for this command is:

```
clear snmp trap {<rcvr_addr>|all}
```

rcvr_addr	IP address or IP alias of the trap receiver (the SNMP management station) to clear
all	Keyword that specifies every entry in the SNMP trap receiver table

Example:

```
C360-N# clear snmp trap 192.168.173.42
SNMP trap deleted.
```

clear ssh-client known-hosts

User level: privileged, supervisor.

Use the `clear ssh-client known-hosts` command to clear the known-hosts file used for scp authentication. It allows scp authentication after scp server public key has been changed.



SECURITY ALERT:

Using this command can cause exposure to the “man-in the middle” attack.

The syntax for this command is:

```
clear ssh-client known-hosts
```

Example:

```
C360-N# clear ssh-client known-hosts
Done!
```

clear timezone

User level: privileged, supervisor.

Use the `clear timezone` command to reset the time zone to its default value UTC (Coordinated Universal Time)

The syntax for this command is:

```
clear timezone
```

Example:

```
C360-N# clear timezone
Timezone name and offset cleared.
```

clear utilization cpu

User level: privileged, supervisor.

Use the `clear utilization cpu` command to disable CPU utilization monitoring on the specified module.

The syntax for this command is:

```
clear utilization cpu <module-number>
```

module-number	The module number for which CPU utilization monitoring is disabled.
---------------	---

Example:

```
C360-N# clear utilization cpu 1
CPU utilization is cleared on module 1
```

clear vlan

User level: privileged, supervisor.

Use the `clear vlan` command to delete an existing VLAN and return ports from this VLAN to the default VLAN #1. When you clear a VLAN, all ports assigned to that VLAN are assigned to the default VLAN #1.

The syntax for this command is:

```
clear vlan [<vlan-id>|name <vlan_name>]
```

vlan_id	VLAN number
vlan_name	VLAN name

If you wish to enter a name which includes spaces, you must enclose the entire name in quotation marks, for example "new york".

Example:

```
C360-N# clear vlan 100
This command will assign all ports on vlan 100 to their default in
the entire management domain - do you want to continue (Y/N)? y
VLAN 100 was deleted successfully
```

configure

User level: privileged, supervisor.

Use the `configure` command to enter configure mode.

The syntax for this command is:

```
configure
```

Example:

```
C360-N# configure
C360-N(configure)#
```

copy module-config scp

User level: supervisor

Use the `copy module-config scp` command to upload the switch-level parameters from the current NVRAM running configuration into a file via SCP.

The syntax for this command is:

```
copy module-config scp <filename> <ip> <mod_num>
```

filename	The file name (full path)
ip	The IP address of the SCP server
mod-num	The switch number

Example:

```
C360-N# copy module-config scp c:\config\switch1.cfg 192.168.49.10 5
Username: 360user
Password:
Beginning upload operation ...
This operation may take a few minutes...
Please refrain from any other operation during this time.
For more information , use 'show upload status' command

*****
* If you are currently running the C360 Device Manager application,*
* it is recommended to exit from it before performing configuration*
* download operations.                                           *
*****
```

copy module-config tftp

User level: supervisor

Use the `copy module-config tftp` command to upload the switch-level parameters from the current NVRAM running configuration into a file via TFTP.

The syntax for this command is:

```
copy module-config tftp <filename> <ip> <mod_num>
```

filename	The file name (full path)
ip	The IP address of the TFTP server
mod-num	The switch number



Tip:

The following file name convention is recommended:
Take the last two digits of the IP address, prefixed by the upload type (module) and the number of the module remote file name : <t><m><i>

- <t> - module type (m)
- <m> - module number 1 to 9 and 0 for 10
- <i> - last 2 numbers of the IP address

Example:

```
C360-N# copy module-config tftp C:\m5134153.cfg 149.49.134.153 5
Username: 360user
Password:
Beginning upload operation ...
This operation may take a few minutes...
Please refrain from any other operation during this time.
For more information , use 'show upload status' command

*****
* If you are currently running the C360 Device Manager application,*
* it is recommended to exit from it before performing configuration*
* download operations.*
*****
```

copy scp module-config

User level: supervisor

Use the `copy scp module-config` command to download a module configuration to the device via SCP.



Tip:

Only parameters that differ from the factory default settings for the switch are included in the configuration file. Therefore, it is important to reinitialize the NVRAM to the factory default settings before downloading configuration files to the switch. To reinitialize the NVRAM, run the `nvrाम initialize` command.

The syntax for this command is:

```
copy scp module-config <filename> <ip>
```

filename	Source file name on the SCP server (full path).
ip	The ip address of the SCP server.

Example:

```
C360-N# copy scp module-config c:\C360\module.cfg 149.49.100.41

Username: 360user
Password:
Beginning download operation ...
This operation may take a few minutes...
Please refrain from any other operation during this time.
For more information , use 'show download status' command

*****
* If you are currently running the C360 Device Manager application,*
* it is recommended to exit from it before performing configuration*
* download operations.*
*****
```

Example: (for Unix):

```
C360-N# copy scp module-config /folder/C360/module.cfg 149.49.100.41
Username: 360user
Password:
Beginning download operation ...
This operation may take a few minutes...
Please refrain from any other operation during this time.
For more information , use 'show download status' command

*****
* If you are currently running the C360 Device Manager application,*
* it is recommended to exit from it before performing configuration*
* download operations.                                           *
*****
```

copy scp stack-config

User level: supervisor

Use the `copy scp stack-config` command to download a stack configuration to the device via SCP.

NOTE:

Only parameters that differ from the factory default settings for the switch are included in the configuration file. Therefore, it is important to reinitialize the NVRAM to the factory default settings before downloading configuration files to the switch. To reinitialize the NVRAM, run the `nvr initialize` command.

The syntax for this command is:

```
copy scp stack-config <filename> <ip>
```

filename	Source file name on the SCP server (full path).
ip	The ip address of the SCP server.

Example: (for Windows)

```
C360-N# copy scp stack-config c:\C360\stack.cfg 149.49.100.41
Username: 360user
Password:
Beginning download operation ...
This operation may take a few minutes...
Please refrain from any other operation during this time.
For more information , use 'show download status' command

*****
* If you are currently running the C360 Device Manager application,*
* it is recommended to exit from it before performing configuration*
* download operations.                                           *
*****
```

Example: (for Unix):

```
C360-N# copy scp stack-config /folder/C360/stack.cfg 149.49.100.41
Username: 360user
Password:
Beginning download operation ...
This operation may take a few minutes...
Please refrain from any other operation during this time.
For more information , use 'show download status' command

*****
* If you are currently running the C360 Device Manager application,*
* it is recommended to exit from it before performing configuration*
* download operations. *
*****
```

copy stack-config scp

User level: supervisor

Use the `copy stack-config scp` command to upload the switch-level parameters from the active bank into a file via SCP.

The syntax for this command is:

```
copy stack-config scp <filename> <ip> <mod_num>
```

filename	The file name (full path)
ip	The IP address of the SCP server
mod-num	The switch number

Example:

```
C360-N# copy stack-config scp c:\config\switch1.cfg 192.168.49.10 5
Username: 360user
Password:
Beginning upload operation ...
This operation may take a few minutes...
Please refrain from any other operation during this time.
For more information , use 'show upload status' command

*****
* If you are currently running the C360 Device Manager application,*
* it is recommended to exit from it before performing configuration*
* download operations. *
*****
```

copy stack-config tftp

User level: supervisor

Use the `copy stack-config tftp` command to upload the stack-level parameters from the current NVRAM running configuration into a file via TFTP.

NOTE:

Create the file into which you wish to upload the stack-level parameters prior to executing this command.

The syntax for this command is:

```
copy stack-config tftp <filename> <ip>
```

filename	The file name (full path)
ip	The IP address of the TFTP server

Example:

```
C360-N# copy stack-config tftp c:\conf.cfg 192.168.49.10
Beginning upload operation ...
This operation may take a few minutes...
Please refrain from any other operation during this time.
For more information , use 'upload status' command
*****
* If you are currently running the C360 Device Manager application,*
* it is recommended to exit from it before performing configuration*
* download operations.*
*****
```

copy tftp EW_Archive

User level: privileged, supervisor.

Use the `copy tftp EW-Archive` command to download the C360 Device Manager application into the switch via TFTP.



Tip:

To use this command, you need to have an active TFTP server and to create a file into which to download the data.



Tip:

If Avaya Integrated Manager is running, you do not require an additional TFTP server..

The syntax for this command is:

```
copy tftp EW_archive <filename> <ip>
```

filename	C360 Device Manager image file name (full path)
----------	---

ip	The IP address of the host
----	----------------------------

Example:

```
C360-N# copy tftp EW-archive c:\C360\switch1.cfg 192.168.49.10
```

copy tftp module-config

User level: supervisor

Use the `copy tftp module-config` command to download the switch-level configuration from a saved file into the current NVRAM running configuration of a switch from a TFTP server.

NOTE:

Only parameters that differ from the factory default settings for the switch are included in the configuration file. Therefore, it is important to reinitialize the NVRAM to the factory default settings before downloading configuration files to the switch. To reinitialize the NVRAM, run the `nvr initialize` command.

The syntax for this command is:

```
copy tftp module-config <filename> <ip>
```

filename	The file name (full path)
ip	The ip address of the TFTP server

Example: (for Windows)

```
C360-N# copy tftp module-config c:\config\switch1.cfg 192.168.49.10
```

Example: (for Unix):

```
C360-N# copy tftp module-config /folder/startup.cfg 192.168.49.10
```

copy tftp stack-config

User level: supervisor

Use the `copy tftp stack-config` command to download the stack-level configuration from a saved file into the current NVRAM running configuration from a TFTP server.

NOTE:

Only parameters that differ from the factory default settings for the switch are included in the configuration file. Therefore, it is important to reinitialize the NVRAM to the factory default settings before downloading configuration files to the switch. To reinitialize the NVRAM, run the `nvr initialize` command.

The syntax for this command is:

```
copy tftp stack-config <filename> <ip>
```

filename	The file name (full path)
ip	The IP address of the TFTP server

Example: (for Windows)

```
C360-1(super)# copy tftp stack-config c:\config\switch1.cfg
192.168.49.10
```

Example: (for Unix):

```
C360-1(super)# copy tftp stack-config /folder/switch1.cfg 192.168.49.10
```

copy tftp SW_image

User level: supervisor

Use the `copy tftp SW_image` command to download a new firmware version into bank B while either keeping the old version in bank A, or downloading the Device Manager software into bank A.

The syntax for this command is:

```
copy tftp SW_image <sw_image_file> EW_archive <EmWeb_file> <IP_addr> <mod_num>
```

sw_image_file	Firmware image file name (full path)
EmWeb_file	Device Manager image file name (full path) - Optional, can be a dummy name
IP_addr	The ip address of the TFTP server
mod_num	Target switch module number

Example: (for Windows)

```
C360-1(super)# copy tftp SW_image c:\versions\C360\p333t EW_image x
149.49.138.170 1
```

Example: (for Unix):

```
C360-1(super)# copy tftp SW_image /folder/versions/C360/p333t EW_image
x 149.49.138.170 1
```



Tip:

If file "x" does not exist, the Embedded web image will not be downloaded and bank A will retain the previous SW version image.

Example:

```
C360-N# copy tftp SW_image /home/C360/viisa EW_archive 1 135.64.103.104 1
Module           : 1
Source file      : /home/C360/viisa
Destination file : C360
Host            : 135.64.103.104
Running state   : Download Process Started
Failure display  : no-error
Last warning    : -
.....
Module           : 1
Source file      : /home/C360/viisa
Destination file : C360
Host            : 135.64.103.104
Running state   : Testing ...
Failure display  : no-error
Last warning    : -
.....
Module           : 1
Source file      : /home/C360/viisa
Destination file : C360
Host            : 135.64.103.104
Running state   : Erasing FLASH
Failure display  : no-error
Last warning    : -
.....
Module           : 1
Source file      : /home/C360/viisa
Destination file : C360
Host            : 135.64.103.104
Running state   : Downloading ...
Failure display  : no-error
Last warning    : -
...
Module           : 1
Source file      : /home/C360/viisa
Destination file : C360
Host            : 135.64.103.104
Running state   : Download Ok
Failure display  : no-error
Last warning    : -
```

copy tftp SW_powerinline_image

User level: supervisor

NOTE:

This command applies to P333T-PWR switches only and is used by C360 switches to control P333T-PWR modules in the stack.

Use the `copy tftp SW_powerinline_image` command to update the inline software application from a TFTP server to the memory of a designated module. You need to be in privilege mode to execute this command.

The syntax for this command is:

```
copy tftp SW_powerinline_image <image-file> <ip-addr> <mod-num>
```

image_file	Common name for the file that contain the Power over Ethernet (PoE) Software image and the Embedded Web archive (full path)
ip_addr	IP address of the TFTP host
mod_num	Target module number

Example:

```
C360-1# copy tftp SW_powerinline_image c:\c360\p333T_203 192.168.49.10 5
Module: 5
Source file:c:\p333t\p333t_203
Destination file:Powerinline
Host: 192.168.49.10
Running state:Downloading
Failure Display:Access Violation
Last warning:

Download completed
```

NOTE:

Before executing the download, the following checks will be performed by embedded SW, on the TFTP server file:

- Ensure that the file size is within its allocated space.
- Check that the file contains embedded web SW for this application
- Verify file validity by calculating the checksum.

crypto key generate DSA

User level: supervisor

Use the `crypto key generate DSA` command to create a new SSH server DSA public key.

The syntax for this command is:

```
crypto key generate DSA [key-size <key-length>]
```

key-size	A keyword specifying that the key length is provided by the user.
----------	---

key-length	The number of bits in the key. Possible values are: 512 – 2048. The default is 768 bits.
------------	---

Example:

```
C360-1(super)# crypto key generate dsa key-size 768
Generating DSA key, This command may take a few minutes...
.....
Key was created!
Key version: SSH2, DSA
Key Fingerprint: a5:f8:4a:5d:c5:b5:9c:b5:26:51:2b:36:02:c0:18:a4
```

dir

User level: user, privileged, supervisor

Use the dir command to show the file types that have been downloaded to the switch.

The syntax for this command is:

```
dir [module_number]
```

Example:

```
C360-N> dir
M# file                ver num  file type    file location  file description
-- ----                -
1  Booter_Image         3.5.17   SW BootImage Nv-Ram         Booter Image
1  module-config        N/A     Running Conf Ram            Module Configuration
1  stack-config         N/A     Running Conf Ram            Stack Configuration
1  EW_Archive           N/A     SW Web Image Nv-Ram         Web Download
2  Booter_Image         3.2.5   SW BootImage Nv-Ram         Booter Image
2  module-config        N/A     Running Conf Ram            Module Configuration
2  EW_Archive           N/A     SW Web Image Nv-Ram         Web Download
```

Output Fields:

Field	Description
M#	The switch number

file	<p>There are several files loaded into the switch's memory:</p> <ul style="list-style-type: none"> • module-config – file which contains the configuration settings made to this switch • stack-config – file which contains the configuration settings made at the stack level (for example IP address of the stack) • EW_Archive – file which contains the Device Manager (Embedded Web) software • Booter_Image - file containing the booter code executed after reset. This file can't be replaced by the user. • startup-config - file which contains the startup (saved in NVRAM) configuration for policy and routing in the C360 • running-config - file which contains the running (currently active) configuration for policy and routing in the C360
ver num	S/W Version number – relevant only for Device Manager and Booter image.
file type	<p>There are several file types:</p> <ul style="list-style-type: none"> • Running Conf – the configuration currently in use. • Startup-config - startup configuration for policy and routing in the C360 • SW boot image - Booter file • SW Web Image – Device Manager S/W archive file
file location	Type of internal memory into which the file is loaded
file description	Description of the file

**Tip:**

If N/A is displayed for the EW_Archive file, this means that the Device Manager software is not loaded correctly. Download the Device Manager software again.

disconnect ssh

User level: supervisor

Use the `disconnect ssh` command to disconnect an SSH session.

The syntax for this command is:

```
disconnect ssh <session-id>
```

session-id	The SSH session ID.
------------	---------------------

Example:

```
C360-1(super)# disconnect ssh 0x508622f0

You are about to close this session - do you want to continue (Y/N)? y

Closing session 0x508622f0
```

get time

User level: privileged, supervisor.

Use the `get time` command to retrieve the time from the network.

The syntax for this command is:

```
get time
```

Example:

```
C360-N> get time
Time is being acquired from server 0.0.0.0
Time has been acquired from the network.
```

help

User level: user, privileged, supervisor

Use the `help` command to print a list of all possible commands at the current level. If a command is specified and has no further sub-command(s), the help for that command is printed. If the command has a further sub-command, a brief description of the sub-command is printed.

The syntax for this command is:

```
help [<command> [<subcommand>...]]
```

Example:

```
C360-N> help hostname
Hostname commands:
-----
Usage: hostname [<hostname_string>]
    <hostname_string> : none    - displays current hostname
    <hostname_string> : string - string to be used as the hostname (up to
20 characters)
Example: hostname
    hostname M_MLS_LAB
    hostname #
```

hostname

User level: privileged, supervisor.

Use the `hostname` command to change the Command Line Interface (CLI) prompt. The current module number always appears at the end of the prompt.

Use the `no hostname` command to return the CLI prompt to its default.

The syntax for this command is:

```
[no] hostname [<hostname_string>]
```

hostname_string	<ul style="list-style-type: none"> • none – displays current hostname • string – the string to be used as the hostname (up to 20 characters).
-----------------	---

Example:

```
C360-N# hostname
Session hostname is 'C360'
```

```
C360-N# hostname "gregory"
gregory-N#
```

```
gregory-N# no hostname
C360-N#
```



Tip:

If you wish to enter a name which includes spaces, you must enclose the entire name in quotation marks, for example “new york”.

ip http

User level: supervisor

Use the `ip http enable` command to enable HTTP access to the device.

Use the `no ip http` command to disable HTTP access to the device.

The syntax for this command is:

```
[no] ip http
```

Example:

```
C360-1(super)# ip http
Done!
```

ip icmp redirect

User level: supervisor

Use the `ip icmp redirect` command to enable ICMP redirects via the device.

Use the `no ip icmp redirect` command to disable ICMP redirects via the device.

The syntax for this command is:

```
[no] ip icmp redirect
```

Example:

```
C360-1(super)# ip icmp redirect
Done!
```

ip ssh

User level: supervisor

Use the `ip ssh` command to enable the SSH server.

Use the `no ip ssh` command to disable the SSH server.

The syntax for this command is:

```
[no] ip ssh enable
```

Example:

```
C360-1(super)# ip ssh enable
Done!
```

ip telnet

User level: supervisor

Use the `ip telnet` command to enable Telnet access to the device.

Use the `no ip telnet` command to disable Telnet access to the device.

The syntax for this command is:

```
[no] ip telnet
```

Example:

```
C360-1(super)# ip telnet
Done!
```

ip telnet-client

User level: supervisor

Use the `ip telnet-client enable` command to enable the device to act as a Telnet client.



Tip:

This command can only be run from the console port on the device.

The syntax for this command is:

```
ip telnet-client
```

Example:

```
C360-1(super)# ip telnet-client
Done!
```

no hostname

See [hostname](#) on page 46

no ip http

See [ip http](#) on page 46.

no ip icmp redirect

See [ip icmp redirect](#) on page 47.

no ip ssh

See [ip ssh](#) on page 47.

no ip telnet

See [ip telnet](#) on page 47.

no ip telnet-client

See [ip telnet-client](#) on page 48.

no rmon alarm

See [rmon alarm](#) on page 54.

no rmon event

See [rmon event](#) on page 54.

no rmon history

See [rmon history](#) on page 55.

no username

See [username](#) on page 175.

nvrn initialize

User level: privileged, supervisor.

Use the `nvrn initialize` command to reset the configuration parameters to their factory defaults.

The syntax for this command is:

```
nvrn initialize {switch | all}
```

switch	Resets all the switching parameters (Layer 2 only) throughout the stack
all	Resets all parameters including licenses and routing parameters of the Layer 3 switches present in the stack

Example:

```
C360-N# nvrn initialize
This command will restore factory defaults, and can disconnect
your telnet session
*** Reset *** - do you want to continue (Y/N)? y
Connection closed by foreign host
```

ping

User level: user, privileged, supervisor

Use the `ping` command to send ICMP echo request packets to another node on the network.



Tip:

You can use this command via the master switch only.

The syntax for this command is:

```
ping [host[number]]
```

host	Host IP address/Internet address of route destination. If you do not specify these host IP address, then the host IP address specified in the last ping command is used.
number	Number of packets to send. If you do not specify the number, then the number specified in the last ping command is used. The default is 5.

Example: to ping the IP address 149.49.48.1 three times:

```
C360-N> ping 149.49.48.1 3

PING 149.49.48.1: 56 data bytes
64 bytes from 149.49.48.1: icmp_seq=0. time=0. ms
64 bytes from 149.49.48.1: icmp_seq=1. time=0. ms
64 bytes from 149.49.48.1: icmp_seq=2. time=0. ms

----149.49.48.1 PING Statistics----
3 packets transmitted, 3 packets received, 0% packet loss
round-trip (ms)  min/avg/max = 0/0/0
```

prompt-length

User level: supervisor

Use the `prompt-length` command to specify the length of the default CLI prompt.

The syntax for this command is:

```
prompt-length <full|<prompt-size>>
```

full	Display the full length of the prompt
------	---------------------------------------

prompt-size	Set the length in characters of the prompt to display
-------------	---

Example:

```
C360-1(super)# prompt-length 4
~r)#
```

reset

User level: user, privileged, supervisor

Use the `reset` command to restart the stack or an individual switch. If no switch number is defined or the switch number of the Master is defined, the command resets the entire stack. If the switch number is defined, the command resets the specified switch only.

The syntax for this command is:

```
reset {module number}
```

Example:

To reset the Master agent and force the entire stack to reset:

```
C360-N# reset
This command will force a switch-over to the master module and
disconnect your telnet session.
Do you want to continue (y/n) [n]? y
Connection closed by foreign host.
```

To reset switch 4:

```
C360-N# reset 4
This command will reset module 4 and may disconnect your telnet
session.
Do you want to continue (y/n) [n]? y
Resetting module 4...
```

reset mgp

User level: privileged, supervisor.

Use the `reset mgp` command to perform a software reset in the G700 Media Gateway Processor.

The syntax for this command is:

```
reset mgp [module]
```

module	Number of the MGP in the stack
--------	--------------------------------

Example:

```
C360-N# reset mgp 1
```

reset module-and-powerinline

User level: privileged, supervisor.

Use the `reset mgp` command to perform a hardware reset of the switch and the PoE circuitry.

The syntax for this command is:

```
reset module-and-powerinline [module]
```

module	Number of the switch
--------	----------------------

Example:

```
C360-N# reset module-and-powerinline
This command will reset module 1 and its PoE circuitry and may
disconnect your telnet session.
*** Powerinline module reset*** - do you want to continue (Y/N)?
```

reset stack-and-powerinline

User level: privileged, supervisor.

Use the `reset stack` command to perform a hardware reset of the entire stack and the PoE circuitry.

The syntax for this command is:

```
reset stack-and-powerinline
```

Example:

```
C360-N# reset stack-and-powerinline
This command will force a reset to all modules and PoE circuitry
in the stack and will disconnect opened telnet sessions
*** Stack Reset *** - do you want to continue (Y/N)?
```

reset wan

User level: user, privileged, supervisor

Use the `reset wan` command to perform a software reset in the X330 WAN Access Router Module.

The syntax for this command is:

```
reset wan [module][bank-a]
```

module	Optional - the module number where the WAN module to be reset resides.
bank-a	Optional - boot the WAN module from bank-a after reset.

Example:

```
C360-N# reset wan 2
This command will force a switch-over to the wan device
and disconnect your telnet session
*** Reset *** - do you want to continue (Y/N)? y
```

retstatus

User level: supervisor

Use the `retstatus` to display the return status of the previously executed command.

The syntax for this command is:

```
retstatus
```

Example:

```
C360-N# retstatus
Succeeded
```

rmon alarm

User level: privileged, supervisor.

Use the `rmon alarm` command to create a new RMON alarm entry.

The syntax for this command is:

```
rmon alarm <Alarm Number> <variable> <interval> <sample type> rising-threshold
<rising threshold> <rising event> falling-threshold <falling threshold>
<falling event> <startup alarm> <owner>
```

Use the `no rmon alarm` command <Alarm Number> to delete an RMON alarm.

Alarm Number	This is the alarm index number of this entry (it is advisable to use the same interface number as your alarm index number.)
variable	The instance of an RMON statistic.
interval	The interval between 2 samples.
sample type	This can be set to either delta (the difference between 2 samples) or an absolute value.
rising threshold	This sets the upper threshold for the alarm entry.
rising event	The RMON event entry that will be notified if the upper threshold is passed.
falling threshold	This sets the lower threshold for the alarm entry.
falling event	The RMON event entry that will be notified if the lower threshold is passed.
startup alarm	The instances in which the alarm will be activated. The possible parameters are: Rising, Falling, risingOrfalling .
owner	Owner name string.

Example:

```
C360-N# rmon alarm 1026 1.3.6.1.2.1.16.1.1.1.5.1026 60 delta
rising-threshold 10000 1054 falling-threshold 10 1054
risingOrFalling gregory
alarm 1026 was created successfully
```

rmon event

User level: privileged, supervisor.

Use the `rmon event` command to create an RMON event entry.

The syntax for this command is:

```
rmon event <Event Number> <type> description <description> owner <owner>
```

Use the `no rmon event` command to delete an existing RMON event entry.

The syntax for this command is:

```
no rmon event [event number]
```

event number	This is the event index number of this entry.
type	The type of the event. The possible parameters are: <ul style="list-style-type: none"> • trap • log • logAndTrap • none
description	A user description of this event
owner	Owner name string

Example:

```
C360-N# rmon event 1054 logAndTrap description "event for
monitoring gregory's computer" owner gregory
event 1054 was created successfully
```

rmon history

User level: privileged, supervisor.

Use the `rmon history` command to create an RMON history entry.

The syntax for this command is:

```
rmon history <history index> [<module>[</port>]] interval <interval> buckets
<number of buckets> owner <owner name>
```

Use the `no rmon history` command to delete an existing RMON history entry.

The syntax for this command is:

```
no rmon history <history_index>
```

history_index	History index number of this entry (it is advisable to use the same interface number as your history index number).
module/port	The switch number/the port number.
interval	The interval between 2 samples.
number of buckets	The number of buckets defined.
owner name	The owner name string.

Example:

```
C360-N# rmon history 1026 1026 3/2 30 buckets 20 owner gregory
history 1026 was created successfully
```



Tip:

If you wish to define a name which includes spaces, you must enclose the entire name in quotation marks, for example “new york”.

session

User level: user, privileged, supervisor

Use the `session` command to open a session with a specific entity within a switch or the stack. For example, you can open a session with the Routing entity of a C360 switch in the stack.

NOTE:

Layer 2 commands are only available if you open a `switch` session with the Master switch.

NOTE:

When you use the `session` command the security level stays the same.

The syntax for this command is:

```
session {module_number} {switch|router|atm|mgp|wan}
```

module_number	(optional) The switch number. If you do not specify this parameter, you will get the list of modules within the stack.
switch router atm mgp wan	(optional) The entity to which you want to open a session. If you do not specify this parameter, you will get the default entity of the specific module: switch - Layer 2 entity of the switch (see Note below). router - Routing entity. atm - ATM entity. mgp - Media Gateway Processor. wan - WAN access router entity.

Use the `session` command without any parameters to identify the stack master and its slot number. It will list all the modules in the stack and their slot number with the master module marked with an asterisk.

Example:

```
C360-1# session 2
C360-2# session
C363T (*) In Slot 1
C364T-PWR      In Slot 2
C360-2#
```

set allowed managers

User level: privileged, supervisor.

Use the `set allowed managers` command to enable or disable the Allowed Managers feature.

When this feature is enabled, only those stations whose IP addresses are listed in the Allowed Managers table can access the device over Telnet, SNMP, or HTTP.

The syntax for this command is:

```
set allowed managers [enabled|disabled]
```

Example:

```
C360-1(super)# set allowed managers enabled
Managers are enabled
```

set allowed managers ip

User level: privileged, supervisor.

Use the `set allowed manager ip` command to add or remove an IP address from the Allowed Managers table. The Allowed Managers table can contain up to twenty IP addresses.

The syntax for this command is:

```
set allowed managers ip [add | delete][IP address]
```

add	Adds specified IP address to the Allowed Managers table
delete	Deletes specified IP address from the Allowed Managers table
IP address	IP address to be added or removed

Example:

```
C360-N# set allowed managers ip add 149.49.32.134
Ip was added to the table
```

set arp-aging-interval

User level: privileged, supervisor.

Use the `set arp-aging interval` command to set the ARP table aging interval for entries in the agent Layer 2 ARP table.

The entry is deleted at the end of every aging interval. The default value is 10 minutes.

The syntax for this command is:

```
set arp-aging-interval <value>
```

value	The number representing the interval, from 0 to 10 minutes. 0 - arp-aging interval is 20 minutes.
-------	--

Example:

```
C360-N# set arp-aging-interval 10
ARP table aging interval was set to 10 minutes.
```

set arp-tx-interval

User level: privileged, supervisor.

Use the `set arp-tx-interval` command to set the keep-alive frames sending interval. The keep-alive frames in ARP packets for the C360 agent are used to ensure connectivity with the C360 agent is always achieved.

The syntax for this command is:

```
set arp-tx-interval <value>
```

value	The interval in seconds. (0-3600) 0 disables the transmission of the keep-alive frames.
-------	--

Example:

```
C360-N# set arp-tx-interval 15
ARP tx interval was set to 15 seconds.
```

set autopartition

User level: privileged, supervisor.

NOTE:

This command is not relevant to C360 switches. It appears in the C360 CLI for controlling autopartition of P330 switches in the stack.

Use the `set autopartition` command to enable or disable auto-partitioning on P330 switches in the stack.

The syntax for this command is:

```
set autopartition <value>[module]
```

value	enable/disable
module	module slot number

Example:

```
C360-N# set autopartition enable 3
Auto-partition is enabled in module 3.
```

set boot bank

User level: privileged, supervisor.

Use the `set boot bank` command to configure the firmware bank from which the switch will boot at the next boot process. This command should be issued separately for each switch in the stack using the `session` command first.

NOTE:

If you wish to execute this command on a switch other than the stack master, you must open a session the relevant switch.

The syntax for this command is:

```
set boot bank <value>
```

value	{bank-a bank-b}
-------	-------------------

Example:

```
C360-N# set boot bank bank-a
Boot bank is set to bank-a
```

set cascading

User level: privileged, supervisor.

Use the `set cascading` command to control the generation of fault-traps for unconnected cascading links. This command is useful when cascading cables are not connected intentionally, and therefore no fault-traps are desired for this event.

The syntax for this command is:

```
set cascading {up|down} fault-monitoring {enable|disable} <mod-num>
```

module	Number of the C360 switch in the stack
--------	--

Example:

```
C360-N# set cascading down fault-monitoring enable 1
Module 1 cascading-down fault monitoring enabled
```

set device-mode

User level: privileged, supervisor.

Use the `set device-mode` command to select the module's operating mode — Layer 2 or Router .

NOTE:

This command is available on C360 switches with Layer 3 only.

The syntax for this command is:

```
set device-mode <mode>
```

mode	<ul style="list-style-type: none"> • Router – switch operates at Layers 2 and 3. • Layer2 – switch operates at Layer 2.
------	---

Example:

```
C360-N# set device-mode Router
This command will RESET the switch****
Reset **** do you want to continue (Y/N) ?

Done!
```

set dot1x max-req

User level: supervisor

Use the `set dot1x max-req` command to set maximum number of times the port tries to retransmit requests to the Authenticated Station before the session is terminated.

The syntax for this command is:

```
set dot1x max-req <count>
```

count	Number of attempts – 1 to 10
-------	------------------------------

Example:

```
C360-1(super)# set dot1x max-req 3
```

set dot1x quiet-period

User level: supervisor

Use the `set dot1x quiet-period` command to set the minimal time between authentication attempts.

The syntax for this command is:

```
set dot1x quiet-period <Seconds>
```

Seconds	Number of seconds – 1 to 65535
---------	--------------------------------

Example:

```
C360-1(super)# set dot1x quiet-period 90
Done!
```

set dot1x re-authperiod

User level: supervisor

Use the `set dot1x re-authperiod` command to set the idle time between re-authentication attempts.

The syntax for this command is:

```
set dot1x re-authperiod <Seconds>
```

Seconds	Number of seconds – 1 to 65535
---------	--------------------------------

Example:

```
C360-1(super)# set dot1x re-authperiod 90
Done!
```

set dot1x server-timeout

User level: supervisor

Use the `set dot1x server-timeout` command to set the server retransmission timeout period for all ports. This is the maximum time that the port will wait for a reply from the Authentication Server.

The syntax for this command is:

```
set dot1x server-timeout <Seconds>
```

Seconds	Number of seconds – 1 to 65535
---------	--------------------------------

Example:

```
C360-1(super)# set dot1x server-timeout 90
C360-1(super)#
```

set dot1x supp-timeout

User level: supervisor

Use the `set dot1x supp-timeout` command to set the maximum time that the switch will wait for a reply from the Authenticated Station before the session is terminated.

The syntax for this command is:

```
set dot1x supp-timeout <Seconds>
```

Seconds	Number of seconds – 1 to 65535
---------	--------------------------------

Example:

```
C360-1(super)# set dot1x supp-timeout 90
C360-1(super)#
```

set dot1x system-auth-control disable

User level: supervisor

Use the `set dot1x system-auth-control disable` command to globally disable the PBNAC (802.1x) feature.

The syntax for this command is:

```
set dot1x system-auth-control disable
```

Example:

```
C360-1(super)# set dot1x system-auth-control disable
dot1x system-auth-control disabled
```

set dot1x system-auth-control enable

User level: supervisor

Use the `set dot1x system-auth-control enable` command to globally enable the PBNAC (802.1x) feature.

The syntax for this command is:

```
set dot1x system-auth-control enable
```

Example:

- When a RADIUS server is defined:

```
C360-1(super)# set dot1x system-auth-control enable
dot1x system-auth-control enabled
```

- When a RADIUS server is not defined:

```
C360-1(super)# set dot1x system-auth-control enable
*** Warning : Authentication server ( RADIUS ) is disabled/not-
exist and so,
*** no authentication can be made
dot1x system-auth-control enabled
```

set dot1x tx-period

User level: supervisor

Use the `set dot1x tx-period` command to set the time interval between attempts to access the Authenticated Station.

The syntax for this command is:

```
set dot1x tx-period <Seconds>
```

Seconds	Number of seconds – 1 to 65535
---------	--------------------------------

Example:

```
C360-1(super)# set dot1x tx-period 90
Done!
```

set inband vlan

User level: privileged, supervisor.

Use the `set inband vlan` command to set the inband management VLAN.

The syntax for this command is:

```
set inband vlan <value>
```

value	Number of the VLAN to be assigned to the management interface.
-------	--

Example:

```
C360-N# set inband vlan 1
Management VLAN number set to 1
```

set intelligent-multicast

User level: privileged, supervisor.

Use the `set intelligent-multicast` command to enable or disable the IP-multicast filtering application.

The syntax for this command is:

```
set intelligent-multicast {enable|disable}
```

Example:

```
C360-N# set intelligent-multicast enable
Done!
```

set intelligent-multicast client-port-pruning time

User level: privileged, supervisor.

Use the `set intelligent-multicast client port pruning time` command to set the aging time for client ports. This is the time after the C360 switch reset during which the filtering information is learned by the switch but not configured on the ports.

The syntax for this command is:

```
set intelligent-multicast client-port-pruning time <seconds>
```

seconds	Client port pruning time in seconds
---------	-------------------------------------

Example:

```
C360-N# set intelligent-multicast client-port-pruning-time 40
Done!
```

set intelligent-multicast group-filtering-delay time

User level: privileged, supervisor.

Use the `set intelligent-multicast group-filtering delay time` command to set group filtering time delays. This is the time that the switch waits between becoming aware of a Multicast group on a certain VLAN and starting to filter traffic for this group.

The syntax for this command is:

```
set intelligent-multicast group-filtering-delay time <seconds>
```

seconds	Group filtering time in seconds.
---------	----------------------------------

Example:

```
C360-N# set intelligent-multicast group-filtering-delay time 40
Done!
```

set intelligent-multicast router-port-pruning time

User level: privileged, supervisor.

Use the `set intelligent-multicast router-port-pruning time` command to set the aging time for router ports. This is a timer that ages out Router port information if IGMP queries are not received within the configured time.

The syntax for this command is:

```
set intelligent-multicast router-port-pruning time <seconds>
```

seconds	Router port pruning time in seconds.
---------	--------------------------------------

Example:

```
C360-N# set intelligent-multicast router-port-pruning-time 40
Done!
```

set interface inband

User level: privileged, supervisor.

Use the `set interface inband` command to configure the Management inband interface on the Master agent in the stack.

The syntax for this command is:

```
set interface inband <vlan> <ip_addr> <netmask>
```

vlan	The number of the VLAN to be assigned to the interface
ip_addr	IP address of the inband interface
netmask	Subnet mask

Example:

To configure the inband interface on VLAN 1, IP address 1.1.1.1 and netmask 255.255.255.224:

```
C360-N# set interface inband 1 1.1.1.1 255.255.255.224

Interface inband IP address set.
You must reset the device in order for the change to take effect.
```

set interface ppp

User level: privileged, supervisor.

Use the `set interface ppp` command to configure the Master agent PPP interface IP parameters, exit modem mode, disconnect the PPP session, or reset the connected modem.

You must configure an IP address and net-mask for the C360 before you can establish a PPP connection. The IP address is a dummy address that is shared between two peers, and must be taken from a subnet that is different from the agent's inband IP subnet.

The syntax for this command is:

```
set interface ppp <ip_addr> <net-mask>
```

ip_addr	IP address used by the C360 Supervisor Module to connect via its PPP interface
net-mask	Subnet mask used by the C360 Supervisor Module to connect via its PPP interface

Example:

```
C360-N# set interface ppp 149.49.34.125 24
Interface ppp ip address set
```

set interface ppp enable/enable-always/disable/off/reset

User level: privileged, supervisor.

Use the `set interface ppp` command to enter modem mode, enter terminal mode, disconnect the PPP session or to reset the connected modem.

The syntax for this command is:

```
set interface ppp {enable|enable-always|disable|off|reset}
```

enable	Enable PPP and enter modem mode.
enable-always	Enter modem mode every time that the proprietary modem cable is plugged into the console port.
disable	Disable PPP and enter terminal mode
off	Disconnect the active PPP session.
reset	Reset the connected modem.

Example:

```
C360-N# set interface ppp reset
PPP has reset the connected modem.
```

Example:

```
C360-N# set interface ppp enable
Entering the Modem mode within 60 seconds...
Please check that the proprietary modem cable is plugged into the
console port
```

Example:

```
C360-N# set interface ppp disable
Entering the Terminal mode immediately
```

set intermodule port redundancy

User level: privileged, supervisor.

Use the `set intermodule port redundancy` command to define the stack's unique intermodule redundancy scheme. The defined scheme can be cleared using the `set intermodule port redundancy off` command.

NOTE:

You must disable Spanning Tree before you can enable intermodule port redundancy.

The syntax for this command is:

```
set intermodule port redundancy <module/prim-port> <module/second-port> {on
[<name>]}
```

module/prim-port	Primary port number
module/second-port	Secondary port number
on	Set the intermodule redundancy
name	Name of the fast redundancy (default is 'intermodule')

Example:

```
C360-N# set intermodule port redundancy 1/7 2/12 on backbone
backbone: port 2/12 is intermodule redundant to port 1/7
```

NOTE:

If you wish to define a name which includes spaces, you must enclose the entire name in quotation marks, e.g. "new york".

set intermodule port redundancy off

Use the `set intermodule port redundancy off` command to clear the intermodule port redundancy scheme.

The syntax for this command is:

```
set intermodule port redundancy off
```

Example:

```
C360-N# set intermodule port redundancy off
Intermodule port redundancy entry deleted.
```

set internal buffering

User level: privileged, supervisor.

NOTE:

This command is not relevant to C360 switches. It appears in the C360 CLI for controlling internal buffering of P330 switches in the stack.

The `set internal buffering` command allows you to set the size (Maximum, Medium, and Minimum) of the Receive (Rx) buffer allocated to each port of the specified switch. This command is meaningless when any port of the switch is operating with flow control ON.

The syntax for this command is:

```
set internal buffering <module> {value}
```

module	Number of P330 switch in the stack
value	max - sets the internal receive buffer to its maximum size med - sets the internal receive buffer capacity dynamically min - sets the internal receive buffer to its minimum size Default is min

Example:

```
C360-N# set internal buffering 1 max
Done.
```

set ip route

User level: privileged, supervisor.

Use the `set ip route` command to add a route to the IP routing table. You can configure from 1 to 10 default static gateways for a C360 switch.

The syntax for this command is:

```
set ip route <destination> <gateway>
```

destination	IP address of the network, or specific host to be added
gateway	IP address of the router

Example:

This example shows how to add a default route to the IP routing table:

```
C360-N# set ip route 0.0.0.0 192.168.1.1
destination = 0.0.0.0 gateway = 192.168.1.1
```

ROUTE NET TABLE						
destination	gateway	flags	Refcnt	Use	Interface	
0.0.0.0	192.168.1.1	1	1	3199	se0	
127.1.1.0	127.1.1.1	1	8	7606	se1	

ROUTE HOST TABLE						
destination	gateway	flags	Refcnt	Use	Interface	
127.0.0.1	127.0.0.1	5	2	131	lo0	
10.10.10.10	192.168.1.1	7	0	0	se0	

set leaky-vlan

User level: privileged, supervisor.

NOTE:

This command is not relevant to C360 switches. It appears in the C360 CLI for controlling internal buffering of P330 switches in the stack.

Use the `set leaky-vlan` command to define the P330 leaky VLAN mode. In this mode, VLAN test is done only on broadcast/multicast/unknown frames, and not on unicast frames.

The syntax for this command is

```
set leaky-vlan <enable|disable>
```

Example:

```
C360-N# set leaky-vlan enable
Leaky VLAN mode enabled

Note: The leaky vlan feature is activated only on boards
      (module,plug-in,cascade) that their CS is 2.x and above
```

set license

User level: privileged, supervisor.

Use the `set license` command to activate the SMON and Routing capabilities of the Avaya C360 stack. An Avaya C360 stack can include several Avaya C360 switches. One SMON license is required per Avaya C360 stack; a routing license is required for each C360 switch in the stack.

For a full description of the SMON or Routing License and the installation procedure please refer to the Installation Guide provided with the SMON/Routing License.

The syntax for this command is:

```
set license [module] [license] [feature name]
```

module	Switch number
license	License number
feature name	Name of the feature, either smon or routing

Example:

```
C360-N# set license 1 026a 9b8f 3216 9c08 adea 5f4d smon
The setting of a new smon license has been done!
Please reset the device in order for the feature to be updated!
```

set logging file condition

User level: privileged, supervisor.

Use the `set logging file condition` command to define a filter rule for logging messages to the logging file.

The syntax for this command is:

```
set logging file condition { all | <application> } { none | <severity> }
```

all	A keyword signifying that messages from all applications are displayed.
-----	---

application	<p>The application from which logging messages are logged to the logging file. Possible values are:</p> <ul style="list-style-type: none"> • Boot • System • ROUTER • CONFIG • TEMP • FILESYS • FAN • SUPPLY • SECURITY • CASCADE • QOS • SWITCHFABRIC • LAG • VLAN • OSPF • RIP • SNMP • POLICY • CLI • STP • ATM • WAN • THRESHOLD
none	<p>A keyword signifying that logging messages are not logged to the logging file regardless of the severity of the message.</p>
severity	<p>The minimum severity of the logging messages that are logged to the logging file. Possible values are:</p> <ul style="list-style-type: none"> • Emergency • Alert • Critical • Error • Warning • Notification • Informational • Debugging

Example:

```
C360-N# set logging file condition RIP Debugging
Done!
```

set logging file disable

User level: privileged, supervisor.

Use the `set logging file disable` command to disable logging messages to a logging file.

The syntax for this command is:

```
set logging file disable
```

Example:

```
C360-N# set logging file disable
Done!
```

set logging file enable

User level: privileged, supervisor.

Use the `set logging file enable` command to enable logging messages to a logging file.

The syntax for this command is:

```
set logging file enable
```

Example:

```
C360-N# set logging file enable
Done!
```

set logging server access level

User level: privileged, supervisor.

Use the `set logging server access-level` command to define the access level associated with Syslog server sink. The user cannot specify an access level higher than the level assigned to him.

The syntax for this command is:

```
set logging server access-level < admission-level > <ip-address>
```

admission-level	The access level associated with the Syslog server sink. Possible values are: <ul style="list-style-type: none"> • read-only • read-write • admin
ip-address	The IP address of the Syslog server.

Example:

```
C360-N# set logging server access-level read-only 149.49.38.22
Done!
```

set logging server condition

User level: privileged, supervisor.

Use the `set logging server condition` command to define a filter rule for logging messages to the Syslog server.

The syntax for this command is:

```
set logging server condition { all | <application> } { none | <severity> }
<ip-address>
```

all	A keyword signifying that the specified severity threshold applies to all applications.
application	The application to which the filter applies. Possible values are: <ul style="list-style-type: none"> •
none	A keyword signifying that logging messages are not logged to the Syslog server regardless of the severity of the message.

severity	The minimum severity of the logging messages that are logged to the Syslog server. Possible values are: <ul style="list-style-type: none"> • Emergency • Alert • Critical • Error • Warning • Notification • Informational • Debugging
ip-address	The IP address of the Syslog server.

Example:

```
C360-N# set logging server condition LAG Warning 135.64.102.224
Done!
```

set logging server disable

User level: privileged, supervisor.

Use the `set logging server disable` command to disable logging messages to a Syslog server.

The syntax for this command is:

```
set logging server disable <ip-address>
```

ip-address	The IP address of the Syslog server.
------------	--------------------------------------

Example:

```
C360-N# set logging server disable 149.49.35.21
Done!
```

set logging server enable

User level: privileged, supervisor.

Use the `set logging server enable` command to enable logging messages to a Syslog server.

The syntax for this command is:

```
set logging server enable <ip-address>
```

ip-address	The IP address of the Syslog server.
------------	--------------------------------------

Example:

```
C360-N# set logging server enable 149.49.35.21
Done!
```

set logging server facility

User level: privileged, supervisor.

Use the `set logging server facility` command to update the server facility used for sending messages to Syslog server. Facility settings are done on per Syslog server.

The syntax for this command is:

```
set logging server facility <server-facility> <ip-address>
```

server-facility	<p>The facility used for sending messages to the Syslog server. Possible values are:</p> <ul style="list-style-type: none"> • kern – Kernel • user – User processes • mail – Electronic mail • daemon – Background system processes • auth – Authorization • syslog – System logger • lpr – Printer • news – Usenet news • uucp – Unix-to-Unix copy program • clkd – Clock daemon • sec – Security • ftpd – FTP daemon • ntp – NTP subsystem • audi – Log audit • alert – Log alert • clkd2 – Clock daemon • local0-local7 – Available for user defined facilities
ip-address	The IP address of the Syslog server.

Example:

```
C360-N# set logging server facility news 135.64.102.224
Done!
```

set logging session condition

User level: privileged, supervisor.

Use the `set logging session condition` command to define a filter rule for logging messages during the current session.

The syntax for this command is:

```
set logging session condition { all | <application> } { none | <severity> }
```

all	A keyword signifying that the specified severity threshold applies to all applications.
application	The application to which the filter applies. Possible values are: <ul style="list-style-type: none"> • System • ROUTER • CONFIG • FILESYS • FAN • SUPPLY • SECURITY • CASCADE • QOS • SWITCHFABRIC • LAG • VLAN • SNMP • POLICY • CLI • STP • THRESHOLD
none	A keyword signifying that messages are not logged regardless of their severity.

severity	<p>The minimum severity of the logging messages that are logged.</p> <p>Possible values are:</p> <ul style="list-style-type: none"> • Emergency • Alert • Critical • Error • Warning • Notification • Informational • Debugging
----------	---

Example:

```
C360-N# set logging session condition LAG Error
Done!
```

set logging session disable

User level: privileged, supervisor.

Use the `set logging session disable` command to disable logging messages in the current CLI session.

The syntax for this command is:

```
set logging session disable
```

Example:

```
C360-N# set logging session disable
Done!
```

set logging session enable

User level: privileged, supervisor.

Use the `set logging session enable` command to enable logging messages in the current CLI session.

The syntax for this command is:

```
set logging session enable
```

Example:

```
C360-N# set logging session enable
Done!
```

set logout

User level: privileged, supervisor.

Use the `set logout` command to set the time in minutes before the system automatically disconnects an idle session.

The syntax for this command is:

```
set logout [timeout in minutes]
```

timeout in minutes	<p>Time until the system automatically disconnects an idle session.</p> <ul style="list-style-type: none"> Setting the value to 0 disables the automatic disconnection of idle sessions Default value is 15 minutes
--------------------	---

Example:

- To set the time until the system disconnects an idle session automatically to 20 minutes:

```
C360-N# set logout 20
Sessions will be automatically logged out after 20 minutes of idle time.
```

- To disable the automatic disconnection of idle sessions:

```
C360-N# set logout 0
Sessions will not be automatically logged out.
```

set mac-aging

User level: privileged, supervisor.

Use the `set mac-aging` command to enable or disable the MAC aging function.

The syntax for this command is:

```
Set mac-aging <status>
```

status	enable / disable
--------	------------------

Example:

```
C360-N# set mac-aging enable
mac aging is enabled.
```

```
C360-N# set mac-aging disable
mac aging is disabled.
```

set mac-aging-time

User level: privileged, supervisor.

Use the `set mac-aging-time` command to set the MAC aging time in minutes. This is the time after which unused MAC addresses in the MAC table are erased.

The syntax for this command is:

```
Set mac-aging-time <aging-time>
```

aging-time	Aging time in minutes (1-3600; default =5).
------------	---

Example:

```
C360-N# set mac-aging-time 5
mac aging time is set to 5 minutes.
```



Tip:

The entered value is the aging time lower limit. The actual aging time might be up to three minutes longer.

set port auto-negotiation-flowcontrol-advertisement

User level: privileged, supervisor.

Use the `set port auto-negotiation-flowcontrol-advertisement` command to set the flowcontrol advertisement for a Gigabit port when performing autonegotiation.

The syntax for this command is:

```
set port auto-negotiation-flowcontrol-advertisement <module>/<port> {no-
flowcontrol | asym-tx-only | sym-only | sym-and-asym-rx}
```

module	Number of the module.
--------	-----------------------

port	Number of the port on the module. If you do not specify a number, all the ports on the module are set. Alternatively, you can specify a range of ports separated by a dash, for example, 4/5-13 for ports 5 to 13 on module 4.
no-flowcontrol	The port will advertise no pause capabilities.
asym-tx-only	The port will advertise asymmetric Tx pause capabilities only.
sym-only	The port will advertise symmetric pause capabilities only.
sym-and-asym-rx	The port will advertise both symmetric and asymmetric Rx pause capabilities.

Example:

```
C360-N# set port auto-negotiation-flowcontrol-advertisement 1/5
asym-tx-only

Port 1/5 pause capabilities was set
```

set port channel

User level: privileged, supervisor.

Use the `set port channel` command to enable or disable a Link Aggregation Group (LAG) interface on the switch. LAG creation requires a LAG name to be specified. There is no default name.

You can also add or remove a port from an existing LAG. When adding or removing a port to an existing LAG, type the same LAG-name. All ports in the LAG are configured with the parameters of the first port that is added to the LAG. These parameters include port administrative status, speed, duplex, autonegotiation mode, VLAN ID, tagging mode, binding mode, and priority level.

The ports added to a LAG must belong to the same LAG group - refer to the “LAG” marking on device’s front panel.

NOTE:

When adding a port to an existing LAG, type the same LAG name, otherwise you will create a new LAG.

The syntax for this command is:

```
set port channel [<port_list>] [<value>] [<name>]
```

port_list	A list of ports to be aggregated in the format module/port
value	on or off – enables or disables the channel for the specified module ports
name	Channel name

**Tip:**

If you wish to define a name which includes spaces, you must enclose the entire name in quotation marks, for example “new york”.

Example:s

```
C360-N# set port channel 1/5-6,8 on my-channel
Port 1/5 channel mode set to on 1/102
Port 1/6 was added to channel 1/102
Port 1/8 was added to channel 1/102
```

set port classification

User level: privileged, supervisor.

Use the `set port classification` command to set the port classification to either regular or valuable. Any change in the Spanning Tree state from Forwarding for a valuable port will erase all learnt MAC addresses in the stack.

The syntax for this command is:

```
set port classification [module/port] {regular|valuable}
```

module port	module/port range
regular valuable	port classification

Example:

```
C360-N# set port classification 2/19 valuable
Port 2/19 classification has been changed.
```

set port disable

User level: privileged, supervisor.

Use the `set port disable` command to disable a port or range of ports.

The syntax for this command is:

```
set port disable <mod_num>/<port_num>
```

module	Number of the switch in the stack.
port	Number of the port on the module. If you do not specify a number, all the ports on the module are disabled. You can also specify a range of ports separated by a dash, for example, 4/5-13 for ports 5 to 13 on switch 4.

Example:

```
C360-N# set port disable 4/1

Port 4/1 disabled.
```

set port dot1x initialize

User level: supervisor

Use the `set port dot1x initialize` command to initialize port dot1x.

The syntax for this command is:

```
set port dot1x initialize <module/port>
```

module/port	Module and port number You can also specify a range of ports separated by a dash, for example, 4/5-13 for ports 5 to 13 on switch 4.
-------------	---

Example:

```
C360-1(super)# set port dot1x initialize 2/3

port 1/2 dot1x was initialized
```

set port dot1x max-req

User level: supervisor

Use the `set port dot1x max-req` command to set the maximal number of times the port tries to retransmit requests to the Authenticated Station before the session is terminated.

The syntax for this command is:

```
set port dot1x max-req <module/port> <count>
```

module/port	Module and port number (or range of ports)
count	Number of attempts — 1-10

Example:

```
C360-1(super)# set port dot1x max-req 1/2 5
```

set port dot1x port-control

User level: supervisor

Use the `set port dot1x port-control` command to set the dot1x parameter per port.

The syntax for this command is:

```
set port dot1x port-control <module/port> <mode>
```

module/port	Module and port number (or range of ports)
mode	force-unauthorize - the port is always is blocking state auto - forwarding/blocking depends on authorization outcome force-authorize - the port is always in forwarding state

Example:

```
C360-1(super)# set port dot1x port-control 2/3 force-authorize
port 1/2 control was set to force-authorize
```

set port dot1x quiet-period

User level: supervisor

Use the `set port dot1x quiet-period` command to set the 802.1x quiet period per port.

The syntax for this command is:

```
set port dot1x quiet-period <module/port> <seconds>
```

module/port	Module and port number (or range of ports)
seconds	Number of seconds – 1 to 65535

Example:

```
C360-1(super)# set port dot1x quiet-period 4/2 300
```

set port dot1x re-authenticate

User level: supervisor

Use the `set port dot1x re-authenticate` command to set the port to re-authenticate.

The syntax for this command is:

```
set port dot1x re-authenticate <module/port>
```

module/port	Module and port number (or range of ports)
-------------	--

Example:

```
C360-1(super)# set port dot1x re-authenticate 1/2
port 1/2 is not in authenticating process
```

set port dot1x re-authentication

User level: supervisor

Use the `set port dot1x re-authentication` command to set the re-authentication mode per port.

The syntax for this command is:

```
set port dot1x re-authentication <module/port> <mode>
```

module/port	Module and port number (or range of ports)
mode	enable disable

Example:

```
C360-1(super)# set port dot1x re-authentication 1/2 enable
port 1/2 re-authenticate was set to enable
```

set port dot1x re-authperiod

User level: supervisor

Use the `set port dot1x re-authperiod` command to set the the idle time between re-authentication attempts before the session is terminated.

The syntax for this command is:

```
set port dot1x re-authperiod <module/port> <seconds>
```

module/port	Module and port number (or range of ports)
seconds	Number of seconds – 1 to 65535

Example:

```
C360-1(super)# set port dot1x re-authperiod 1/2 400
```

set port dot1x server-timeout

User level: supervisor

Use the `set port dot1x server-timeout` command to set the time to wait for a reply from the Authentication Server before the session is terminated.

The syntax for this command is:

```
set port dot1x server-timeout <module/port> <seconds>
```

module/port	Module and port number (or range of ports)
seconds	Number of seconds – 1 to 65535

Example:

```
C360-1(super)# set port dot1x server timeout 1/2 400
```

set port dot1x supp-timeout

User level: supervisor

Use the `set port dot1x supp-timeout` command to set the time for the port to wait for a reply from the Authentication Server before the session is terminated.

The syntax for this command is:

```
set port dot1x supp-timeout<module/port> <seconds>
```

module/port	Module and port number (or range of ports)
seconds	Number of seconds – 1 to 65535

Example:

```
C360-1(super)# set port dot1x supp-timeout 1/2 400
```

set port dot1x tx-period

User level: supervisor

Use the `set port dot1x tx-period` command to set the time interval between attempts to access the Authenticated Station.

The syntax for this command is:

```
set port dot1x tx-period <module/port> <seconds>
```

module/port	Module and port number (or range of ports)
seconds	Number of seconds — 1 to 65535

Example:

```
C360-1(super)# set port dot1x quiet-period 1/2 5000
```

set port duplex

User level: privileged, supervisor.

Use the `set port duplex` command to configure the duplex type of an Ethernet or Fast Ethernet port or range of ports. You can configure Ethernet and Fast Ethernet interfaces to either full-duplex or half-duplex.

The duplex status of a port in auto-negotiation mode is determined by auto-negotiation. An error message is generated if you attempt to set the transmission type of auto negotiation Fast Ethernet ports to half- or full-duplex mode.

NOTE:

Ports 51, 52 (Gigabit SFP ports) work in Full duplex mode only. An error message is generated if you attempt to change these ports to half-duplex.

The syntax for this command is:

```
set port duplex <module>/<port> {full|half}
```

module	Number of the switch in the stack. If you do not specify a number, the ports on all the switches are shown.
port	Number of the port on the module. If you do not specify a number, all the ports on the module are shown. You can also specify a range of ports separated by a dash, for example, 4/5-13 for ports 5 to 13 on switch 4.
full	Set full-duplex transmission
half	Set half-duplex transmission

Example:

To set port 1 on module 4 to full duplex:

```
C360-N# set port duplex 4/1 full

Port 4/1 set to full-duplex.
```

set port edge admin state

User level: privileged, supervisor.

Use the `set port edge admin state` command to set the port as an RSTP edge-port or non-edge-port.

NOTE:

You must manually configure uplink and backbone ports (including LAG logical ports) to be “non-edge” ports, using the CLI command `set port edge admin state`.

The syntax for this command is:

```
set port edge admin state <module/port> <admin state>
```

module/port	Port identifier
admin state	The port's admin state can be set to either edge-port or non-edge-port.

Example:

```
C360-N# set port edge admin state 1/1 edge-port
port 1/1 edge admin state is set to edge-port
```

```
C360-N# set port edge admin state 1/1 non-edge-port
port 1/1 edge admin state is set to non-edge-port
```

set port enable

User level: privileged, supervisor.

Use the `set port enable` command to enable a port or a range of ports.

The syntax for this command is:

```
set port enable [mod_num/port_num]
```

module	Number of the switch.
port	Number of the port on the switch. You can also specify a range of ports separated by a dash, for example, 4/5-13 for ports 5 to 13 on switch 4.

Example:

```
C360-N# set port enable 4/1
Port 4/1 enabled.
```

set port flowcontrol

User level: privileged, supervisor.

Use the `set port flowcontrol` command to set the send/receive mode for flow-control frames (IEEE 802.3x or proprietary) for a full duplex port. Each direction (send or receive) can be configured separately.

The syntax for this command is:

```
set port flowcontrol {receive | send | all} <module/port> {off | on | proprietary}
```

receive	Indicates whether the port can receive administrative status from a remote device. Available only for Gigabit Ethernet modules with negotiation set to off.
send	Indicate whether the local port can send administrative status to a remote device. Available only for Gigabit Ethernet modules with negotiation set to off.
all	Send and receive (symmetric flow control).
module	Number of the module.
port	Number of the port on the module.
off	Used with receive to turn off an attached device's ability to send flow-control packets to a local port. Used with send to turn off the local port's ability to send administrative status to a remote device.
on	Used with receive to require that a local port receive administrative status from a remote device. Used with send, the local port sends administrative status to a remote device.

Example:

```
C360-N# set port flowcontrol receive 5/1 on

Port 5/1 flow control receive administration status set to on
```

set port level

User level: privileged, supervisor.

Use the `set port level` command to set the priority level of a port or range of ports on the switching bus. Packets traveling through a port set at normal priority should be served only after packets traveling through a port set at high priority are served.

The syntax for this command is:

```
set port level <module>/<port> [value]
```

module	Number of the switch.
--------	-----------------------

port	Number of the port on the module. You can also specify a range of ports separated by a dash, for example, 4/5-13 for ports 5 to 13 on switch 4.
value	Priority level (0 to 7)

Example:

```
C360-N# set port level 3/1 5

Port 3/1 level set to 5
```

set port mirror

User level: privileged, supervisor.

Use the `set port mirror` command to define a port mirroring pair in the stack.

NOTE:

Ensure that the VLAN binding parameters are identical on the source and destination ports.

The syntax for this command is:

```
set port mirror source-port <module/port> mirror-port <module/port> sampling
<activate> direction <direction>
```

module	Number of the switch.
port	Number of the port on the switch.
activate	always - keyword to activate the port mirroring entry
direction	rx - keyword to copy only incoming traffic both - keyword to copy both incoming and outgoing traffic

Example:

```
C360-N# set port mirror source-port 3/9 mirror-port 4/10
sampling always direction both

Mirroring both Rx and Tx packets from port 3/9 to port 4/10 is
enabled
```

set port name

User level: privileged, supervisor.

Use the `set port name` command to configure a name for a port. If you do not specify a name, the port name remains blank.

The syntax for this command is:

```
set port name <module>/<port> [<name>]
```

module	Number of the switch.
port	Number of the port on the switch.
name	Name (up to 16 characters)

Example:

```
C360-N# set port name 4/21 arthur

Port 4/21 name set.
```

NOTE:

If you wish to define a name which includes spaces, you must enclose the entire name in quotation marks, for example “new york”.

set port negotiation

User level: privileged, supervisor.

Use the `set port negotiation` command to enable or disable the link negotiation protocol on the specified port. This command is available on Fast Ethernet or Gigabit Ethernet ports.

- When negotiation is enabled, the speed and duplex of the Fast Ethernet ports are determined by auto-negotiation.
- If negotiation is disabled, you can set the speed and duplex of the Fast Ethernet ports.
- For Fiber Gigbit Ethernet ports it can determine the flow control (pause) mode only.

The syntax for this command is:

```
set port negotiation <module>/<port> {enable|disable}
```

module	Number of the switch. If you do not specify a number, the ports on all the switches are shown.
port	Number of the port on the module. You can also specify a range of ports separated by a dash, for example, 4/5-13 for ports 5 to 13 on module 4.
enable	Enable port negotiation protocol
disable	Disable port negotiation protocol

Example:

To disable autonegotiation on port 1, module 4:

```
C360-N# set port negotiation 4/1 disable
Link negotiation protocol disabled on port 4/1.
```

set port point-to-point admin status

User level: privileged, supervisor.

Use the `set port point-to-point admin status` command to set the port RSTP point-to-point admin status.

The syntax for this command is:

```
set port point-to-point admin status <module/port> <admin status>
```

module/port	Port identifier
admin status	force-true - treat this port as if it is connected point-to-point force-false - treat this port as if it is connected to shared media auto - try to automatically detect the connection type of the port

Example:

```
C360-N# set port point-to-point admin status 1/1 force-true
port 1/1 point to point admin status is set to force-true
```

set port powerinline

User level: privileged, supervisor.

Use the `set port powerinline` command to enable or disable the load detection process and power delivery for the port.

The syntax for this command is:

```
set port powerinline <module_number/port_number> {[enable] | disable}
```

module_number	Number of the module hosting the port for which load detection is to be enabled/disabled.
port_number	Number of the port for which load detection should be enabled/disabled.
	enable - enables load detection process for port disable - disables load detection process for port

Example:

```
C360-N# set port powerinline 3/1-3 enable
Load detection process on ports 3/1-3 is enabled
```

set port powerinline priority

User level: privileged, supervisor.

Use the `set port power inline priority` command to configure the priority level of powering the port. Possible values are Critical, High, and Low. At power on all ports are set to Low Priority.

Within each group, the lowest port number has a highest priority, i.e. within the ports 1 to 8, port 1 has the highest priority although its priority is lower than port 9 which belongs to High priority group.

The syntax for this command is:

```
set port powerinline priority <module_number/port_number> <priority>
```

module_number	Number of the module hosting the port for which a powerline priority level is to be set.
port_number	Number of the port for which a powerline priority level is to be set.
priority	Critical, High, or Low

Example:

```
C360-N# set port powerinline priority 2/3 HighLoad Powering
priority on port/s 2/3 was set to High
```

set port redundancy

User level: privileged, supervisor.

Use the `set port redundancy` command to globally enables or disable the port redundancy pairs you have defined. Using this command will not delete from NVRAM the existing redundancy entries.

The syntax for this command is:

```
set port redundancy {enable|disable}
```

Example:

```
C360-N# set port redundancy enable
All redundancy schemes are now enabled
```

set port redundancy on/off

User level: privileged, supervisor.

Use the set port redundancy command to defines or remove redundancy pairs. A port redundancy member can be any port (including LAG logical port) that is not a member of a LAG or another redundancy scheme.

The syntax for this command is:

```
set port redundancy <module>/<prim_port> <module>/<second_port> {on/off}
[<redundancy_name>]
```

prim_port	Primary port of the redundancy scheme
second_port	Secondary port of the redundancy scheme
redundancy_name (Optional)	Name for the redundancy scheme

Example:

```
C360-N# set port redundancy 1/7 2/12 on red1
uplink: Port 2/12 is redundant to port 1/7.

Port redundancy is active - entry is effective immediately
```

NOTE:

If you wish to define a name which includes spaces, you must enclose the entire name in quotation marks, for example “new york”.

set port redundancy-intervals

User level: privileged, supervisor.

Use the set port redundancy-intervals command to configurs the two time constants that determine redundancy switchover parameters:

- “Min Time-between-switchovers” is the minimum interval between switchover of each pair.
- “Switchback-interval” is the period the primary port link has to be “up” before the system switches back.
If the switchback interval is zero, the system never switches back. If it is one, switchback occurs immediately after the primary port link returns.

The syntax for this command is:

```
set port redundancy-intervals <min-time-between-switchovers> <switchback-
interval> | none
```

min-time-between-switchovers	The minimum time between redundancy switchovers for each pair (in milliseconds).
switchback-interval	The period the primary port link has to be “up” before the system switches back (in milliseconds). <ul style="list-style-type: none"> If switchback interval is zero, the switchback is immediate
none	The system switches back only if the secondary link fails.

Example:

```
C360-N# set port redundancy-intervals 100 20
Done!
```

set port security

User level: privileged, supervisor

NOTE:

This command is not relevant to C360 switches. It appears in the C360 CLI for controlling port security of P330 switches in the stack.

Use the `set port security` command to enable MAC security on a port or a range of ports at the module level. The port security is activated only after you enable the security mode at the stack level using the `set security mode` command.

The syntax for this command is:

```
set port security { enable | disable } [<module>[/<port>]]
```

enable	Enable port mac security
disable	Disable port mac security
module/port	Module number/port number.

Example:

```
C360-N# set port security enable 1/2
Done!
```

set port spantree cost

User level: privileged, supervisor.

Use the `set port spantree cost` command to set the cost of a port. This value defines which port will be allowed to forward traffic if two ports with different costs cause a loop.

The syntax for this command is:

```
set port spantree cost [module/port] [auto|value]
```

module/port	Module number/port number.
auto	Spantree cost is calculated according to the standard
value	Number representing the cost. The cost level can be set from 1 to 65535 / 200000000 in STP / RSTP, respectively. A lower cost (lower value) specifies precedence of a port to forward traffic.

Example:

```
C360-#> set port spantree cost 4/2 4096
port 4/2 spantree cost is 4096
```

set port spantree disable

User level: privileged, supervisor.

Use the `set port spantree disable` command to disable the spanning tree mode for specific switch ports.

The syntax for this command is:

```
set port spantree disable [module/port]
```

Module	Module number
Port	Port number

Example:

```
C360-N# set port spantree disable 3/1
port 3/1 was disabled on spantree
```

set port spantree enable

User level: privileged, supervisor.

Use the `set port spantree enable` command to enable the spanning tree mode for specific switch ports.

The syntax for this command is:

```
set port spantree enable [module/port]
```

Module	Module number
Port	Port number

Example:

```
C360-N# set port spantree enable 3/1
port 3/1 was enabled on spantree
```

set port spantree force-protocol-migration

User level: privileged, supervisor.

Use the `set port spantree force-protocol-migration` command to set the port as an RSTP port (and not as common STA port). It forces the port to send a rapid spanning tree BPDU.

The syntax for this command is:

```
set port spantree force-protocol-migration <module/port>
```

module/port	Port identifier
-------------	-----------------

Example:

```
C360-# set port spantree force-protocol-migration 1/1
port 1/1 is forced to send a Rapid spanning tree BPDU
```

set port spantree priority

User level: privileged, supervisor.

Use the `set port spantree` command to set the Spanning Tree priority level of a port. This value defines the priority of a port to be blocked in case two ports with the same costs cause a loop.

The syntax for this command is:

```
set port spantree priority [module/port] [value]
```

module/port	Module number/port number.
value	Number representing the priority of the bridge. The priority level is from 0 to 240, with 0 indicating high priority and 240 indicating low priority. Value should be in steps of 16; default value is 128.

Example:

```
C360-N# set port spantree priority 3/4 128
port 3/4 spantree priority is 128
```



Tip:

Priority value 0 will set the port to Root port.

set port speed

User level: privileged, supervisor.

Use the `set port speed` command to configure the speed of a port or range of 10/100BASE-T ports.

In auto-negotiation mode, the port's speed is determined by auto negotiation. An error message is generated if you attempt to set the speed when auto negotiation is enabled

NOTE:

This command cannot be executed for C360 ports 51, 52 (Gigabit SFP ports). An error message is generated if you attempt to perform the `set port speed` command for these ports that can only work at 1000 Mbps speed.

The syntax for this command is:

```
set port speed <mod_num>/<port_num> <10MB|100MB|1GB>
```

mod_num	Number of the switch.
port_num	Number of the port on the switch. You can also specify a range of ports separated by a dash, for example, 4/5-13 for ports 5 to 13 on module 4.

Example:

To configure port 1 on module 4 to 100 Mbps

```
C360-N# set port speed 4/1 100MB
Port 4/1 speed set to 100 Mbps.
```

set port static-vlan

User level: privileged, supervisor.

Use the `set port static-vlan` command to assign static VLANs to ports.

The syntax for this command is:

```
set port static-vlan [module/port range] [vlan num]
```

module/port range	Port range
vlan num	vlan to bind to port

Example:

```
C360-N# set port static-vlan 3/4-6 2
VLAN 2 is bound to port 3/4
VLAN 2 is bound to port 3/5
VLAN 2 is bound to port 3/6
```

set port trap

User level: privileged, supervisor.

Use the `set port trap` command to enable or disable generic SNMP uplink or downlink traps from a port.

The syntax for this command is:

```
set port trap <module>/<port> {enable|disable}
```

module	Number of the switch.
port	Number of the port on the switch. You can also specify a range of ports separated by a dash, for example, 4/5-13 for ports 5 to 13 on switch 4.
enable	Enable uplink/downlink traps
disable	Disable uplink/downlink traps

Example:

```
C360-N# set port trap 3/2 enable

Port 3/2 up/down trap enabled.
```

set port vlan

User level: privileged, supervisor.

Use the `set port vlan` command to set the port VLAN ID (PVID). If adding a new VLAN, the VLAN number must be within the range 1 to 3071.

The syntax for this command is:

```
set port vlan <vlan_num> <module>/<port>
```

vlan_num	Number identifying the VLAN.
module	The switch number
port	Number of the port on the switch. You can also specify a range of ports separated by a dash, for example, 4/5-13 for ports 5 to 13 on module 4.

Example:

To set VLAN 850 to include ports 4 through 7 on module 3.

```
C360-N# set port vlan 850 3/4-7

VLAN 850 modified.
VLAN  Mod/Ports
-----
850    3/4-7
```

set port vlan-binding-mode

User level: privileged, supervisor.

Use the `set port vlan-binding-mode` command to define the binding method used by ports.

The syntax for this command is:

```
set port vlan-binding-mode [port_list] [value]
```

port list	Switches and ports to bundle (format: module/port)
value	<ul style="list-style-type: none"> static - the port supports only the VLAN as configured per port bind-to-configured - the port supports the VLANs configured on the device bind-to-all - the port support the whole range of VLANs on the device

Example:

```
C360-N# set port vlan-binding-mode 5/5-9 static
Set Port vlan binding method:5/5
Set Port vlan binding method:5/6
Set Port vlan binding method:5/7
Set Port vlan binding method:5/8
Set Port vlan binding method:5/9
```

set ppp authentication incoming

User level: privileged, supervisor.

Use the `set ppp authentication` command to define the authentication method used for a PPP server or client session.

The syntax for this command is:

```
set ppp authentication incoming {pap|chap|none}
```

pap	PAP authentication method
chap	CHAP authentication method
none	No authentication

Example:

```
C360-N# set ppp authentication incoming chap
PPP requires CHAP authentication for incoming sessions.
```

set ppp baud-rate

User level: privileged, supervisor.

Defines the baud rate used in PPP sessions.

NOTE:

The peer baud rate on the switch must be the same value as the host.

The syntax for this command is:

```
set ppp baud-rate <9600|19200|38400>
```

Example:

```
C360-N# set ppp baud-rate 38400
ppp baud rate was set to 38400
```

set ppp chap-secret

User level: supervisor

Use the `set ppp chap-secret` command to configure the “shared secret” used in PPP sessions with CHAP authentication. The chap-secret is not transferable via the configuration upload/download mechanism.

The syntax for this command is:

```
set ppp chap-secret <chap-secret>
```

chap-secret	The shared secret, 4 to 32 characters.
-------------	--

Example:

```
C360-1(super)# set ppp chap secret hush
PPP shared secret for CHAP authentication is set
```

set ppp incoming timeout

User level: privileged, supervisor

Use the `set ppp incoming timeout` command to set the number of minutes until the system automatically disconnects an idle PPP incoming session.

The syntax for this command is:

```
set ppp incoming timeout <time>
```

time	The timeout in minutes
------	------------------------

Example:

```
C360-N# set ppp incoming timeout 15
PPP incoming session will automatically disconnect after 15 minutes of idle time
```

set psu type

User level: privileged, supervisor.

Use the `set psu type` command to set the main power supply type (AC/DC) of the module.

NOTE:

This command is not applicable to C360 switches, which determine the PSU type automatically. This command is used to set the power supply types for P330 switches in the stack.

The syntax for this command is:

```
set psu type [AC|DC][module number]
```

Example:

```
C360-N# set psu type DC 3
Power supply type was changed to DC on module 3
```

set queuing scheme

User level: privileged, supervisor.

NOTE:

This command is applicable to C360 switches with Routing only.

Use the `set queuing scheme` command to set the queuing scheme to either strict or weighted round robin and to set the weights.

The syntax for this command is:

```
set queuing scheme {wrr {H} | strict | default} [module]
```

wrr/strict/default	Sets queuing scheme to weighted round robin, strict, or the default.
H	Ratio between high and low priority queues. This parameter is only used when the queuing scheme is weighted round robin.
module	The module number to which the queuing scheme applies. If no module is specified, the command affects all C360 modules in the stack.

Example:

```
C360-N# set queuing scheme wrr 10 2

Module Queuing Scheme
-----

    2   Wrr 10:1

C360-N# set queuing scheme default
Module Queuing Scheme
-----

    1   Default
    2   Default
```

set radius authentication enable/disable

User level: privileged, supervisor.

Use the `set radius authentication` command to enable or disable RADIUS authentication for the C360 switch.

The syntax for this command is:

```
set radius authentication {enable|disable}
```

enable	Enable RADIUS authentication
disable	Disable RADIUS authentication (default)

Example:

```
C360-1(super)# set radius authentication enable
Done!
```

set radius authentication retry-number

User level: privileged, supervisor.

Use the `set radius authentication retry-number` command to set the number of times an access request is sent when there is no response.

The syntax for this command is:

```
set radius authentication retry-number <number>
```

number	Number of retries
--------	-------------------

Example:

```
C360-1(super)# set radius authentication retry-number 3
```

set radius authentication retry-time

User level: privileged, supervisor.

Use the `set radius authentication retry-time` command to set the time to wait before re-sending an access request.

The syntax for this command is:

```
set radius authentication retry-time <time>
```

time	Retry time in seconds
------	-----------------------

Example:

```
C360-1(super)# set radius authentication retry-time 5
```

set radius authentication secret

User level: supervisor

Use the `set radius authentication secret` command to enable secret authentication for the C360 unit.

The syntax for this command is:

```
set radius authentication secret <string>
```

string	text password
--------	---------------

Example:

```
C360-1(super)# set radius authentication secret hush
Done!
```

set radius authentication server

User level: privileged, supervisor.

Sets the IP address (and shared secret) of the primary or secondary RADIUS Authentication server.

The syntax for this command is:

```
set radius authentication server <ip-addr> {primary | secondary}
```

ip-addr	IP address of the RADIUS authentication server
primary	default - Primary authentication server
secondary	Secondary authentication server

Example:

```
C360-1(super)# set radius authentication server 192.40.12.36
primary
Done!
```

set radius authentication udp-port

User level: privileged, supervisor.

Use the `set radius authentication udp-port` command to set the RFC 2138 approved UDP port number.

Normally, the UDP port number should be set to its default value of 1812. Some early implementations of the RADIUS server used port number 1645.

The syntax for this command is:

```
set radius authentication udp-port <number>
```

Example:

```
C360-1(super)# set radius authentication udp-port 300
Done!
```

set security mode

User level: privileged, supervisor.

NOTE:

This command is not relevant to C360 switches. It appears in the C360 CLI for controlling internal buffering of P330 switches in the stack.

Use the `set security mode` command to enable or disable MAC security at the stack level. When enabled, the ports are secured based on their individual configuration. When disabled, all the ports in a stack are non-secured.

```
set security mode {enable|disable}
```

Example

```
C360-1(super)# set security mode enable
Security mode enabled.
```

set snmp community

User level: privileged, supervisor.

Use the `set snmp community` command to set or modify the switch's SNMP community strings.

The syntax for this command is:

```
set snmp community <read-only | read-write | trap> [community string]
```

Example:

```
C360-N# set snmp community read-only read
SNMP read-only community string set
```

set snmp retries

User level: privileged, supervisor.

Use the `set snmp retries` command to set the number of retries initiated by the C360 Manager when it tries to send SNMP messages to the switch.

The syntax for this command is:

```
set snmp retries <number>
```

number	Number of retries
--------	-------------------

Example:

```
C360-N# set snmp retries 10
Done!
```

set snmp timeout

User level: privileged, supervisor.

Use the `set snmp timeout` command to set the SNMP timeout in seconds. This command is only used for access using the C360 Embedded Web Manager.

The syntax for this command is:

```
set snmp timeout <number>
```

number	Timeout in seconds
--------	--------------------

Example:

```
C360-N# set snmp timeout 2000
Done!
```

set snmp trap

User level: privileged, supervisor.

Use the `set snmp trap` command to add an entry into the SNMP trap receiver table and to enable or disable the different SNMP traps for a specific receiver.

First add the `rcvr_addr` and then enable/disable the different traps for it.

The syntax for this command is:

```
set snmp trap <rcvr_addr>
```

```
set snmp trap <rcvr_addr> {enable|disable} {all|config|fault|...}
```

enable	Activate SNMP traps
disable	Deactivate SNMP traps
all	(Optional) Specify all trap types
config	(Optional) Specify the ConfigChange trap from the TRAP-MIB.
fault	(Optional) Specify the Fault trap from the TRAP-MIB.
rcvr_addr	IP address or IP alias of the system to receive SNMP traps

Example:

To enable SNMP ConfigChange traps to a specific manager:

```
C360-N# set snmp trap 192.168.173.42 enable config
SNMP config change traps enabled.
```

Example:

To enable all traps to a specific manager:

```
C360-N# set snmp trap 192.168.173.42 enable all
SNMP all traps enabled.
```

Example:

To disable SNMP config traps to a specific manager:

```
C360-N# set snmp trap 192.168.173.42 disable config
SNMP config traps disabled.
```

Example:

To add an entry in the SNMP trap receiver table with default:

```
C360-N# set snmp trap 192.168.173.42
SNMP trap receiver added.
```

set snmp trap auth

User level: privileged, supervisor.

Use the `set snmp trap auth` command to enable or disable the sending of SNMP traps upon SNMP authentication failure.

The syntax for this command is:

```
set snmp trap {enable|disable} auth
```

Example:

```
C360-N# set snmp trap enable auth
Authentication trap enabled
```

set spantree default-path-cost

User level: privileged, supervisor.

Use the `set spantree default-path-cost` command to set the version of the spanning tree default path costs that are to be used by this bridge.

The syntax for this command is:

```
set spantree default-path-cost <path-cost>
```

path-cost	common-spanning-tree - compatible with ieee802.1D standard rapid-spanning-tree - compatible with ieee802.1W standard
-----------	---

Example:

```
C360-N# set spantree default-path-cost rapid-spanning-tree
Spanning tree default path costs is set to rapid spanning tree.
```

set spantree disable

User level: privileged, supervisor.

Use the `set spantree disable` command to disable the spanning-tree algorithm for the switch.

NOTE:

When you disable STP, blocking ports are disabled in order to prevent loops in the network. As a result, you need to wait 30 seconds before disabling STP if you reset the switch, enable STP, or insert a new station.

The syntax for this command is:

```
set spantree disable
```

Example:

```
C360-N# set spantree disable
Succeed to set spantree to disable!
```

set spantree enable

User level: privileged, supervisor.

Use the `set spantree enable` command to enable the spanning-tree algorithm for the switch.

NOTE:

When you disable STP, blocking ports are disabled in order to prevent loops in the network. As a result, you need to wait 30 seconds before disabling STP if you reset the switch, enable STP, or insert a new station.

The syntax for this command is:

```
set spantree enable
```

Example:

```
C360-N# set spantree enable
Succeed to set spantree to disable!
```

set spantree forward-delay

User level: privileged, supervisor.

Use the `set spantree forward-delay` command to set the bridge forward delay time parameter.

The syntax for this command is:

```
set spantree forward-delay <time>
```

forward - delay	The time that is used when transferring the port to forwarding state. Value range is 4-30 and must exceed (Bridge Max Age/2). Recommended value is 15 seconds.
-----------------	--

Example:

```
C360-N# set spantree forward-delay 15

bridge forward delay is set to 15.
```

set spantree hello-time

User level: privileged, supervisor.

Use the `set spantree hello-time` command to set the bridge hello time parameter.

The syntax for this command is:

```
set spantree hello-time <time>
```

hello-time	The time interval (in seconds) between the generation of configuration BPDUs by the Root. Value ranges between 1 to 10 and must not exceed (Bridge-Max-Age/2) - 1. The recommended value is 2 sec.
------------	---

Example:

```
C360-N# set spantree hello-time 2

bridge hello time set to 2.
```

set spantree max-age

User level: privileged, supervisor.

Use the `set spantree max-age` command to set the bridge spanning tree max age parameter.

The syntax for this command is:

```
set spantree max-age <seconds>
```

max-age	The max age time in seconds to keep message information before it is discarded. Value ranges between 6 to 40; value must be between 2 X (Bridge-Hello-Time + 1) and 2 X (Bridge-Forward-Delay - 1). The recommended value is 20 sec.
---------	---

Example:

```
C360-N# set spantree max-age 20
bridge max age is set to 20.
```

set spantree priority

User level: privileged, supervisor.

The syntax for this command is:

```
set spantree priority <number>
```

number	The priority level is from 0 to 61440, with 0 indicating high priority and 61440 indicating low priority; value should be in steps of 4096. Default value is 32768.
--------	---

Example:

```
C360-N# set spantree priority 4096
Bridge priority set to 4096.
```

set spantree tx-hold-count

User level: privileged, supervisor.

Use the `set spantree tx-hold-count` command to limit the maximum number of BPDUs transmitted during a hello-time period.

The syntax for this command is:

```
set spantree tx-hold-count <rate>
```

rate	Value between 1 to 10; recommended value is 3
------	---

Example:

```
C360-N# set spantree tx-hold-count 3
tx hold count is set to 3.
```

set spantree version

User level: privileged, supervisor.

Use the `set spantree version` command to set the rapid spanning tree state machine to work as "STP compatible".

The syntax for this command is:

```
set spantree version <version>
```

version	common-spanning-tree — compatible with ieee802.1D standard. rapid-spanning-tree — compatible with ieee802.1W standard
---------	--

Example:

```
C360-N# set spantree version rapid-spanning-tree
Spanning tree version is set to rapid spanning tree.
```

set system contact

User level: privileged, supervisor.

Use the `set system contact` command to set the mib2 system contact MIB variable.

The syntax for this command is:

```
set system contact [string]
```

string	<ul style="list-style-type: none"> • The contact name string should be typed inside inverted commas. • The name is cleared if you leave this field blank.
--------	---

Example:

```
C360-N# set system contact "gregory kohll"
*** Set System Contact ***

System contact set
```

NOTE:

If you wish to enter a name which includes spaces, you must enclose the entire name in quotation marks, for example "new york".

set system location

User level: privileged, supervisor.

Use the `set system location` command to set the mib2 system location MIB variable

The syntax for this command is:

```
set system location [string]
```

string	<ul style="list-style-type: none"> • The location name string should be typed inside inverted commas. • The location is cleared if you leave this field blank.
--------	--

Example:

```
C360-N# set system location documentation
*** Set System Location ***

System location set
```

NOTE:

If you wish to enter a name which includes spaces, you must enclose the entire name in quotation marks, for example “new york”.

set system name

User level: privileged, supervisor.

Use the `set system name` command to set the mib2 system name MIB variable.

The syntax for this command is:

```
set system name [string]
```

string	<ul style="list-style-type: none"> • The system name string should be typed inside inverted commas. • The name is cleared if you leave this field blank.
--------	--

Example:

```
C360-N# set system name "C360-1"
*** Set System Name ***

System name set
```

NOTE:

If you wish to enter a name which includes spaces, you must enclose the entire name in quotation marks, for example “new york”.

set terminal recovery password disable

User level: supervisor

Use the `set terminal recovery password disable` command to disable the recovery password feature.

**Tip:**

This command can only be run from the console port on the device.

**Tip:**

If the recovery password feature is disabled and you forget your login and password, you will not be able to access the device.

The syntax for this command is:

```
set terminal recovery password disable
```

Example:

```
C360-N# set terminal recovery password disable
Done!
```

set terminal recovery password

User level: supervisor

Use the `set terminal recovery password enable` command to enable the recovery password feature.



Tip:

This command can only be run from the console port on the device.

The syntax for this command is:

```
set terminal recovery password enable
```

Example:

```
C360-N# set terminal recovery password enable
Done!
```

set time client

User level: privileged, supervisor.

Use the `set time client` command to enable or disable the periodic network time acquisition by the switch from the network time server (SNTP or TIME protocol).

The syntax for this command is:

```
set time client {enable|disable}
```

enable	Enable periodic network time acquisition
disable	Disable periodic network time acquisition

Example:

```
C360-N# set time client enable
Time client mode enabled
```

set time protocol

User level: privileged, supervisor.

Use the `set time protocol` command to set the protocol for use in the system as either SNTP protocol or TIME protocol.

The syntax for this command is:

```
set time protocol [sntp-protocol|time-protocol]
```

sntp-protocol	Use the SNTP protocol
time-protocol	Use the TIME protocol

Example:

```
C360-N# set time protocol sntp-protocol
The protocol has been set to SNTP protocol

C360-N# set time protocol time-protocol
The protocol has been set to TIME protocol
```

set time server

User level: privileged, supervisor.

Use the `set time server` command to set the TIME server address.

The syntax for this command is:

```
set time server <ip address>
```

ip address	IP address of the TIME server.
------------	--------------------------------

Example:

```
C360-N# set time server 192.49.53.68
The Server Ip has been set to 192.49.53.68
```

set timezone

User level: privileged, supervisor.

Use the `set timezone` command to assign a timezone name and sets the time difference of the device relative to the Coordinated Universal Time (UTC / GMT).

The minutes parameter can only be set to 30.

The syntax for this command is:

```
set timezone <zone-name> [-]<hours>[:30]
```

zone-name	Three-character name of time zone, for example, EST, GMT
hours	The difference between the time zone and GMT

Example:

```
C360-N# set timezone EST -5
Timezone set to "EST", offset from UTC is -5 hours.
```

set trunk

User level: privileged, supervisor.

Use the `set trunk` command to configure the VLAN tagging mode of a port.

```
set trunk <module/port> {off|dot1q}
```

module	Number of the switch.
port	Number of the port on the switch. You can also specify a range of ports separated by a dash, for example, 4/5-13 for ports 5 to 13 on switch 4.
off	Forces the port to become a non-tagging port.
dot1q	Specifies an IEEE 802.1Q tagging on a Fast Ethernet or Gigabit Ethernet port.

Example:

```
C360-1# set trunk 3/3 dot1q
Dot1Q VLAN tagging set on port 3/3.
```

set utilization cpu

User level: privileged, supervisor.

Use the `set utilization cpu` command to enable CPU utilization monitoring on the specified module.

The syntax for this command is:

```
set utilization cpu <module-number>
```

module-number	The module number for which CPU utilization monitoring is enabled.
---------------	--

Example:

```
C360-N# set utilization cpu 1
CPU utilization is set on module 1
Done!
```

set vlan

User level: privileged, supervisor.

Use the `set vlan` command to configure VLANs.

The syntax for this command is:

```
set vlan <vlan-id> [name <vlan-name>]
```

vlan-id	vlan number
vlan-name	vlan name

Example:

```
C360-N# set vlan 3 name gregory
VLAN id 3, vlan-name gregory created.
```

NOTE:

If you wish to define a name which includes spaces, you must enclose the entire name in quotation marks, for example “new york”.

set web aux-files-url

User level: privileged, supervisor.

Use the `set web aux-files-url` command to allow the Device Manager to automatically locate the URL of the Web server containing the Device Manager help files and Java plug-in.

NOTE:

Ensure that the Web server is always accessible to prevent potential delays to Web access to the device.

The syntax for this command is:

```
set web aux-files-url <>//IP address/directory name>
```

Example:

```
C360-N# set web aux-files-url //192.168.47.25/emweb-aux-files
```

NOTE:

If you wish to define a directory name which includes spaces, you must enclose the entire name in quotation marks, for example "new york".

set welcome message

User level: privileged, supervisor.

Use the `set welcome message` command to set a welcome message to appear after a reboot or after opening a new session (see `session` command) in the stack.

The syntax for this command is:

```
set welcome message [string]
```

string	string - The string to be used as the welcome message. blank - Restores the default string.
--------	--

Example:

```
C360-N# set welcome message avaya
The new welcome string is "avaya"
```

NOTE:

If you wish to define a string which includes spaces, you must enclose the entire string in quotation marks, e.g. "new york".

show allowed managers status

User level: user, privileged, supervisor

Use the `show allowed managers status` command to display the activation status of the Allowed Managers feature.

The syntax for this command is:

```
show allowed managers status
```

Example:

```
C360-N# show allowed managers status

Managers are disabled.
```

show allowed managers table

User level: user, privileged, supervisor

Use the `show allowed managers table` command to display the list of the twenty possible allowed managers IP addresses.

The syntax for this command is:

```
show allowed managers table
```

Example:

```
C360-N# show allowed managers table

 1 ) 149.49.32.134
 2 ) Not Used
 3 ) Not Used
 4 ) Not Used
 5 ) Not Used
 6 ) Not Used
 7 ) Not Used
 8 ) Not Used
 9 ) Not Used
10 ) Not Used
11 ) Not Used
12 ) Not Used
13 ) Not Used
14 ) Not Used
15 ) Not Used
16 ) Not Used
17 ) Not Used
18 ) Not Used
19 ) Not Used
20 ) Not Used
```

show arp-aging-interval

User level: privileged, supervisor.

Use the `show arp-aging-interval` command to display the ARP table aging interval for table entries.

The syntax for this command is:

```
show arp-aging-interval
```

Example:

```
C360-N> show arp-aging-interval
ARP table aging interval is set to 10 minutes.
```

show arp-tx-interval

User level: privileged, supervisor.

Use the `show arp-tx-interval` command to display the keep-alive frames transmission interval.

The syntax for this command is:

```
show arp-tx-interval
```

Example:

```
C360-N> show arp-tx-interval
ARP tx interval is set to 5 seconds.
```

show autopartition

User level: privileged, supervisor.

Use the `show autopartition` command to display the automatic partition.

NOTE:

Autopartition for the C360 switches will always have the value `disabled`. This command is used to display the autopartition status for the P330 switches in the stack.

The syntax for this command is:

```
show autopartition [module]
```

Example:

```
C360-N> show autopartition 1

Mod      Mode
-----
1        Enable
```

show boot bank

User level: privileged, supervisor.

Use the `show boot bank` command to display the firmware bank from which the switch will boot at the next boot process.

You must issue this command separately for each switch in the stack using the `session` command.

NOTE:

If you wish to run this command on a switch other than the stack master, you need to open a session to the relevant switch.

The syntax for this command is:

```
show boot bank
```

Example:

```
C360-N> show boot bank
Boot bank set to bank-a
```

show cam

User level: user, privileged, supervisor

Use the `show cam` command to either display the module and port number where a specific MAC address was learned, or the MAC addresses learned on a specific module and port.

NOTE:

MACs associated with LAGs appear under the LAG ID, not under the LAG port.

The syntax for this command is:

```
show cam [module[/port]]
```

module (Optional)	Number of the switch. If you do not specify a number, all switches in the stack are shown.
port (Optional)	Number of the port on the module. If you do not specify a number, all ports on the specified switch are shown.

Example: (by Module/Port)

```
C360-N> show cam 1/1
show cam 1/1
Dest MAC/Route Dest Destination Ports
-----
00-40-0d-59-03-78 1/1
00-d0-79-0a-0a-da 1/1
00-40-0d-43-1e-e9 1/1
...
00-40-0d-c6-24-01 1/1
Total Matching CAM Entries Displayed = 178
```

show cam mac

User level: user, privileged, supervisor

Use the `show cam mac` command to display the module and port number where a specific MAC address was learned.

NOTE:

MACs associated with LAGs appear under the LAG ID, not under the LAG port.

The syntax for this command is:

```
show cam mac <mac-addr>
```

mac-addr	MAC address to search for.
----------	----------------------------

Example:

```
C360-N# show cam mac 00-00-81-01-23-45
Dest MAC/Route Dest Destination Ports VLAN
-----
00-a0-cc-66-4e-52 1/8 1
Total Matching CAM Entries Displayed = 1
```

show cam vlan

User level: user, privileged, supervisor

Use the `show cam vlan` command to display the MAC addresses learned on a specific VLAN. The MAC addresses are displayed with their destination module and port number.

NOTE:

MACs associated with LAGs appear under the LAG ID, not under the LAG port.

The syntax for this command is:

```
show cam vlan <vlan-number>
```

vlan-number	The VLAN on which the MAC addresses were learned.
-------------	---

Example:

```
C360-N# show cam vlan 1
Please be patient.
Gathering and displaying the information might take a while.
Dest MAC/Route Dest Destination Ports VLAN
-----
08-00-20-c4-c8-51 1/8 1
08-00-20-c6-98-5f 1/8 1
00-01-02-9b-ee-ae 1/8 1
00-01-02-dd-2f-9f 1/8 1
00-02-2d-47-00-6f 1/8 1
...
...
...
00-50-da-74-71-93 1/8 1
00-50-da-de-75-ca 1/8 1
00-60-08-96-25-20 1/8 1
Total Matching CAM Entries Displayed = 138
```

show cascading fault-monitoring

User level: user, privileged, supervisor

Use the `show cascading fault-monitoring` command to display the status of the fault trap sending mode for cascading links.

The syntax for this command is:

```
show cascading fault-monitoring [<mod_num>]
```

Example:

```
C360-N> show cascading fault-monitoring 1
Module 1 cascading-down fault monitoring enabled.
Module 1 cascading-up fault monitoring enabled.
```

show dev log file

User level: privileged, supervisor.

Use the `show dev log file` command to display the encrypted device's log file.

The syntax for this command is:

```
show dev log file
```

Example:

```
C360-N> show dev log file

iW}ZH~YL{ }Z(^E^M}=}EsZ^E}Z
ZH~YL{ }Zj^M}ZZZZZZDZ( " "0Ji HA
Zl{~=ZNLMR}EZZZZZZDZw
Zl~'= ;^E}ZK}Esz~NZDZ@:3:<w
Z!lZjLMR}EZZZZZZZZDZw:3
ZiW}Zl^>}YZn^=^ZzsDZ
ZZZZZZZZZZZZZZ
```

show device-mode

User level: user, privileged, supervisor

Use the `show device-mode` command to show the current C360 operating mode. Possible modes are Router, or Layer 2.

The syntax for this command is:

```
show device-mode
```

Example:

```
C360-N> show device mode
Device mode is router
```

show dot1x

User level: user, privileged, supervisor

Use the `show dot1x` command to display the system dot1x capabilities, protocol version, and timer values.

The syntax for this command is:

```
show dot1x
```

Example:

```
C360-N> show dot1x
dot1x Capabilities           Authenticator Only
Protocol Version             1
system-auth-control         disabled
*** Warning : No authentication can be made because
*** authentication server ( RADIUS ) is disabled/not-
exist
```

show dot1x statistics

User level: user, privileged, supervisor

Use the `show dot1x statistics` command to display Rx and Tx EAPOL and EAP statistics.

The syntax for this command is:

```
show dot1x statistics
```

Example:

```
C360-N> show dot1x statistics
Rx: EAPOL      EAPOL      EAPOL      EAPOL      EAP      EAP      EAP
    Total      Start      Logoff     Invalid    Resp/Id   Resp     LenError
-----
          0          0          0          0          0          0          0

Tx: EAPOL      EAP      EAP
    Total      Req/Id   Req
-----
          0          0          0
```

show download status

User level: user, privileged, supervisor

Use the `show download status` command to display a summary of the last software download operation.

The syntax for this command is:

```
show download status [module_number]
```

Example:

```
C360-N> show download status 1
Module #1
=====
Module           : 1
Source file      : c:\session4.txt
Destination file : module-config
Host             : 149.49.75.100
Running state    : Idle
Failure display  : SCP - Server refused
Last warning     : No-warning
Bytes Downloaded : 0
```

show image version

User level: user, privileged, supervisor

Use the `show image version` command to display the software version of the image on both memory banks of a specified switch.

The syntax for this command is:

```
show image version [<slot>]
```

slot	Switch number. If you do not specify a number then the image version for all switches in the stack will be displayed.
------	---

Example:

```
C360-N> show image version 1
Mod      Module-Type                               Bank  Version
-----  -
1        48 10/100Base-Tx-Pwr + 2 SFP ports switch    A    4.3.4
1        48 10/100Base-Tx-Pwr + 2 SFP ports switch    B    4.3.10
```

show intelligent-multicast

User level: user, privileged, supervisor

Use the `show intelligent-multicast` command to display the intelligent multicast configuration.

The syntax for this command is:

```
show intelligent-multicast
```

Example:

```
C360-N> show intelligent-multicast
Intelligent-multicast configuration:
-----
intelligent-multicast state ----- Disabled
Intelligent-multicast client-port-pruning time --- 600[Sec]
Intelligent-multicast router-port-pruning time --- 1800[Sec]
intelligent-multicast group-filtering-delay time - 10[Sec]
```

show intelligent-multicast hardware-support

User level: user, privileged, supervisor

Use the `show intelligent-multicast hardware-support` command to display the intelligent multicast hardware support configuration.

The syntax for this command is:

```
show intelligent-multicast hardware-support
```

Example:

```
C360-N> show intelligent-multicast hardware support
Intelligent-multicast HW configuration:
#  Module          Sub-Module          Cascade
-----
1  Support IPMc     Not Installed       Support IPMc
```

show interface

User level: user, privileged, supervisor

Use the `show interface` command to display information on network interfaces.

The syntax for this command is:

```
show interface
```

Example:

```
C360-N> show interface
Interface Name      Status      VLAN      IP address      Netmask
-----
inband              disabled    1         135.64.200.105  255.255.255.0
ppp                 disabled    N/A      0.0.0.0         0.0.0.0
```

show intermodule port redundancy

User level: user, privileged, supervisor

Use the `show intermodule redundancy` command to display the intermodule port redundancy entry defined for the stack.

The syntax for this command is:

```
show intermodule port redundancy
```

Example:

```
C360-N> show intermodule port redundancy
Primary-Port           : 1/1
Primary-Port status    : Disable
Secondary-Port         : 1/2
Secondary-Port status  : Disable
```

show internal buffering

User level: user, privileged, supervisor

Use the `show internal buffering` command to display the size options (Maximum, Minimum, or Medium) of the Receive (Rx) buffer allocated to each port of the specified switch.

NOTE:

Internal buffering for the C360 switches will always have the value `Not supported`. This command is used to display the internal buffering status for the P330 switches in the stack

The syntax for this command is:

```
show internal buffering [<mod_num>]
```

mod_num	Switch number. If you do not specify a number then the internal buffering for all switches in the stack will be displayed.
---------	--

Example:

```
C360-N> show internal buffering 1
Module  Internal Buffer
-----  -
1      med
```

show ip route

User level: user, privileged, supervisor

Use the `show ip route` command to display IP routing table entries.

The syntax for this command is:

```
show ip route
```

Example:

```
C360-N> show ip route
Destination          Gateway
-----
0.0.0.0              149.49.54.1
0.0.0.0              0.0.0.0
0.0.0.0              0.0.0.0
0.0.0.0              0.0.0.0
0.0.0.0              0.0.0.0
0.0.0.0              0.0.0.0
0.0.0.0              0.0.0.0
0.0.0.0              0.0.0.0
0.0.0.0              0.0.0.0
0.0.0.0              0.0.0.0
0.0.0.0              0.0.0.0
0.0.0.0              0.0.0.0
```

show ip ssh

User level: supervisor

Use the `show ip ssh` command to display active SSH connections.

The syntax for this command is:

```
show ip ssh
```

Example:

```
C360-N> show ip ssh

Ssh Engine: Enable
Max Sessions: 2
Key Type: DSA , 768 bit
Listen Port: 22
Ciphers List: 3des-cbc
Session-Id  Version  Encryption  User      IP:Port
0x508622f0    2      3des-cbc   root     135.64.100.73:4201
```

show l2-module-config

User level: privileged, supervisor.

Use the `show l2-module-config` command to display Layer 2 module configuration.

NOTE:

If this command is to be implemented on a switch other than the stack master, open a session to the relevant switch.

The syntax for this command is:

```
show l2-module-config
```

Example:

```

C360-N> show l2-module-config

Please be patient.
Gathering and displaying the information might take a while.

C360-N(super)# !#
!# Upload time:          Unavailable Unavailable
!# System description:   Avaya Inc. - C360
!# Master position:      1
!#
!# Module #:             1
!# Module type, expansion type: C364T-PWR-AC
!# Module-CS, expansion-CS:   0.0
!# MAC address:          00-04-0d-3a-3c-00
!# Serial #:             1234567
!# SW versions - bank A, B, Boot: 4.3.4 4.3.10 90.0.33
!# Number of ports:       50!#
!#
set port channel 2/30 on "qq"
!#
!#
!# Set queuing scheme parameters.

!#

set queuing scheme wrr 10 2

set cascading up fault-monitoring disable 2

set port spantree disable 2/5

set port edge admin state 2/52 non-edge-port

set port trap 2/1 disable

set port disable 2/1

set port classification 2/2 valuable

....

set port negotiation 2/11 disable

set port duplex 2/11 half

set port disable 2/15

set port negotiation 2/31 disable

set trunk 2/40 dot1q

set trunk 2/44 dot1q

set port vlan 500 2/44

set trunk 2/51 dot1q

set port dot1x port-control 2/2 force-authorize

set port dot1x port-control 2/18 force-authorize

set secure mac 00-00-01-02-02-02 port 2/5

set secure mac 00-10-5a-0f-5e-1c port 2/11

set port security enable 2/2

```

```

set port security enable 2/10
set port vlan-binding-mode 2/42 bind-to-configured
set port vlan-binding-mode 2/44 bind-to-all

```

show l2-stack-config

User level: privileged, supervisor.

Use the `show l2-stack-config` command to display Layer 2 stack configuration.

The syntax for this command is:

```
show l2-stack-config
```

Example:

```

C360-N> show l2-stack-config
C360-N(super)# !#
!# Upload time:                Unavailable Unavailable
!# System description:         Avaya Inc. - C360
!# IP address, netmask:        149.49.138.157 255.255.255.0
!# Master position:            2
!# Number of modules:          2
!#
set spantree priority 4096
set arp-tx-interval 0
set logging server 149.49.38.22
set logging server condition all Informational 149.49.38.22
set logging file enable
snmp-server informs retries 5 timeout 30
snmp-server group sammy v3 auth read sammy write sammy
snmp-server group sammy v3 priv read iso write iso
snmp-server group initial v3 noauth read iso write iso notify iso
snmp-server view initial 1.3.6.1.4.1.1751.2.53.1.2.1.3.* included
snmp-server host 1.3.4.5 traps v3 noauth initial config generic eth-port-
faults
sw-redundancy temperature cam-Change l3-fault lag-events policy link-down-
fault supply fan cascade security

```

```

...
set time client disable
set ip route 0.0.0.0 149.49.138.1
set logout 0
set vlan 2 name V2
set vlan 3 name V3
set port static-vlan 1/1 3
set port static-vlan 1/2 3
rmon history 1025 1025 interval 30 buckets 10 owner "SYSTEM on console11"
rmon history 1026 1025 interval 1800 buckets 10 owner "Administrator on
console2"
set snmp retries 5
no ip http
set ppp authentication incoming chap
set ppp incoming timeout 10
set radius authentication enable
set radius authentication server 149.49.138.161 primary
set radius authentication server 149.49.77.235 secondary
set allowed managers ip add 1.1.11.1

```

show leaky-vlan

User level: privileged, supervisor.

NOTE:

This command is not relevant to C360 switches. It appears in the C360 CLI for controlling internal buffering of P330 switches in the stack.

Use the `show leaky-vlan` command to display the P330 leaky VLAN mode.

The syntax for this command is

```
show leaky-vlan
```

Example:

```
P330-N# show leaky-vlan
Leaky VLAN mode Disable
```

show license

User level: privileged, supervisor.

Use the `show license` command to display the current licenses installed on the stack.

The syntax for this command is:

```
show license
```

Example:

```
C360-#> show license
Mod      Application      License Key      State  Feature Flag
-----
1        smon             0000 0000 0000 0000 0000 0000  licensed  1
```

show log

User level: privileged, supervisor.

Use the `show log` command to display an encrypted device's reset log.

NOTE:

This command is for Avaya technical support use.

The syntax for this command is:

```
show log [mod_num]
```

Example:

```
C360-N# show log 1
MODULE 1, MESSAGE 01:
00000000 0 05002966 0205 0 0 0 0 0 0 0 0 0 0
MODULE 1, MESSAGE 02:
00000000 0 00004242 0205 0 0 0 0 0 0 0 0 0 0
MODULE 1, MESSAGE 03:
00000000 0 00002395 0205 0 0 0 0 0 0 0 0 0 0
```

show logging file condition

User level: user, privileged, supervisor

Use the show logging file condition command to display the condition and filtering of the log file.

The syntax for this command is:

```
show logging file condition
```

Example:

```
C360-N> show logging file condition

*****
*** Message logging configuration of FILE      sink ***
Sink Is Enabled
Sink default severity: none
```

show logging file content

User level: user, privileged, supervisor

Use the show logging file content command to display the contents of the log file.

The syntax for this command is:

```
show logging file content [<severity>] [{all|<application>}] [<number>]
[<module number>]
```

severity	The minimum severity of the logging messages that are displayed. The severity is represented by an integer. Possible values are: <ul style="list-style-type: none"> • 0 – Emergency • 1 – Alert • 2 – Critical • 3 – Error • 4 – Warning • 5 – Notification • 6 – Informational • 7 – Debugging
all	A keyword signifying that the filter applies to logging messages from all applications.

application	<p>The application to which the filter applies. Possible values are:</p> <ul style="list-style-type: none"> • System • ROUTER • CONFIG • FILESYS • FAN • SUPPLY • SECURITY • CASCADE • QOS • SWITCHFABRIC • LAG • VLAN • SNMP • POLICY • CLI • STP • THRESHOLD
number	The number of messages to display. If no number is specified, all messages are displayed.
module	The number of the module from which the displayed messages originated. If no module is specified, messages from all modules are displayed.

Example:

```
C360-N> show logging file content 7 all
1 > 08/04/2003,15:43:36:CLI-Notification: root: set logging file
condition all 7
```

show logging server condition

User level: user, privileged, supervisor

Use the `show logging server condition` command to display the condition and filtering of logging to the Syslog server.

The syntax for this command is:

```
show logging server condition <ip-address>
```

ip-address	The IP address of the Syslog server. If no IP address is specified, the condition and filtering of logging to all configured Syslog servers is displayed.
------------	---

Example:

```
C360-N> show logging server condition 149.49.38.22

*****
*** Message logging configuration of SYSLOG   sink ***
Sink Is Enabled
Sink default severity: Warning

Server name: 149.49.38.22
Server facility: local7
Server access level: read-write
```

show logging session condition

User level: user, privileged, supervisor

Use the `show logging session condition` command to display the condition and filtering of logging in the current CLI session.

The syntax for this command is:

```
show logging session condition
```

Example:

```
C360-N> show logging session condition

*****
*** Message logging configuration of SESSION sink ***

Sink Is Enabled
Sink default severity: Error

Facility                ! Severity Override
-----
SUPPLY                  ! Warning
Session source ip: 135.64.102.224
```

show logout

User level: user, privileged, supervisor

Use the `show logout` command to display the amount of time the CLI remains idle before timing out in minutes.

If the result is 0, there is no timeout limit. The default is 15 minutes.

The syntax for this command is:

```
show logout
```

Example:

```
C360-N> show logout
CLI timeout is 10 minutes
```

show mac-aging

User level: user, privileged, supervisor

Use the `show mac-aging` command to display the current status of the MAC aging function.

The syntax for this command is:

```
show mac-aging
```

Example:

```
C360-N> show mac-aging
mac aging application is disabled
```

show mac-aging-time

User level: user, privileged, supervisor

Use the `show mac-aging-time` command to display the MAC aging time in minutes.

The syntax for this command is:

```
show mac-aging-time
```

Example:

```
C360-N> show mac-aging-time
MAC aging time is 5 (min.)
```

NOTE:

The displayed value is the aging time lower limit. The actual aging time can be up to 2 minutes longer.

show module

User level: user, privileged, supervisor

Use the `show module` command to display switch status and information. For each switch with an expansion sub-module installed, both switch and expansion sub-module type and information are shown.

The syntax for this command is:

```
show module [<module>]
```

module	(Optional) Number of the switch/expansion module. If you do not specify a number, all switches/expansion modules are shown.
--------	---

Example:

```
C360-N> show module
```

Mod	Type	C/S	S/N	Statuses
1	C364T-PWR	0.0	1234567	PS:AC Fans:Fail Mode:Router
	C360STK	0.0		Conn-Up:Fail Conn-Down:Fail
	BUPS			BUPS:Not Prsnt Power:800 Watts

Output Fields

Mod	Switch number
Type	Switch/Expansion module type
C/S	Hardware Configuration Symbol of the switch/expansion module
S/N	Serial number of the switch
Status	Status of the switch (and expansion module)

show module-identity

User level: user, privileged, supervisor

Use the `show module-identity` command to display the switch identity required for acquiring a license.

The syntax for this command is:

```
show module-identity [module]
```

Example:

```
C360-N> show module-identity
```

Mod	Module Identity
1	1234567
2	4144162

show port

User level: user, privileged, supervisor

Use the `show port` command to display port status.

The syntax for this command is:

```
show port [<mod_num>[/port_num]]
```

mod_num (Optional)	Number of the switch. If you do not specify a number, the ports on all the switches are shown.
port_num (Optional)	Number of the port on the module (can be a virtual LAG port number). If you do not specify a number, all the ports on the switch are shown. You can also specify a range of ports separated by a dash, for example, 4/5-13 for ports 5 to 13 on switch 4.

Example: to display the status for port 4 on switch 3

```
C360-N> show port 3/4
```

Port	Name	Status	Vlan	Level	Neg	Dup.	Spd.	Type
3/4	Gregory	no link	1	0	enable	half	10M	10/100BaseTx Port

Show Port Output Fields

Port	Switch and port number
Name	Name of port
Status	Status of the port (connected, no link, disabled)
Vlan	VLAN ID of the port
Level	Priority level of the port (0-7)
Neg	The autonegotiation status of the port (enabled, disabled)
Dup	Duplex setting for the port (full, half)
Speed	Speed setting for the port (10Mbps, 100Mbps, 1000Mbps)
Type	Port type, for example: <ul style="list-style-type: none"> 10/100BASE-Tx, 1000BASE-SX Port, Link Aggregation Group of 10/100BASE-T ports

show port auto-negotiation-flowcontrol-advertisement

User level: privileged, supervisor.

Use the `show port auto-negotiation-flowcontrol-advertisement` command to display the flowcontrol advertisement for a Gigabit port used to perform auto-negotiation.

The syntax for this command is:

```
set auto-negotiation-flowcontrol-advertisement [mod_num/port_num]
```

mod_num (optional)	Number of the switch
port_num (optional)	Number of the port

Example:

```
C360-N> show port auto-negotiation-flowcontrol-advertisement

Port 1/1  advertises no flow control capabilities.
Port 1/2  advertises no flow control capabilities.
Port 1/3  advertises no flow control capabilities.
```

show port channel

User level: user, privileged, supervisor

Use the `show port channel` command to display Link Aggregation Group (LAG) information for a specific switch or port.

The syntax for this command is:

```
show port channel [<mod_num>[/<port_num>]] [info]
```

mod_num (Optional)	Number of the switch. If you do not specify a number, the modules on all the switches are shown.
port_num (Optional)	Number of the port on the switch. If you do not specify a number, all the ports on the switch are shown. You can also specify a range of ports separated by a dash, for example, 4/5-13 for ports 5 to 13 on switch 4.
info (Optional)	Display port information

Example:

```

C360-N> show port channel
Port    Channel Status  Channel Name      Channel Id
-----
 1/1      on      MEIR              1/101
 1/2      on      MEIR              1/101
 1/3      off
 1/4      off
 1/5      on      my-channel        1/102
 1/6      on      my-channel        1/102
 1/7      off
 1/8      on      my-channel        1/102
C360-N> show port channel 3/3 info
Port    Speed Duplex  Vlan  Port    Trunk    Vlan
              Priority status  Binding
-----
 1/1    10    half   1     0       off      static

```

show port classification

User level: user, privileged, supervisor

Use the `show port classification` command to display a port's classification.

The syntax for this command is:

```
show port classification [module/[port]]
```

module	Number of the switch. If you do not specify a number, the ports on all the switches are shown.
port (Optional)	Number of the port on the module. If you do not specify a number, all the ports on the module are shown. You can also specify a range of ports separated by a dash, for example, 4/5-13 for ports 5 to 13 on module 4.

Example:

```

C360-N> show port classification 4/8
Port    Port Classification
-----
 4/8    regular
C360-N> show port classification 4/9
Port    Port Classification
-----
 4/9    valuable

```

show port dot1x

User level: user, privileged, supervisor

Use the `show port dot1x` command to display all the configurable values associated with the authenticator port access entity (PAE) and backend authenticator.

The syntax for this command is:

```
show dot1x [mod]/[port]
```

mod (Optional)	Number of the module.
port (Optional)	Number of the port on the module, or range of ports.

Example:

C360-N> show port dot1x 1/3											
Port Number	Auth State	BEnd State	Port Control	Port Status	Re Auth	Quiet Priod	ReAuth Priod	Server Tmeout	Supp Tmeout	Tx Priod	Max Req
-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----
1/3	Init	Init	Auto	Unauth	Disa	60	3600	30	30	30	2

Port Number	Number of the module/port on the module.
Auth State	<p>The Port Access Entity state. Possible states include:</p> <ul style="list-style-type: none"> • Initialize • Disconnected • Connecting • Authenticating • Authenticated • Aborting • Held • ForceAuth • ForceUnauth

BEnd Stat	The current state of the Backend Authentication state machine. Possible states include: <ul style="list-style-type: none"> • Request • Response • Success • Fail • Timeout • Idle • Init
Port Control	Port control type. Valid values include: <ul style="list-style-type: none"> • force-authorized • force-unauthorized • auto.
Port Status	The current value of the controlled port status. Possible states include: <ul style="list-style-type: none"> • Authorized • Unauthorized
Re Auth	The state of reauthentication on the port. Possible states include: <ul style="list-style-type: none"> • Enabled - The port connection is reauthenticated after the reAuthPeriod. • Disabled - The port connection is not reauthenticated. The reAuthPeriod is ignored.
Quiet Period	The amount of time, in seconds, between sending authentication requests.
ReAuth Period	The time, in seconds, after which the port connection should be reauthenticated.
Server Tmout	The amount of time, in seconds, the C360 waits for a response from the RADIUS server.
Supp Tmeout	The amount of time, in seconds, before resending authentication requests.
Tx Priod	The amount of time, in seconds, in which an authentication request must be answered.
Max Req	The maximum number of times a request for authentication is sent before timing out.

show port dot1x statistics

User level: user, privileged, supervisor

Use the `show port dot1x statistics` command to display all the port dot1x statistics.

The syntax for this command is:

```
show dot1x statistics [mod]/[port]
```

mod (Optional)	Number of the module.
port (Optional)	Number of the port on the module, or range of ports.

Example:

```
C360-N> show port statistics 1/1
```

Port	Tx_Req/Id	Tx_Req	Tx_Total	Rx_Start	Rx_Logff	Rx_Resp/Id	Rx_Resp
1/1	2	5	0	0	0	0	0
Port	Rx_Invalid	Rx_Len_Err	Rx_Total	Last_Rx_Frm_Ver	Last_Rx_Frm_Src_Mac		
1/1	0	0	0	0	1d-80-00-00-00-00		

show port edge state

User level: user, privileged, supervisor

Use the `show port edge state` command to show a port's edge admin and operational RSTP state.

NOTE:

A port can be set to admin state of edge port, but if a BPDU is received on this port the oper state is changed to non-edge state.

The syntax for this command is:

```
show port edge state <module/port>
```

module/port	Port identifier
-------------	-----------------

Example:

```
C360-N> show port edge state
```

Port	admin state	oper state
1/1	edge-port	edge-port
1/2	non-edge-port	non-edge-port

show port flowcontrol

User level: user, privileged, supervisor

Use the `show port flowcontrol` command to display per-port status information related to flow control.

The syntax for this command is:

```
show port flowcontrol [<mod_num>[/<port_num>]]
```

module (Optional)	Number of the switch . If you do not specify a number, all switches are shown.
port (Optional)	Number of the port on the switch. If you do not specify a number, all ports on the specified switch are shown.

Example:

```
C360-N> show port flowcontrol 3/4
Port      Send-Flowcontrol  Receive-Flowcontrol
          Admin Oper          Admin Oper
-----
3/4 off off      off off
```

Output Fields

Port	Module and port number
Send-Flowcontrol-Admin	Send flow-control administration. Possible settings: <ul style="list-style-type: none"> • ON indicates that the local port is allowed to send flow control frames to the far end. • OFF indicates that the local port is <i>not</i> allowed to send flow control frames to the far end.
Send-Flowcontrol-Oper	Send flow-control operation mode. Possible modes: <ul style="list-style-type: none"> • ON indicates that the local port will send flow control frames to the far end. • OFF indicates that the local port will <i>not</i> send flow control frames to the far end.
Receive-Flowcontrol-Admin	Receive flow-control administration. Possible settings: <ul style="list-style-type: none"> • ON indicates that the local port will act upon flow control indications if received from the far end. • OFF indicates that the local port will discard flow control frames if received from the far end.

Receive-Flowcontrol-Oper	Receive flow-control operation mode. Possible modes: <ul style="list-style-type: none"> • ON indicates that the local port will act upon flow control indications received from the far end. • OFF indicates that the local port will discard flow control frames received from the far end.
--------------------------	--

show port mirror

User level: user, privileged, supervisor

Use the show port mirror command to display mirroring information for the stack.

The syntax for this command is:

```
show port mirror
```

Example:

```
C360-N> show port mirror
port mirroring
-----
Mirroring both Rx and Tx packets from port 3/2 to port 4/4 is enabled

C360-N>show port mirror
port mirroring
```

show port point-to-point status

User level: user, privileged, supervisor

Use the show port point-to-point status command to show the port's point-to-point admin and operational RSTP status.

The syntax for this command is:

```
show port point-to-point status <module/port>
```

module/port	Port identifier
-------------	-----------------

Example:

```
C360-N> show port point-to-point status
Port      point-to-point admin state  point-to-point oper state
-----
1/1       auto                        point to point connection
1/2       auto                        point to point connection
1/3       auto                        point to point connection
1/4       auto                        point to point connection
1/5       auto                        point to point connection
1/6       auto                        point to point connection
1/7       auto                        point to point connection
```

show port redundancy

User level: user, privileged, supervisor

Use the `show port redundancy` command to display information about the port redundancy schemes defined for the switch. The “status” column displays which of the two redundancy member ports is enabled currently.

The syntax for this command is:

```
show port redundancy
```

Example:

```
C360-N> show port redundancy
Redundancy Name      Primary Port      Secondary Port      Status
-----
gregory              3/48              3/47                secondary
rafi                  3/46              3/45                secondary
meir                  3/1                3/2                 primary
arie                  3/34              3/33                secondary

Port Redundancy global state is enable

Minimum Time between Switchovers: 1
Switchback interval: 3
```

show port security

User level: user, privileged, supervisor

NOTE:

This command is not relevant to C360 switches. It appears in the C360 CLI for displaying port security of P330 switches in the stack.

Use the `show port security` command to list the security mode of the ports of a switch or stack. When no port number is specified, this command displays all the secured ports in the stack.

The syntax for this command is:

```
show port security [<module>[/<port>]]
```

Example:

```
C360-N> show port security 1
Switch-level security mode disabled
Violation action is restrict and notify
Port      Status
-----  -
1/1      enabled
1/2      disabled
1/3      disabled
...
```

show port trap

User level: user, privileged, supervisor

Use the `show port trap` command to display information on SNMP generic link up/down traps sent for a specific port.

The syntax for this command is:

```
show port trap [<module>[/<port>]]
```

module (Optional)	Number of the switches. If you do not specify a number, the ports on all the switches are shown.
port (Optional)	Number of the port on the switch. If you do not specify a number, all the ports on the switch are shown. You can also specify a range of ports separated by a dash, for example, 4/5-13 for ports 5 to 13 on switch 4.

Example:

```
C360-N> show port trap 4/1
Port 4/1 up/down trap is disabled
```

show port vlan-binding-mode

User level: user, privileged, supervisor

Use the `show port-vlan-binding` command to display port vlan binding mode information.

The syntax for this command is:

```
show port vlan-binding-mode [module[/port]]
```

module	Number of the switch. If you do not specify a number, the ports on all the switches are shown.
port (Optional)	Number of the port on the switch. If you do not specify a number, all the ports on the switch are shown. You can also specify a range of ports separated by a dash, for example, 4/5-13 for ports 5 to 13 on switch 4.

Example:

```
C360-N> show port vlan-binding-mode
port 2/1 is statically bound
port 2/2 is statically bound
port 2/3 is statically bound
port 2/4 is statically bound
port 2/5 is statically bound
port 2/6 is statically bound
port 2/7 is statically bound
port 2/8 is statically bound
port 2/9 is statically bound
port 2/10 is statically bound
```

show powerinline

User level: user, privileged, supervisor

NOTE:

This command applies to the C363T-PWR and C364T-PWR only.

Use the `show powerinline` command to display the current status of the PD inline power on all ports.

The syntax of this command is:

```
show powerinline <mod_number [/<port_number>]>
```

Example:

```
C360-N> show powerinline 3
Port      Inline Operational      Powering
          Status              Priority
-----  -
3/1      on                       Low
3/2      on                       Low
3/3      on                       High
...
```

Example:

```
C360-N> show powerinline 2/1
Port      Inline Operational      Powering
          Status              Priority
-----  -
2/1      off                      Low
```

show ppp authentication

User level: user, privileged, supervisor

Use the `show ppp authentication` command to display the authentication method used for PPP sessions.

The syntax for this command is:

```
show ppp authentication
```

Example:

```
C360-N> show ppp authentication
PPP Authentication Parameters:
-----
Incoming:      CHAP
```

show ppp baud-rate

User level: user, privileged, supervisor

Use the `show ppp baud-rate` command to display the ppp baud-rate.

The syntax for this command is:

```
show ppp baud-rate
```

Example:

```
C360-N> show ppp baud-rate
PPP baud rate is 38400
```

show ppp configuration

User level: user, privileged, supervisor

Use the `show ppp configuration` command to display the ppp configuration.

The syntax for this command is:

```
show ppp configuration
```

Example:

```
C360-N> show ppp configuration
PPP baud rate is 38400
PPP incoming timeout is 15 minutes
PPP Authentication Parameters:
-----
Incoming:          None
```

show ppp incoming timeout

User level: user, privileged, supervisor

Use this `show ppp incoming timeout` command to display the amount of time in minutes that a PPP session can remain idle before being automatically disconnected.

The syntax for this command is:

```
show ppp incoming timeout
```

Example:

```
C360-N> show ppp incoming timeout
PPP incoming timeout is 15 minutes
```

show ppp session

User level: user, privileged, supervisor

Use the `show ppp session` command to display PPP parameters and statistics of an active PPP session.

The syntax for this command is:

```
show ppp session
```

Example:

```
C360-N> show ppp session
```

show protocol

User level: user, privileged, supervisor

Use the `show protocol` command to display the current state of allowed protocols on the switch.

The syntax for this command is:

```
show protocol
```

Example:

```
C360-N> show protocol
  Protocols          Status
  -----          -
SSH                 ON
TELNET-CLIENT      OFF
SNMPv1              OFF
TELNET              ON
HTTP                OFF
ICMP redirect       OFF
recovery-password   ON
```

show queuing scheme

User level: user, privileged, supervisor

NOTE:

This command is available on C360 switches with Routing only

Use the `show queuing scheme` command to display the current queuing scheme settings.

NOTE:

If this command is to be implemented on a C360 switch other than the stack master, open a session to the relevant switch.

The syntax for this command is:

```
show queuing scheme
```

Example:

```
C360-N> show queuing scheme
Module Queuing Scheme
-----
1   Wrr 1:4:16:64
```

show radius authentication

User level: user, privileged, supervisor

Use the `show radius authentication` command to display all RADIUS authentication configurations.

The syntax for this command is:

```
show radius authentication
```

Example:

```
C360-N> show radius authentication
Mode:                Enabled
Primary-server:      192.168.42.252
Secondary-server:    192.168.48.134
Retry-number:        4
Retry-time:          5
UDP-port:            1645
Shared-secret:       sodot
```

show rmon alarm

User level: user, privileged, supervisor

Use the `show rmon alarm` command to display the parameters set for a specific alarm entry that was set using the `rmon alarm` command on or using the C360 Device Manager.

The syntax for this command is:

```
show rmon alarm [<Alarm Index>]
```

Alarm Index	History index defined using <code>rmon alarm</code> command or the C360 Manager.
-------------	--

Example:

```
C360-N> show rmon alarm 1026
alarm

alarm 1026 is active, owned by amir
Monitors ifEntry.1.1026 every 60 seconds
Taking delta samples, last value was 1712
Rising threshold is 10000, assigned to event # 1054
Falling threshold is 10, assigned to event # 1054
On startup enable rising or_falling alarms.
```

show rmon event

User level: user, privileged, supervisor

Use the `show rmon event` command to show the parameters of an Event entry defined by the `rmon` event command or using the C360 Device Manager.

The syntax for this command is:

```
show rmon event [<Event Index>]
```

Alarm Index	History index defined using <code>rmon event</code> command or the C360 Manager
-------------	---

Example:

```
C360-N> show rmon event 1026
event

Event 1054 is active, owned by amir
Description is event for monitoring amir's co
Event firing causes log and trap to community public,last fired
0:0:0
```

show rmon history

User level: user, privileged, supervisor

Use the `show rmon history` command to display the most recent RMON history log for a given History Index. The history index is defined using the `rmon history` command or using an RMON management tool.

The syntax for this command is:

```
show rmon history [<History Index>]
```

History Index	History index defined using rmon history command or RMON management tool
---------------	--

Example:

```
C360-N> show rmon history 1026
history
Entry 1026 is active, owned by amir
Monitors ifEntry.1.1026 every 30 seconds
Requested # of time intervals, ie buckets, is 20
Granted # of time intervals, ie buckets, is 20
Sample # 1 began measuring at 2:53:9
Received 62545 octets, 642 packets,
391 broadcast and 145 multicast packets,
0 undersize and 0 oversize packets,
0 fragments and 0 jabbers,
0 CRC alignment errors and 0 collisions,
# of dropped packet events (due to a lack of resources): 0
Network utilization is estimated at 0
```

show rmon statistics

User level: user, privileged, supervisor

Use the `show rmon statistics` command to show the Received Packet RMON statistics counters for a certain interface number according to the MIB-2 interface table numbering scheme.

The syntax for this command is:

```
show rmon statistics <module/port>
```

module/port	Range of ports
-------------	----------------

Example:

```
C360-N> show rmon statistics
Statistics for switch is active,owned by Monitor
Monitors ifEntry.1.1026 which has
Received 26375085 octets, 222536 packets,
154821 broadcast and 53909 multicast packets,
0 undersize and 0 oversize packets,
0 fragments and 0 jabbers,
1 CRC alignment errors and 0 collisions,
# of dropped packet events (due to a lack of resources): 0
# of packets received of length (in octets):
64:94530, 65-127:85124, 128-255:25896,
256-511:10440, 512-1023:6057, 1024-1518:489
```

show secure current

User level: user, privileged, supervisor

Use the `show secure current` command to list the IP addresses of managers currently connected to the switch.

The syntax for this command is:

```
show secure current
```

Example:

```
C360-N> show secure current
  IP Address                Time Since Last Request(In Sec)
  -----
  135.64.100.205            7
  149.49.77.13              13
  149.49.77.7               2
```

show security mode

User level: user, privileged, supervisor

Use the `show security mode` command to display the mac security mode of the stack.

The syntax for this command is:

```
show security mode
```

Example:

```
C360-N> show security mode
Switch-level security mode disabled.
```

show serial-number

User level: user, privileged, supervisor

Use the `show serial-number` command to display the serial number of the switch.



Tip:

This number contains information that may be required by Avaya Technical Support. It is recommended to have the serial number available when you contact them.

The syntax for this command is:

```
show serial-number
```

Example:

```
C360-N> show serial number
Serial number:      1234567
New format:        255255//255255255255255255255255
```

show snmp

User level: user, privileged, supervisor

Use the `show snmp` command to display SNMP information.

The syntax for this command is:

```
show snmp
```

```

C360-N> show snmp
  Authentication trap enabled

Community-Access      Community-String
-----
read-only             public
read-write           public
trap                  meir

Trap-Rec-Address      Status      Traps Configured
-----
135.64.100.73        Enabled
config
fault
traffic_threshold
module_De-Enrollment
module_Enrollment
delete_SW_redundancy_entry
create_SW_redundancy_entry
temperature_warning
general_threshold
cam_change
duplicate_ip
ip_vlan_violation
link_aggregation_connection_fault
link_aggregation_connection_return
link_aggregation_partial_fault
link_aggregation_partial_return
link_aggregation_auto_neg_fault
link_aggregation_auto_neg_fault_return
delete_lag
create_new_lag
active_policy_list_change
policy_access_control_violation
PSU_module_fault
PSU_module_fault_return
BUPS_module_fault
BUPS_module_fault_return
BUPS_fans_module_fault
BUPS_fans_module_fault_return
fans_module_fault
fans_module_fault_return
cascade_up_connection_fault
Cascade_up_connection_fault_return
Cascade_down_connection_fault

```

show snmp retries

User level: user, privileged, supervisor

Use the `show snmp retries` command to display the number of retries initiated by the C360 Device Manager when it tries to send SNMP messages to the device.

The syntax for this command is:

```
show snmp retries
```

Example:

```

C360-N> show snmp retries
the SNMP Retries Number is 3

```

show snmp timeout

User level: user, privileged, supervisor

Use the `show snmp timeout` command to display the default SNMP timeout in seconds. The SNMP timeout is only for the Avaya C360 Device Manager.



Tip:

This command is useful for access using the Device Manager.

The syntax for this command is:

```
show snmp timeout
```

Example:

```
C360-N> show snmp timeout
the SNMP Timeout is 2000
```

show spantree

User level: user, privileged, supervisor

Use then `show spantree` command to display spanning-tree information.

The syntax for this command is:

```
show spantree [<mod_num>[/<port_num>]]
```

mod_num (Optional)	Number of the switch. If you do not specify a number, all switches are shown.
port (Optional)	Number of the port on the switch. If you do not specify a number, all ports on the specified switch are shown.

Example:

```
C360-N> show spantree

Spanning tree state is enabled

Designated Root: 00-40-0d-8c-88-ff
Designated Root Priority: 32768
Designated Root Cost: 100
Designated Root Port: 1/7
Root Max Age: 20 Hello Time: 2
Root Forward Delay: 15

Bridge ID MAC ADDR: 00-40-0d-b9-89-ff
Bridge ID priority: 32768
Bridge Max Age: 20 Bridge Hello Time: 2
Bridge Forward Delay: 15 Tx Hold Count 3
Spanning Tree Version is rapid spanning tree
Spanning Tree Default Path Costs is according to common spanning
tree

Port      State          Cost          Priority
-----
4 /1     not-connected 19             128
4 /2     not-connected 19             128
4 /3     LAG-member    19             128
4 /4     LAG-member    19             128
4 /5     not-connected 19             128
4 /6     not-connected 19             128
4 /8     not-connected 19             128
4 /9     not-connected 19             128
4 /10    not-connected 19             128
4 /11    not-connected 19             128
```

Output fields:

Spanning tree	Status of whether Spanning-Tree Protocol is enabled or disabled
Designated Root	MAC address of the designated spanning-tree root bridge
Designated Root Priority	Priority of the designated root bridge
Designated Root Cost	Total path cost to reach the root
Designated Root Port	Port through which the root bridge can be reached (shown only on nonroot bridges)
Root Max Age	Amount of time a BPDU packet should be considered valid
Hello Time	Number of times the root bridge sends BPDUs
Root Forward Delay	This time value, measured in units of hundredths of a second, controls how fast a port changes its spanning state when moving towards the Forwarding state.
Bridge ID MAC ADDR	Bridge MAC address used in the sent BPDUs
Bridge ID Priority	Bridge priority

Bridge Max Age	The value that all bridges use for MaxAge when this bridge is acting as the root.
Bridge Hello Time	The value that all bridges use for HelloTime when this bridge is acting as the root.
Bridge Forward Delay	The value that all bridges use for ForwardDelay when this bridge is acting as the root.
Tx Hold Count	The value used by the Port Transmit state machine to limit the maximum transmission rate.
Soanning Tree Version	The version of Spanning Tree Protocol the bridge is currently running
Spanning Tree Default Path Costs	The version of the Spanning Tree default Path Costs that are to be used by this Bridge.
Port	Port number
State	Spanning-tree port state (disabled, inactive, not-connected, blocking, listening, learning, forwarding, bridging, or type-pvid-inconsistent)
Cost	Cost associated with the port
Priority	Priority associated with the port

show system

User level: user, privileged, supervisor

Use the `show system` command to display the up time, system name, location, and contact person.

The syntax for this command is:

```
show system
```

Example:

```
C360-N> show system
Uptime d,h:m:s
-----
0,1:20:45

System Name           System Location       System Contact
-----
techdoc                documentation         gregory kohll

Switch MAC address
-----
00 04 0d 3a 3c 00
```

show tftp download software status

User level: user, privileged, supervisor

Use the `show tftp download software status` commands to display the status of the current TFTP Device Manager firmware (Device Manager) download process into the device.

The syntax for this command is:

```
show tftp download software status [<mod_num>]
```

Example:

```
C360-N> show tftp download software status

Module #1
=====
Module           : 1
Source file      : p340_4_0_4.web
Destination file : EW_Archive
Host             : 149.49.100.51
Running state    : Idle
Failure display  : (null)
Last warning     : No-warning
Bytes Downloaded : 1860987
=====
```

show time

User level: user, privileged, supervisor

Use the `show time` command to display the current C360 time and timezone.

The syntax for this command is:

```
show time
```

Example:

```
C360-N> show time
10:32:34 27 JAN 2000 GMT
```

show time parameters

User level: user, privileged, supervisor

Use the `show time parameters` command to display the time status and parameters.

The syntax for this command is:

```
show time parameters
```

Example:

```
C360-N> show time parameters
Client status: Enabled
Current time : L:00:57:19 01 JAN 1970 GMT
Timezone set to 'GMT', offset from UTC is 0 hours
Time-Server : 0.0.0.0 (I.e. broadcast address)
Time acquired from Time-Server: 0.0.0.0
Time protocol set to : TIME protocol
```

show timeout

User level: user, privileged, supervisor

Use the `show timeout` command to display the amount of time the CLI can remain idle before timing out in minutes. If the result is 0, there is no timeout limit. The default is 15 minutes.

The syntax for this command is:

```
show timeout
```

Example:

```
C360-N> show timeout
CLI timeout is 10 minutes
```

show timezone

User level: user, privileged, supervisor

Use the `show timezone` command to display the current C360 time zone.

The syntax for this command is:

```
show timezone
```

Example:

```
C360-N> show timezone
Timezone set to 'GMT', offset from UTC is 0 hours
```

show trunk

User level: user, privileged, supervisor

Use the `show trunk` command to display VLAN tagging information for the switch or a specified module or port.

The syntax for this command is:

```
show trunk [<module>[/<port>]]
```

mod_num (Optional)	Number of the switch. If you do not specify a number, all switches in the stack are shown.
port_num (Optional)	Number of the port on the switch. If you do not specify a number, all ports on the specificity switch are shown. You can specify a port range.

Example:

```
C360-N> show trunk 1/42-44

Port  Mode  Binding mode          Native vlan Vlans allowed on trunk
-----
1/42  off   bound to configured vlans  1          1-9,500

Port  Mode  Binding mode          Native vlan Vlans allowed on trunk
-----
1/43  off   statically bound       1          1,7-8

Port  Mode  Binding mode          Native vlan Vlans allowed on trunk
-----
1/44  dot1q bound to all vlans     500       1-3071
```

Output Fields:

Field	Description
Port	Switch and port number(s)

Mode	Tag status of the port (dot1q - dot1Q tagging mode, off - clear mode).
Binding mode	Binding mode of the port
Native VLAN	Number of the Port VLAN ID (the VLAN to which received untagged traffic will be assigned).

show upload status

User level: user, privileged, supervisor

Use the `show upload status` commands to display the status of the current configuration file copy process from the device.

The syntax for this command is:

```
show upload status [module_number]
```

module_number (Optional)	Number of the module. If you do not specify a number, upload statuses for all modules in the stack are shown.
-----------------------------	---

Example:

```
C360-N> show upload status 1
Module           : 1
Source file      : stack-config
Destination file : c:\conf.cfg
Host             : 149.49.36.200
Running state    : Executing
Failure display  : (null)
Last warning     : No-warning
```

show username

User level: supervisor

Use the `show username` command to display the local user accounts.

The syntax for this command is:

```
show username
```

Example:

User account	password	access-type
root	*****	admin
gkohll	*****	read-only
readwrite	*****	read-write

show utilization

User level: privileged, supervisor

Use the `show utilization` command to display CPU utilization statistics for modules in the stack.

The syntax for this command is:

```
show utilization [module]
```

module	The module for which to display utilization statistics. If no module is specified, utilization statistics for all modules is displayed.
--------	---

Example:

Mod	CPU 5sec	CPU 60sec	RAM used(%)	RAM Total(Kb)
1	1%	2%	35%	48999 Kb

show vlan

User level: user, privileged, supervisor

Use the `show vlan` command to display the VLANs configured in the stack or switch or the ports bound to a specified VLAN.

The syntax for this command is:

```
show vlan { <vlan-id> | name <vlan-name> }
```

vlan-id	The VLAN ID for which to display bound ports.
vlan-name	The VLAN name for which to display bound ports.

Example:

```
C360-N> show vlan
VLAN ID Vlan-name
-----
1       v1
5       V5
10      V10
15      V15
20      V20
25      V25

C360-N> show vlan 7
VLAN ID Vlan-name
-----
7       v7

Switch Ports currently bound to this vlan:
In module 1 : 9 42 43 44

Switch Ports statically bound to this vlan:
In module 1 : 43
```

Output Fields:

Field	Description
VLAN ID	The VLAN ID.
Vlan-name	The VLAN name.
Switch Ports currently bound to this vlan	Switch ports that have this VLAN as their PVID, are statically bound to this VLAN, or configured as bind-to-all or bind-to-configure.
Switch Ports statically bound to this vlan	Switch ports that are statically bound to this VLAN.

show web aux-files-url

User level: user, privileged, supervisor

Displays the URL/directory from where the switch can access the Device Manager auxiliary files (for example help files).

The syntax for this command is:

```
show web aux-files-url
```

Example:

```
C360-N> show web aux-files-url  
the web aux-files-url is 149.49.36.212/P330test
```

stack health

User level: privileged, supervisor

Use the `stack health` command to test the integrity of stacking modules and cables.

- You can only run this command on a stack.
- The stack is reset once the command has been executed.
- You should not load the stack with traffic during this test.
- Please follow the instruction shown on the CLI screen, during the various stages of this test.

The syntax for this command is:

```
stack health
```

Example:

```
C360-N> stack health  
  
This operation will eventually result in a Stack reset.  
- do you want to continue (Y/N)? y  
  
Start testing stack health....  
This test will take a few minutes!!  
The stack health test was completed successfully
```

sync time

User level: privileged, supervisor.

Use the `sync time` command to synchronize the time used by all modules in the switch.

The syntax for this command is:

```
sync time
```

Example:

```
C360-N# sync time
Time has been distributed.
```

tech

User level: supervisor

NOTE:

This command is reserved for service personnel use only.

Use the `tech` command to enter tech mode.

telnet

User level: user, privileged, supervisor

Use the `telnet` command to open a Telnet session to a remote host.

The syntax for this command is:

```
telnet <ip-address> [<port-num>]
```

ip-address	The IP address of the remote host.
port-num (Optional)	The port number over which to open the Telnet connection.

Example:

```
C360-N> telnet 149.22.38.127
```

terminal length

User level: user, privileged, supervisor

Use the `terminal length` command to display or set the length screen length in characters.

The syntax for this command is:

`terminal length [<screen-length>]`

screen-length	<ul style="list-style-type: none"> • none – display the current value • length: 3 to 200
---------------	--

Example:

```
C360-N> terminal length 24
terminal length: 24
```

terminal width

User level: user, privileged, supervisor

Use the `terminal width` command to display or set the screen width.

The syntax for this command is:

`terminal width [<screen-width>]`

screen-width	<ul style="list-style-type: none"> • none – display the current value • width: 10 to 200
--------------	--

Example:

```
C360-N> terminal width
terminal width: 80 (auto-detected)
```

tree

User level: user, privileged, supervisor

Use the `tree` command to display a list of CLI commands available at the current user level.

The syntax for this command is:

`tree [<depth>]`

depth	Depth of CLI commands displayed
-------	---------------------------------

Example:

```
C360-N> tree 1
> clear cam
> clear log
> clear screen
> clear timezone
> clear vlan
> configure
> dir
> disconnect ssh
> get time
> hostname
> ip http
> ip ssh
> ip telnet
> ip telnet-client
> no hostname
> no username
> nvram initialize
> ping
> reset
> reset mcp
> reset powerinline
> reset stack
> reset wan
--type q to quit or space key to continue--
```

username

User level: supervisor

Use the `username` command to add a local user account.

NOTE:

By default there is only a single user account, named "root", with password "root", which access the administrator level. You cannot delete this basic user account, nor can you modify its access level, but you can modify its basic password.

The syntax for this command is:

```
username <name> password <passwd> access-type {read-only|read-write|admin}
```

Use the `no username` command to remove a local CLI user account.

The syntax for this command is:

```
no username <name>
```

name	New user name (minimum four characters)
passwd	User's password (minimum four characters)
access-type	Access type definition - read only, read-write or administrator

Example:

```
C360-1(super)# username john password johnny access-type read-
write
User account added.

C360-1(super)# username root password secret access-type read-
write
ERROR: User account root has always an administrator access type.

C360-1(super)# username root password secret access-type admin
User account modified.
```

NOTE:

If you wish to define a name which includes spaces, you must enclose the entire name in quotation marks, for example "new york".

NOTE:

You cannot delete the default user account "root".

3 Avaya C360 Layer 3 CLI Commands

This chapter provides all the Layer 3 CLI (Command Line Interface) commands, parameters, and their default values.

area

User level: privileged, supervisor.

NOTE:

You can only access this command in the “Router-OSPF” context.

Type **router ospf** at the command prompt to enter the “Router -OSPF” context if necessary.

Use the `area` command to configure the area ID of the router.

Use the `no area` command to deleted the area ID of the router (set it to 0) and remove the stub definition.

The default area is **0.0.0.0**.



Tip:

You cannot define a stub area when OSPF is redistributing other protocols or when the Area ID is 0.0.0.0.

The syntax for this command is:

```
[no] area <area id> [<stub>]
```

area id	IP address
stub	Stub

Example:

```
Router-N(configure router:ospf)# area 192.168.49.1
Router-N(configure router:ospf)# area 192.168.49.1 stub
```

arp

User level: privileged, supervisor.

NOTE:

If you are at the “privileged” level, you can only access this command in Configure mode.

Type **configure** at the command prompt to enter configure mode.

Use the `arp` command to add a permanent entry to the Address Resolution Protocol (ARP) cache.

Use the `no arp` command to remove an entry, either static entry or dynamically learned.

The syntax for this command is:

```
[no] arp <ip-address> <mac-address>
```

ip-address	IP address, in dotted decimal format, of the station
mac-address	MAC address of the local data link

Example:

To add a permanent entry for station 192.168.7.8 to the ARP cache:

```
Router-N(configure)# arp 192.168.7.8 00:40:0d:8c:2a:01
```

Example:

To remove an entry to the ARP cache for the station 192.168.13.76:

```
Router-N(configure)# no arp 192.168.13.76
```

arp timeout

User level: privileged, supervisor.

NOTE:

If you are at the "privileged" level, you can only access this command in Configure mode. Type **configure** at the command prompt to enter configure mode.

Use the `arp timeout` command to set the amount of time that an entry remains in the ARP cache.

Use the `no arp timeout` command to restore the default value, 14,400.

The syntax for this command is:

```
[no] arp timeout <seconds>
```

seconds	The amount of time, in seconds, that an entry remains in the arp cache.
---------	---

Example:

To set the arp timeout to one hour:

```
Router-N(configure)# arp timeout 3600
```

To restore the default arp timeout:

```
Router-N(configure)# no arp timeout
```

clear arp-cache

User level: privileged, supervisor.

NOTE:

If you are at the "privileged" level, you can only access this command in Configure mode. Type **configure** at the command prompt to enter configure mode.

Use the `clear arp-cache` command to delete dynamic entries from the ARP cache and the IP route cache.

The syntax for this command is:

```
clear arp cache [<vlan> | <ip addr> [<mask>]]
```

vlan	VLAN string (up to 16 characters)
ip addr	IP address
mask	IP mask

Example:

```
Router-N(configure)# clear arp-cache
Flushing all arp entries
Flushed 100 ARP entries
Done!
```

clear fragment

User level: privileged, supervisor.

Use the `clear fragment` command to restore fragment action database defaults and free all waiting fragments.

The syntax for this command is:

```
clear fragment
```

Example:

```
Router-N# clear fragment

Done!
```

clear ip route

User level: privileged, supervisor.

Use the `clear ip route` command to delete one or all of the dynamic routing entries from the Routing Table (RIP only).

The syntax for this command is:

```
clear ip route * | <ip-addr> [<ip-mask>]
```

*	Clears the entire ip routing table
ip-addr	IP address
ip-mask	IP mask address

Example:

```
Router-N# clear ip route 192.168.49.1 255.255.255.0
```

clear ip traffic

User level: privileged, supervisor.



Tip:

This command does not apply to the P333R-LB.

Use the `clear ip traffic` command to clear the ip traffic statistics counters.

The syntax for this command is:

```
clear ip traffic
```

Example:

```
Router-N# clear ip traffic
```

clear screen

User level: user, privileged, supervisor

Use the `clear screen` command to clear the screen.

The syntax for this command is:

```
clear screen
```

clear vlan

User level: privileged, supervisor.

NOTE:

If you are at the "privileged" level, you can only access this command in Configure mode. Type **configure** at the command prompt to enter Configure mode if necessary.

Use the `clear vlan` command to delete a Router layer 3 VLAN.

The syntax for this command is:

```
clear vlan [<ifIndex>] | [name <ifname>]
```

ifIndex	VLAN number
ifname	VLAN name

Example:

```
Router-N(configure)# clear vlan 2 name vlan2
```

NOTE:

If you wish to enter a name which includes spaces, you must enclose the entire name in quotation marks, for example "new york".

configure

User level: privileged, supervisor.

Use the `configure` command to enter configure mode.

The syntax for this command is:

```
configure
```

Example:

```
Router-N(super)# configure  
Router-N(configure)#
```

copy running-config scp

User level: privileged, supervisor.

Use the `copy running-config scp` command to upload the current switch-level parameters from the current NVRAM running configuration into a file via SCP.

The syntax for this command is:

```
copy running-config scp <filename> <ip> <mod_num>
```

filename	The file name (full path)
ip	The IP address of the SCP server
mod-num	The switch number

Example:

```
Router-N# copy running-config scp c:\config\switch1.cfg 192.168.49.10 5
Beginning upload operation ...
This operation may take a few minutes...
Please refrain from any other operation during this time.
For more information , use 'show upload status' command

*****
* If you are currently running the C360 Device Manager application,*
* it is recommended to exit from it before performing configuration*
* download operations.                                           *
*****
```

copy running-config startup-config

User level: privileged, supervisor.

Use the `copy running-config startup-config` command to save the policy and router configurations to the startup configuration file in the NVRAM.

The syntax for this command is:

```
copy running-config startup-config
```

Example:

```
Router-N(super)# copy running-config startup-config
Beginning copy operation ...
This operation may take up to 20 seconds.
Please refrain from any other operation during this time.
For more information , use 'show copy status' command
```

copy running-config tftp

User level: privileged, supervisor.

Use the `copy running-config tftp` command to upload the active policy and router configurations to a TFTP server.

The syntax for this command is:

```
copy running-config tftp <filename> <ip>
```

filename	Destination file name in the tftp server (full path).
ip	The ip address of the tftp server.

Example:

```
Router-N(super)# copy running-config tftp c:\C360\startup.cfg
149.49.100.41
```

Example: (for Unix):

```
Router-N(super)# copy running-config tftp
/folder/C360/startup.cfg 149.49.100.41
```

copy scp startup-config

User level: privileged, supervisor.

Use the `copy scp startup-config` command to download a startup configuration to the device via SCP.

NOTE:

Only parameters that differ from the factory default settings for the switch are included in the configuration file. Therefore, it is important to reinitialize the NVRAM to the factory default settings before downloading configuration files to the switch. To reinitialize the NVRAM, run the `nvr initialize` command.

The syntax for this command is:

```
copy scp startup-config <filename> <ip>
```

filename	Source file name on the SCP server (full path).
ip	The ip address of the SCP server.

Example: (for Windows)

```
Router-N# copy scp startup-config c:\C360\startup.cfg
149.49.100.41
```

Example: (for Unix):

```
Router-N# copy scp startup-config /folder/C360/startup.cfg
149.49.100.41
```

copy startup-config scp

User level: privileged, supervisor.

Use the `copy startup-config scp` command to upload the switch-level startup configuration from the active bank into a file via SCP.

The syntax for this command is:

```
copy startup-config scp <filename> <ip> <mod_num>
```

filename	The file name (full path)
ip	The IP address of the SCP server
mod-num	The switch number

Example:

```
Router-N# copy startup-config scp c:\config\switch1.cfg
192.168.49.10 5

Beginning upload operation ...

This operation may take a few minutes...

Please refrain from any other operation during this time.

For more information , use 'show upload status' command

*****

* If you are currently running the C360 Device Manager application,*
* it is recommended to exit from it before performing configuration*
* download operations.                                           *

*****
```

copy startup-config tftp

User level: privileged, supervisor.

Use the `copy startup-config tftp` command to upload the policy and router startup configurations to a TFTP server.

The syntax for this command is:

```
copy startup-config tftp <filename> <ip>
```

filename	Destination file name in the tftp server (full path).
ip	The ip address of the tftp server.

Example:

```
Router-N(super)# copy startup-config tftp c:\C360\startup.cfg
149.49.100.41
```

Example: (for Unix):

```
Router-N(super)# copy startup-config tftp /folder/C360/startup.cfg
149.49.100.41
```

copy tftp startup-config

User level: privileged, supervisor.

Copies the policy and router configurations from the saved TFTP file to the Startup Configuration file in the NVRAM.

NOTE:

Only parameters that differ from the factory default settings for the switch are included in the configuration file. Therefore, it is important to reinitialize the NVRAM to the factory default settings before downloading configuration files to the switch. To reinitialize the NVRAM, run the `nvr initialize` command.

The syntax for this command is:

```
copy tftp startup-config <filename> <ip>
```

filename	file name (full path)
ip	The ip address of the host

Example:

```
Router-N> copy tftp startup-config c:\C360\router1.cfg
192.168.49.10
```

default-metric

User level: privileged, supervisor.



Tip:

You can only access this command in interface mode.

Type **interface [name]** at the command prompt to enter interface mode if necessary.

Use the `default metric` command to set the interface RIP route metric.

Use the `no default metric` command to restore the default value.

The default metric is 1.

The syntax for this command is:

```
[no] default-metric <number>
```

number	The interface RIP route metric value. The range is 1 to 15.
--------	---

Example:

```
Router-N(configure-if:marketing) # default metric 10
Done!
```

disconnect ssh

User level: supervisor

Use the `disconnect ssh` command to disconnect an SSH session.

The syntax for this command is:

```
disconnect ssh <session-id>
```

session-id	The SSH session ID. Use the <code>show ssh</code> command to learn an SSH session ID.
------------	---

Example:

```
Router-N(super)# disconnect ssh 0x508622f0

You are about to close this session - do you want to continue
(Y/N)? y

Closing session 0x508622f0
```

enable vlan commands

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface [name]** at the command prompt to enter interface mode if necessary.

Use the `enable vlan commands` command before configuring VLAN-oriented parameters, such as vrrp and boorp-dhcp relay that affect all interfaces on the same VLAN.

The syntax for this command is:

```
enable vlan commands
```

Example:

```
Router-N(config-if:marketing)# enable vlan commands
```

erase startup-config

User level: privileged, supervisor.

Use the `erase startup-config` command to clear the startup configuration.

The syntax for this command is:

```
erase startup-config
```

Example:

```
Router-N# erase startup-config  
Beginning erase operation ...  
This operation may take up to 20 seconds.  
Please refrain from any other operation during this time.  
For more information , use 'show erase status' command
```

event log

User level: user, privileged, supervisor

Use the `event log` command to display a list of the event messages.

NOTE:

The event messages shown are encrypted and are reserved for Avaya use only.

The syntax for this command is:

```
event log [<num>]
```

num	Number of event messages to display (max=30)
-----	--

Example:

```
Marketing-1# event log
The following message is for internal use only!!!

Z,o(9?+.ig?aDZ_Z0"Dw"ZHlJZZ,300R3333aDZt?(Z
Zt?(Z?qDZ?gXZ;z=WZYLd{z5^=}ZHt!Z^YYE
Z33D@3D3YDRTDQTD3wZ'E~MZw@T:@T: @_:_QZ~NZz'oYPZw
Z,o(9?+.ig?aDZ"Z0"D3"ZHlJZZ,300R3333aDZt?(Z
Zt?(Z?qDZ?gXZ;z=WZYLd{z5^=}ZHt!Z^YYE
Z33D@3D3YDRTDQTD3wZ'E~MZw@T:@T: @_:_QZ~NZz'oYPZw
Z,=H^zNaDZ0Z3D33ZHlJZZ,303"3333aDZ?lU19ojoiz Z(""? A\Zlit?ign
Z,!AoaDZwZ0Q_D_QZHlJZZ,303w3333aDZgjKZ ZZ}>}N=Z{~/Z5{ }^E}Y
Done!
```

exit

User level: user, privileged, supervisor

Use the `exit` command to return to the previous context or disconnect from the switch.

The syntax for this command is:

```
exit
```

Example:

```
Router-N(configure router:rip)# exit
Router-N(configure)#
```

fragment chain

User level: privileged, supervisor.

Use the `fragment chain` command to set the maximum number of fragments that can comprise a single IP packet destined to the router.

Use the `no fragment chain` of this command to set the fragment chain to the default value (64).

NOTE:

The router does not perform reassembly of packets in transit.

The syntax for this command is:

```
[no] fragment chain <chain-limit>
```

chain-limit	The maximum number of fragments that can comprise a single IP packet, from 2 to 2048. The default is 64.
-------------	--

Example:

```
Router-N# fragment chain 30
```

fragment size

User level: privileged, supervisor.

Use the `fragment size` command to set the maximum number of fragmented IP packets, destined to the router, to reassemble at any given time.

Use the `no fragment size` command to set the fragment size to the default value (100).

NOTE:

The router does not perform reassembly of packets in transit.

The syntax for this command is:

```
[no] fragment size <database-limit>
```

database-limit	The maximum number of packets undergoing re-assembly at any given time, from 0 to 200. The default is 100.
----------------	--

Example:

```
Router-N# fragment size 150
```

fragment timeout

User level: privileged, supervisor.

Use the `fragment timeout` command to set the maximum number of seconds to reassemble a fragmented IP packet destined to the router.

Use the `no fragment timeout` command to set the fragment timeout to the default value (10).



Tip:

The router does not perform reassembly of packets in transit.

The syntax for this command is:

```
[no] fragment timeout <timeout>
```

timeout	The maximum number of seconds to re-assemble an IP packet, from 5 to 120. The default is 10.
---------	--

Example:

```
Router-N# fragment timeout 30
```

help

User level: user, privileged, supervisor

Use the `help` command to obtain help on CLI commands.

The syntax for this command is:

```
help <command>
```

command	A specific CLI command or group of commands
---------	---

Example:

```
Marketing-1# help ping
Ping commands:
-----
Syntax : ping <host> [<interval> [<size> [<timeout> [<source
address>]]]]
    <host>          - IP address
    <interval>      - interval in seconds(1-256)
    <size>          - integer(22-65500)
    <timeout>       - timeout in seconds(1-10)
    <source>        - IP address
Example: ping 192.168.49.1
ping 192.168.49.1 3
ping 192.168.49.1 3 50
ping 192.168.49.1 3 50 2
ping 192.168.49.1 3 50 2 192.168.49.4
```

hostname

User level: privileged, supervisor.

Use the `hostname` command to change the system prompt used for the router

Use the `no hostname` command to return the system prompt to its default.

This command does not change the system prompt of the switch. To change the system prompt of the switch, use the host name command in the Layer 2 tree.

The syntax for this command is:

```
[no] hostname [<hostname_string>]
```

hostname_string	The string to be used as the hostname (up to 20 characters). If you do not enter a string, the current hostname is displayed.
-----------------	--

Example:

```
Router-1# hostname Marketing
Marketing-1#
```

NOTE:

If you wish to enter a name which includes spaces, you must enclose the entire name in quotation marks, for example “new york”.

icmp in-echo-limit

User level: privileged, supervisor.

Use the `icmp in-echo-limit` command to set the number of echo requests per second that the router will reply.

Use the `no icmp in-echo-limit` command to restores the value to its default.

The syntax for this command is:

```
icmp in-echo-limit <size>
```

size	The rate of echo requests per second. Value range = 1 to 1000. Default = 50.
------	---

Example:

```
Router-N# icmp in-echo-limit 100
Done!
```

interface

User level: privileged, supervisor.

Use the `interface` command to create and enter the Interface Configuration Mode.

Use the `no interface` command to delete a specific IP interface.

The syntax for this command is:

```
[no] interface <interface name>
```

interface name	String (up to 32 characters). This name should not start with the letters "def".
----------------	--

Example:

```
Router-N(configure)# interface marketing
Done!
Router-1(config-if:marketing)#
```

NOTE:

If you wish to enter a name which includes spaces, you must enclose the entire name in quotation marks, for example "new york".

ip access-default-action

User level: *privileged, supervisor.*

NOTE:

If you are at the "read-write" user level, you can only access this command in Configure mode.

Type **configure** at the command prompt to enter configure mode if necessary.

Use the `ip access-default-action` command to set the default action for a specific policy list.

The syntax for this command is:

```
ip access-default-action <policy-list-number> [default-action]
```

<policy-list-number>	integer (100 - 149)
<default-action>	permit deny

Example:

```
Router-N(super)# ip access-default-action 101 default-action-deny
Done!
```

ip access-group

User level: *privileged, supervisor.*

NOTE:

If you are at the "read-write" user level, you can only access this command in Configure mode.

Type **configure** at the command prompt to enter configure mode if necessary.

Use the `ip access group` command to activate a specific policy list.

The syntax for this command is:

```
ip access-group <policy-list-number> [default-action]
```

<policy-list-number>	integer (100 - 149)
<default-action>	permit deny

Example:

```
Router-N(super)# ip access-group 101
Done!
```

ip access-list

User level: privileged, supervisor.

NOTE:

If you are at the "read-write" user level, you can only access this command in Configure mode.

Type **configure** at the command prompt to enter configure mode if necessary.

Use the `ip access list` command to create a specific policy rule. The access list contains several of these rules: each rule pertains to the source IP address, the destination IP address, the protocol, the protocol ports (if relevant), and to the ACK bit (if relevant).

Use the `no ip access list` command to delete a specific rule.

The syntax for this command is:

```
[no] ip access-list <access-list-number> <access-list-index>
      <command> <protocol> {<source-ip>
      <source-wildcard> | any |host
      <source-ip>}[<operator> <port> [<port>]]
      {<destination-ip> <destination-
      wildcard>|any |host
      <destination-ip>}[<operator> <port>
      [<port>]][established] [precedence]
```

access-list-number	integer (100 - 149)
access-list-index	integer (1 - 9999)
command	permit deny deny-and-notify fwd0-7
protocol	ip tcp udp integer (1 - 255)
source-ip	ip network
source-wildcard	ip network wildcard
operator	eq lt gt range
port	integer (1 - 65535)
destination-ip	ip network
destination-wildcard	ip network wildcard
precedence	mandatory optional

Example:

```
Router-N# ip access-list 101 23 deny ip any
1.2.0.0 0.0.255.255
```

ip access-list-cookie

User level: privileged, supervisor.

NOTE:

If you are at the "read-write" user level, you can only access this command in Configure mode.

Type **configure** at the command prompt to enter configure mode if necessary.

Use the `ip access-list-cookie` command to set the list cookie for a specific policy list.

The syntax for this command is:

```
ip access-list-cookie <policy-list-number> <cookie>
```

policy-list-number	integer (100 - 149). 0 is the default list
cookie	integer

Example:

```
Router-N(super)# ip access-list-cookie 101 12345
```

ip access-list-copy

User level: privileged, supervisor.

NOTE:

If you are at the "read-write" user level, you can only access this command in Configure mode.

Type **configure** at the command prompt to enter configure mode if necessary.

Use the `ip access-list-copy` command to copy a configured source policy list to a destination policy list.

The syntax for this command is:

```
ip access-list-copy <source-list> <destination-list>
```

source-list	integer (100 - 149)
destination-list	integer (100 - 149)

Example:

```
Router-N(super)# ip access-list-copy 100 101
```

ip access-list-dscp name

User level: privileged, supervisor.

NOTE:

If you are at the "read-write" user level, you can only access this command in Configure mode.

Type **configure** at the command prompt to enter configure mode if necessary.

Use the `ip access-list-dscp name` command to set a DSCP name

The syntax for this command is:

```
ip access-list-dscp name <policy-list-number> <dscp> <name>
```

policy-list-number	A valid id number for a policy list currently defined for the module (100 - 149)
dscp	Range of dscp. For example: <dscp-range> : [0 - 63] <low-dscp>-<high-dscp> <low-dscp>-<low-dscp>: apply the map to all packets with DSCP from <low-dscp> to <high-dscp>.
name	The name

Example:

```
Router-N(configure)# ip access-list-dscp name 101 1 Lincroft
Done!
```

ip access-list-dscp operation

User level: privileged, supervisor.

NOTE:

If you are at the "read-write" user level, you can only access this command in Configure mode.

Type **configure** at the command prompt to enter configure mode if necessary.

Use the `ip access-list-dscp operation` command to set a DSCP to CoS mapping.

The syntax for this command is:

```
ip access-list-dscp operation <policy-list-number> <dscp> <action>
```

policy-list-number	A valid id number for a policy list currently defined for the module (100 - 149)
--------------------	--

dscp	Range of dscp. For example: <dscp-range> : [0 - 63] <low-dscp>-<high-dscp> <low-dscp>-<low-dscp>: apply the map to all packets with DSCP from <low-dscp> to <high-dscp>.
action	<action> = permit deny deny-and-notify fwd0 fwd1 - fwd7 <ul style="list-style-type: none"> • permit: do nothing, let the packet pass: • deny: drop the packet • deny-and-notify: drop the packet and send an SNMP trap • fwd0, fwd1fwd7: Set the frame COS field to 0,7

Example:

```
Router-N(configure)# ip access-list-dscp operation 101 0-63 permit
Router-N(configure)# ip access-list-dscp operation 101 62 fwd5
```

ip access-list-dscp trust

User level: privileged, supervisor.

NOTE:

If you are at the "read-write" user level, you can only access this command in Configure mode.

Type **configure** at the command prompt to enter configure mode if necessary.

Use the `ip access-list-dscp trust` command to decide which original frame fields influence the selection of packet priority.

The syntax for this command is:

```
ip access-list-dscp trust <policy-list-number> {untrusted|trust-cos |trust-dscp}
```

policy-list-number	A valid id number for a policy list currently defined for the switch (100 to 149)
untrusted	Forward the packet with priority 0
trust-cos	Forward the packet with its original 802.1p priority (default)
trust-dscp	Forward the packet with the maximum priority between 802.1p and the priority obtained from the DSCP-CoS mapping table

Example:

```
Router-N(super)# ip access-list-dscp trust 100 trust-dscp
Done!
```

ip access-list-name

User level: privileged, supervisor.

NOTE:

If you are at the "read-write" user level, you can only access this command in Configure mode.

Type **configure** at the command prompt to enter configure mode if necessary.

Use the `ip access-list-name` command to set a name for a policy list.

The syntax for this command is:

```
ip access-list-name <policy-list-number> <name>
```

<policy-list-number>	integer (100 - 149)
<name>	list name

Example:

```
Router-N(super)# ip access-list-name 101 morning
```

NOTE:

If you wish to enter a name which includes spaces, you must enclose the entire name in quotation marks, for example "new york".

ip access-list-owner

User level: privileged, supervisor.

NOTE:

If you are at the "read-write" user level, you can only access this command in Configure mode.

Type **configure** at the command prompt to enter configure mode if necessary.

Use the `ip access-list owner` command to set the owner for a specific policy list.

The syntax for this command is:

```
ip access-list-owner <policy-list-number> <owner>
```

<policy-list-number>	integer (100 - 149)
<owner>	list owner

Example:

```
Router-N(configure)# ip access-list-owner 101 admin
Done!
```

ip address

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface [name]** at the command prompt to enter interface mode if necessary.

Use the `ip address` command to assign an IP address and mask to an interface.

The syntax for this command is:

```
ip address <ip-address> <mask> [<admin-state>]
```

ip address	The IP address assigned to the interface.
mask	Mask for the associated IP subnet
admin-state	The administration status – either Up or Down

Example:

To assign the IP address 192.168.22.33 with mask 255.255.255.0 to the interface “marketing”:

```
Router-N(config-if:marketing)# ip address 192.168.22.33
255.255.255.0
Done!
```

ip admin-state

User level: privileged, supervisor.



Tip:

You can only access this command in interface mode.

Type **interface [name]** at the command prompt to enter interface mode if necessary.

Use the `admin-state` command to set the administrative state of an IP interface. The default state is up.

The syntax for this command is:

```
ip admin-state <up/down>
```

up/down	Administrative state of the interface. The choices are <ul style="list-style-type: none"> • up (active) or • down (inactive).
---------	--

Example:

```
Router-N(config-if:marketing)# ip admin-state up
```

ip bootp-dhcp network

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface** [name] at the command prompt to enter interface mode if necessary.

Use the `ip bootp-dhcp network` command to configure the network from which the BOOTP/DHCP server shall allocate an address.

Use the `no ip bootp-dhcp network` command to remove a network.

NOTE:

Multiple networks can be configured and relayed per VLAN, by repeating the `ip bootp-dhcp network` command. If more than one network is configured, then the address allocation is based on a round-robin algorithm.

The syntax for this command is:

```
[no] ip bootp-dhcp network <ip-net>
```

ip-net	The IP address of the network.
--------	--------------------------------

Example:

To select the network 192.168.169.0 as the network from which an address shall be allocated for bootp/dhcp requests:

```
Router-N(configure-if:marketing)# ip bootp-dhcp network
192.168.169.0
Done!
```

ip bootp-dhcp relay

User level: privileged, supervisor.

NOTE:

You can only access this command in Interface mode.

Type **interface** [name] at the command prompt to enter Interface mode if necessary.

The `ip bootp-dhcp` command enables relaying of bootp and dhcp requests to the bootp/dhcp server.

The `no ip bootp-dhcp` command disables bootp/dhcp relay.

The default state is disabled.

The syntax for this command is:

```
[no] ip bootp-dhcp relay
```

Example:

To enable relaying of BOOTP and DHCP requests:

```
Router-N(super)# ip bootp-dhcp relay
Done!
```

To disable relaying of bootp and dhcp requests:

```
Router-N(super)# no ip bootp-dhcp relay
Done!
```

ip bootp-dhcp server

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface [name]** at the command prompt to enter interface mode if necessary.

Use the `ip bootp-dhcp server` command to add a bootp/dhcp server to handle BOOTP/DHCP requests received by this interface.

Use the `no ip bootp-dhcp server` command to remove the server. A maximum of two servers can be added to a single interface.

The syntax for this command is:

```
ip bootp-dhcp server <ip addr>
```

ip addr	The IP address of the server.
---------	-------------------------------

Example:

To add station 192.168.37.46 as a bootp/dhcp server to handle bootp/dhcp requests arriving at the interface “marketing”:

```
Router-N(configure-if:marketing) # ip bootp-dhcp server
192.168.37.46
Done!
```

ip broadcast-address

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface** [**name**] at the command prompt to enter interface mode if necessary.

Use the `ip broadcast` command to update the interface broadcast address. The Broadcast address must be filled in with 0s (zeros) or 1s (ones).

The syntax for this command is:

```
<bc addr>
```

bc addr	The broadcast IP address
---------	--------------------------

Example:

```
Router-N(config-if:marketing)# ip broadcast address
192.168.255.255
```

ip default-gateway

User level: privileged, supervisor.

NOTE:

If you are at the “read-write” user level, you can only access this command in Configure mode.

Type **configure** at the command prompt to enter configure mode.

Use the `ip default-gateway` command to define a default gateway (router).

Use the `no ip default gateway` command to remove the default gateway.

The syntax for this command is:

```
[no] ip default-gateway <ip-address>[<cost>][<preference>]
```

ip-address	The IP address of the router.
cost	The path cost. The default is 1
preference	Preference, either High or Low. Default is Low.

Example:

To define the router at address 192.168.37.1 as the default gateway:

```
Router-N(configure)# ip default-gateway 192.168.37.1
```

ip directed-broadcast

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface [name]** at the command prompt to enter interface mode if necessary.

Use the `ip directed-broadcast` command to enable net-directed broadcast forwarding.

Use the `no ip directed-broadcast` command to disables net-directed broadcasts on an interface.

The syntax for this command is:

```
[no] ip directed-broadcast
```

Example:

```
Router-N(config-if:marketing)# ip directed broadcast
```

ip icmp-errors

User level: privileged, supervisor.

NOTE:

If you are at the “read-write” user level, you can only access this command in Configure mode.

Type **configure** at the command prompt to enter configure mode.

Use the `icmp-error` command to turn ICMP error messages on.

Use the `no icmp-error` command to turn ICMP error messages off.

The syntax for this command is:

```
[no] ip icmp-errors
```

Example:

To turn the ICMP error messages on:

```
Router-N(super)# ip icmp-errors
Done!
```

ip max-arp-entries

User level: privileged, supervisor.

NOTE:

If you are at the “read-write” user level, you can only access this command in Configure mode.

Type **configure** at the command prompt to enter configure mode.

Use the `ip max-arp-entries` command to set the maximum number of ARP cache entries allowed in the ARP cache.

Use the `no ip max-arp-entries` command to restore the default value of 4096.

NOTE:

For this command to take effect, run the `copy running-config startup-config` command and reset the device.

The syntax for this command is:

```
[no] ip max-arp-entries <value>
```

value	The space available for the IP address table. When you decrease the number of entries, it may cause the table to be relearned more frequently. If you do not enter a value, then the current ARP Cache size is shown.
-------	---

Example:

To set the maximum number of ARP cache entries to 8000:

```
Router-N(super)# ip max-arp-entries 8000
```

To restore the maximum number of ARP cache entries to its default:

```
Router-N(super)# no ip max-arp-entries
```

ip max-route-entries

User level: privileged, supervisor.

NOTE:

If you are at the “privileged” level, you can only access this command in Configure mode. Type **configure** at the command prompt to enter configure mode.

The `ip max-route-entries` command exists for compatibility with Avaya™ P550. There is no limitation on the size of the routing table, except for the amount of available memory.

Use the `no ip max-route-entries` command to remove the limitation.

NOTE:

For this command to take effect, run the `copy running-config startup-config` command and reset the device.

The syntax for this command is:

```
[no] ip max-route-entries <value>
```

value	Number of entries
-------	-------------------

Example:

```
Router-N(configure)# ip max-route-entries 4000
```

ip netbios-rebroadcast

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface** [**name**] at the command prompt to enter interface mode if necessary.

Use the `ip netbios-rebroadcast` command to set the NETBIOS rebroadcasts mode on an interface.

Use the `no ip netbios-rebroadcast` command to disable NETBIOS rebroadcasts on an interface.

The syntax for this command is:

```
[no] ip netbios-rebroadcast [<direction>]
```

The possible values for direction are:

both	Netbios packets received on the interface rebroadcasted to other interfaces and netbios packets received on other interfaces are rebroadcasted into this interface. This is the default value.
disable	Netbios packets are not rebroadcasted into or out of this interface.

Example:

To enable rebroadcasting of netbios packets received by and sent from the interface “marketing”:

```
Router-N(config-if:marketing)# ip netbios-rebroadcast both
```

ip netmask-format

User level: privileged, supervisor.

NOTE:

If you are at the "privileged" level, you can only access this command in Configure mode. Type **configure** at the command prompt to enter configure mode.

Use the `ip netmask-format` command to specify the format of netmasks in the `show` command output.

Use the `no ip netmask-format` command to restores the default format which is a dotted decimal.

The syntax for this command is:

```
[no] ip netmask-format <mask-format>
```

The possible mask formats are:

bitcount	Addresses are followed by a slash and the total number of bits in the netmask. For example 17
decimal	The network masks are in dotted decimal notation. For example, 255.255.255.0.
hexadecimal	The network masks are in hexadecimal format as indicated by the leading 0X. For example, 0FFFFFFF00.

Example:

To display netmasks in decimal format:

```
Router-N(super)# ip netmask-format bitcount decimal
Done!
```

ip ospf authentication-key

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode. Type **interface** [**name**] at the command prompt to enter interface mode if necessary.

Use the `ip ospf authentication-key` command to configure the interface authentication password.

Use the `no ip ospf authentication-key` command to remove the OSPF password.

The syntax for this command is:

```
[no] ip ospf authentication-key <key>
```

key	string (up to 8 characters)
-----	-----------------------------

Example:

```
Router-N(configure-if:marketing) # ip ospf authentication-key
my_pass
```

ip ospf cost

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface** [**name**] at the command prompt to enter interface mode if necessary.

Use the `ip ospf cost` command to configure interface metric.

Use the `no ip ospf cost` command to set the cost to its default. The default is 1.

The syntax for this command is:

```
[no] ip ospf cost <cost>
```

cost	integer
------	---------

Example:

```
Router-N(configure-if:marketing) # ip ospf cost 10
Done!
```

ip ospf dead-interval

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface** [**name**] at the command prompt to enter interface mode if necessary.

Use the `ip ospf dead-interval` command to configure the interval before declaring the neighbor as dead.

Use `no ospf dead-interval` to set the dead-interval to its default value of 40.

The syntax for this command is:

```
[no] ip ospf dead-interval <seconds>
```

seconds	Time in seconds (integer value)
---------	---------------------------------

Example:

```
Router-N(configure-if:marketing) # ip ospf dead-interval 15
```

ip ospf hello-interval

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface** [**name**] at the command prompt to enter interface mode if necessary.

Use this command to specify the time interval between OSPF hello messages the router sends.

Use `no ip ospf hello-interval` to set the hello-interval to its default.

The default is 10.

The syntax for this command is:

```
[no] ip ospf hello-interval <seconds>
```

seconds	integer
---------	---------

Example:

```
Router-N(configure-if:marketing) # ip ospf hello-interval 5
Done!
```

ip ospf priority

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface** [**name**] at the command prompt to enter interface mode if necessary.

Use the `ip ospf priority` command to configure interface priority used in DR election.

Use the `no ip ospf priority` to set the OSPF priority to its default value.

The default is 1.

The syntax for this command is:

```
[no] ip ospf priority <priority>
```

priority	integer
----------	---------

Example:

```
Router-N(configure-if:marketing) # ip ospf priority 17
Done!
```

ip ospf router-id

User level: privileged, supervisor.

Use the `ip ospf router-id` command to configure the router identity.

Use the `no ip ospf router-id` command to return the router identity to its default (the lowest existing IP interface).

The syntax for this command is:

```
[no] ip ospf router-id <router id>
```

router-id	The IP address of the router.
-----------	-------------------------------

Example:

```
Router-N(super)# ip ospf router-id 192.168.49.1
```

ip proxy-arp

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface** [**name**] at the command prompt to enter interface mode if necessary.

Use the `ip proxy-arp` command to enable proxy ARP on an interface.

Use the `no ip proxy-arp` command to disable proxy ARP on an interface.

The syntax for this command is:

```
[no] ip proxy-arp
```

Example:

To disable proxy ARP on interface marketing:

```
Router-N(config-if:marketing)# no ip proxy arp
```

ip redirects

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface [name]** at the command prompt to enter interface mode if necessary.

Use the `ip redirects` command to enables the sending of redirect messages on the interface.

Use the `no ip redirect` command to disable the redirect messages. By default, sending of redirect messages on the interface is enabled.

The syntax for this command is:

```
[no] ip redirect
```

Example:

```
Router-N(config-if:marketing)# ip redirects
```

ip rip authentication key

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface [name]** at the command prompt to enter interface mode if necessary.

Use the `ip rip authentication key` command to set the authentication string used on the interface.

Use the `no ip rip authentication key` command to clear the password.

The syntax for this command is:

```
[no] ip rip authentication key <password>
```

password	The authentication string for the interface. Up to 16 characters are allowed.
----------	---

Example:

To set the authentication string used on the interface “marketing” to be “hush-hush”.

```
Router-N(configure-if:marketing) # ip rip authentication key hush-hush
```

ip rip authentication mode

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface [name]** at the command prompt to enter interface mode if necessary.

Use the `ip rip authentication` command to specify the type of authentication used in RIP Version 2 packets.

Use the `no ip rip authentication` command to restore the default value of none.

The syntax for this command is: `[no] ip rip authentication mode [simple|none]`

simple none	The authentication type used in RIP Version 2 packets: <ul style="list-style-type: none"> • simple - clear text authentication. • none - no authentication.
-------------	---

Example:

To specify simple authentication to be used in RIP Version 2 packets on the interface “marketing”.

```
Router-N(configure-if:marketing)# ip rip authentication mode simple
```

ip rip default-route-mode

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface [name]** at the command prompt to enter interface mode if necessary.

Use the `ip rip default-route-mode` command to enable learning of the default route received by the RIP protocol. The default state is talk-listen.

Use the `no ip rip default-route-mode` command to disable learning of the default route.

The syntax for this command is:

```
ip rip default-route-mode <mode>
```

The possible default route modes on an interface are:

talk-listen	Set RIP to send and receive default route updates on the interface.
talk-only	Set RIP to send but not receive default route updates on the interface.

Example:

```
Router-N(configure-if:marketing) # ip rip default-route-mode talk
listen
Done!
```

ip rip poison-reverse

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface [name]** at the command prompt to enter interface mode if necessary.

Use the `ip rip poison-reverse` command to enable split-horizon with poison-reverse on an interface.

Use the `no ip poison-reverse` command to disable the poison-reverse mechanism.

The split-horizon technique prevents information about routes from exiting the router interface through which the information was received. This prevents routing loops.

Poison reverse updates explicitly indicate that a network or subnet is unreachable rather than implying they are not reachable. Poison reverse updates are sent to defeat large routing loops.

The syntax for this command is:

```
[no] ip rip poison-reverse
```

Example:

```
Router-N(configure-if:marketing)# ip rip poison-reverse
Done!
```

ip rip rip-version

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface [name]** at the command prompt to enter interface mode if necessary.

Use the `ip rip rip-version` command to specify the RIP version running on the interface basis.

The syntax for this command is:

```
ip rip rip-version <version>
```

The possible versions of the RIP packets received and sent on an interface are:

1	RIP Version 1 packets
2	RIP Version 2 packets.

Example:

To specify that RIP version 2 should be running on the basis of the interface “marketing”:

```
Router-N(configure-if:marketing)# ip rip rip-version 2
Done!
```

ip rip send-receive-mode

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface** [**name**] at the command prompt to enter interface mode if necessary.

Use the `ip rip send-receive` command to set the RIP Send and Receive mode on an interface. The default state is **talk-listen**.

The syntax for this command is:

```
ip rip send-receive-mode <mode>[<default route metric>]
```

mode	talk-listen - Set RIP to receive and transmit updates on the interface.
	talkdefault-listen - Set RIP to receive updates on the interface and send only a default route.
	listen-only – Set RIP to only receive updates on the interface and not transmit them.
default route metric	Integer value

Example:

To set the RIP Send and Receive mode on the interface “marketing” to be listen-only:

```
Router-N(configure-if:marketing)# ip rip send-receive-mode
listen-only
Done!
```

ip rip split-horizon

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface** [**name**] at the command prompt to enter interface mode if necessary.

Use the `ip rip split-horizon` command to enable split-horizon mechanism. Use the `no ip rip split-horizon` command to disable the split-horizon.

By default split-horizon is enabled.

The split-horizon technique prevents information about routes from exiting the router interface through which the information was received. This prevents routing loops.

The syntax for this command is:

```
[no] ip rip split-horizon
```

Example:

```
Router-N(configure-if:marketing)# no ip rip split-horizon
Done!
```

ip route

User level: privileged, supervisor.

NOTE:

If you are at the "privileged" level, you can only access this command in Configure mode. Type **configure** at the command prompt to enter configure mode.

Use the `ip route` command to establish a static route.

Use the `no ip route` command to remove a static route.

You can edit (add or remove), individually, each one of the three possible next-hop addresses for a static route.

The syntax for this command is:

```
[no] ip route <ip-address> <mask> <next-hop> [<next-hop>] [<next-hop>]
[<cost>] [<preference>]
```

ip-address	The IP address of the network
mask	Mask of the static route
next-hop	The next hop address in the network
cost	The path cost. The default is 1
preference	Preference, either High or Low. Default is Low.

Example:

To define the router 192.168.33.38 as the next hop for the network 192.168.33.0 with mask 255.255.255.0:

```
Router-N(super)# ip route 192.168.33.0 255.255.255.0 10.10.10.10
```

ip routing

User level: privileged, supervisor.

NOTE:

If you are at the "privileged" level, you can only access this command in Configure mode. Type **configure** at the command prompt to enter configure mode.

Use the `ip routing` command to enable IP routing.

Use the `no ip routing` command to disable the IP routing process in the device. By default, IP routing is enabled.

The syntax for this command is:

```
[no] ip routing
```

Example:

```
Router-N(super)# ip routing
Done!
```

ip routing-mode

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode. Type **interface [name]** at the command prompt to enter interface mode if necessary.

Use the `ip routing-mode` command to set the IP routing mode of the interface. In RT-MGMT mode, the interface functions as a routing interface. In RT_PRIMARY_MGMT mode, the interface function as both a routing interface and the primary management interface.

The IP address used in MSNM is the primary management interface IP address. Only one interface can be in RT_PRIMARY_MGMT mode. If no interface is configured to RT_PRIMARY_MGMT, the IP address used in MSNM is selected randomly.

The syntax for this command is:

```
ip routing-mode <mode>
```

mode	RT_MGMT or RT_PRIMARY_MGMT mode
------	---------------------------------

Example:

```
Router-N(config-if:marketing)# ip routing-mode RT_PRIMARY_MGMT
```

ip simulate

User level: privileged, supervisor.

NOTE:

If you are at the "privileged" level, you can only access this command in Configure mode. Type **configure** at the command prompt to enter Configure mode if necessary.

Use the `ip simulate` command to check the policy for a simulated packet. The command contains the addressed list number, and the packet parameters.

The syntax for this command is:

```
ip simulate <access-list-number> [<priority>] [<dscp-value>]<source> <destination> [<protocol>
[<source port> <destination port> [<established>]]]
```

access-list-number	integer (100 - 149, 0 is the default list)
priority	fwd0 fwd1 - fwd7
dscp value	dscp0 dscp1 - dscp63
source	source ip address
destination	destination ip address
protocol	ip tcp udp integer (1 - 255)
source port	integer (1 - 65535)
destination port	integer (1 - 65535)
established	value of TCP established bit

Example:

```
Router-N(super)# ip simulate 100 192.67.85.12 193.76.54.25
```

ip vlan/ip vlan name

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode. Type **interface [name]** at the command prompt to enter interface mode if necessary.

Use the `ip vlan` and `ip vlan name` commands to specify the VLAN on which an IP interface resides. You can specify either the VLAN ID using the `ip vlan` command or the VLAN name using the `ip vlan name` command.

The `no ip vlan` or `no ip vlan name` command to reset the IP interface to the default VLAN.

The syntax for this command is:

```
[no] ip vlan <vlan-id>
```

or

```
ip vlan name <vlan-Name>
```

Example:

To specify VLAN developmental as the VLAN used by interface “products”:

```
Router-N(config-if:marketing)# ip vlan name development
```

NOTE:

If you wish to enter a name which includes spaces, you must enclose the entire name in quotation marks, for example “new york”.

ip vrrp

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface [name]** at the command prompt to enter interface mode if necessary.

Use the `ip vrrp` command to create a virtual router on the interface.

Use the `no ip vrrp` command to delete a virtual router.

The syntax for this command is:

```
[no] ip vrrp <vr-id>
```

vr-id	Virtual Router ID (1-255)
-------	---------------------------

Example:

```
Router-N(configure-if:marketing)# ip vrrp 1
```

```
Done!
```

ip vrrp address

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface [name]** at the command prompt to enter interface mode if necessary.

Use the `ip vrrp address` command to assign an IP address to the virtual router.

Use the `no ip vrrp address` command to remove an IP address from a virtual router.

The syntax for this command is:

```
[no] ip vrrp <vr-id> address <ip-address>
```

vr-id	Virtual Router ID (1-255)
ip-address	The IP address to be assigned to the virtual router.

Example:

To assign address 10.0.1.2 to virtual router 1:

```
Router-N(configure-if:marketing)# ip vrrp 1 address 10.0.1.2
Done!
```

ip vrrp auth-key

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface [name]** at the command prompt to enter interface mode if necessary.

Use the `ip vrrp auth-key` command to set the virtual router simple password authentication for the virtual router ID.

Use the `no ip vrrp auth-key` command to disable simple password authentication for the virtual router instance.

The syntax for this command is:

```
[no] ip vrrp <vr-id> auth-key <key-string>
```

vr-id	Virtual Router ID (1-255)
key-string	Simple password string.

Example:

To assign “secret” as the simple password for virtual router 1:

```
Router-N(configure-if:marketing)# ip vrrp 1 auth-key secret
Done!
```

ip vrrp override addr owner

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface [name]** at the command prompt to enter interface mode if necessary.

Use the `ip vrrp override addr owner` command to accept packets addressed to the IP address(es) associated with the virtual router, such as ICMP, SNMP, and TELNET (if it is not the IP address owner).

Use the `no ip vrrp override addr owner` command to discard these packets.

The syntax for this command is:

```
[no] ip vrrp <vr-id> override addr owner
```

vr-id	Virtual Router ID (1-255)
-------	---------------------------

Example:

```
Router-N(configure-if:marketing)# ip vrrp 1 override addr owner
Done!
```

ip vrrp preempt

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface [name]** at the command prompt to enter interface mode if necessary.

Use the `ip vrrp preempt` command to configure the router to preempt a lower priority master for the virtual router ID.

Use the `no ip vrrp preempt` command to disable preemption for the virtual router instance.

By default, preemption is enabled.

The syntax for this command is:

```
[no] ip vrrp <vr-id> preempt
```

vr-id	Virtual Router ID (1-255)
-------	---------------------------

Example:

```
Router-N(configure-if:marketing)# ip vrrp 1 preempt
Done!
```

ip vrrp primary

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface [name]** at the command prompt to enter interface mode if necessary.

Use the `ip vrrp primary` command to set the primary address that shall be used as the source address of VRRP packets for the virtual router ID.

Use the `no ip vrrp primary` command to return to the default primary address for the virtual router instance.

By default, the primary address is selected automatically by the device.

The syntax for this command is:

```
[no] ip vrrp <vr-id> primary <ip-address>
```

vr-id	Virtual Router ID (1-255)
ip-address	Primary IP address of the virtual router. This address should be one of the router addresses on the VLAN.

Example:

```
Router-N(configure-if:marketing)# ip vrrp 1 primary 192.168.66.23
Done!
```

ip vrrp priority

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface [name]** at the command prompt to enter interface mode if necessary.

Use the `ip vrrp priority` command to set the virtual router priority value used when selecting a master router.

Use the `no ip vrrp priority` command to restore the default value.

The syntax for this command is:

```
[no] ip vrrp <vr-id> priority <pri-value>
```

vr-id	Virtual Router ID (1-255)
pri-value	The priority value. The range is 1-254.

Example:

To set the priority value for virtual router 1 to ten:

```
Router-N(configure-if:marketing)# ip vrrp 1 priority 10
Done!
```

Example:

To set the virtual router simple password for virtual router 1 to abcd:

```
Router-N(configure-if:marketing)# ip vrrp 1 auth-key abcd
Done!
```

ip vrrp timer

User level: privileged, supervisor.

NOTE:

You can only access this command in interface mode.

Type **interface [name]** at the command prompt to enter interface mode if necessary.

Use the `ip vrrp timer` command to set the virtual router advertisement timer value (in seconds) for the virtual router ID.

Use `no ip vrrp timer` command to restore the default value.

The syntax for this command is:

```
[no] ip vrrp <vr-id> timer <value>
```

vr-id	Virtual Router ID (1-255)
value	The advertisement transmit time (seconds).

Example:

To set the virtual router advertisement timer value for virtual router 3 to 2:

```
Router-N(configure-if:marketing)# ip vrrp 3 timer 2
Done!
```

network (OSPF context)

User level: privileged, supervisor.

NOTE:

You can only access these command in the “Router-OSPF” context.

Type **router ospf** at the command prompt to enter the “Router -OSPF” context if necessary.

Use the `network` command to enable OSPF in this network.

Use the `no network` command to disable OSPF in this network.

The default is disabled.

The syntax for this command is:

```
network <net addr> [<wildcard-mask> [area <area id>]]
```

net addr	IP address
wildcard-mask	Wildcard mask address
area id	Area ID. This parameter exists for compatibility with P550.

Example:

```
Router-N(configure router:ospf)# network 192.168.0.0
Router-N(configure router:ospf)# area 192.168.0.0 0.0.255.255 area
0.0.0.0
```

network (RIP context)

User level: privileged, supervisor.

NOTE:

You can only access these commands in the “Router-RIP” context.

Type `router rip` at the command prompt to enter the “Router-RIP” context if necessary.

Use the `network` command to specify a list of networks on which the RIP is running.

Use the `no network` command to remove an entry.

The syntax for this command is:

```
[no] network <ip-address> [<wildcard-mask>]
```

ip addr	The IP address of the network of directly connected networks
wildcard-mask	Wildcard mask address. Exists for compatibility with P550.

Example:

To specify that RIP will be used on all interfaces connected to the network 192.168.37.0:

```
Router-N(configure router:rip)# network 192.168.37.0
Done!
```

no arp

See [arp](#) on page 177.

no arp timeout

See [arp timeout](#) on page 178.

no fragment chain

See [fragment chain](#) on page 189.

no fragment size

See [fragment size](#) on page 189.

no fragment timeout

See [fragment timeout](#) on page 190.

no hostname

See [hostname](#) on page 191.

no icmp in-echo-limit

See [icmp in-echo-limit](#) on page 192.

no interface

See [interface](#) on page 192.

no ip access-group

See [ip access-group](#) on page 193.

no ip access-list

See [ip access-list](#) on page 194.

no ip bootp-dhcp relay

See [ip bootp-dhcp relay](#) on page 200

no ip default-gateway

See [ip default-gateway](#) on page 202.

no ip icmp-errors

See [ip icmp-errors](#) on page 203.

no ip max-arp-entries

See [ip max-arp-entries](#) on page 204.

no ip max-route-entries

See [ip max-route-entries](#) on page 204.

no ip netmask-format

See [ip netmask-format](#) on page 206.

no ip ospf router-id

See [ip ospf router-id](#) on page 209.

no ip route

See [ip route](#) on page 214.

no ip routing

See [ip routing](#) on page 215.

no router ospf

See [router ospf](#) on page 228.

no router rip

See [router rip](#) on page 228.

no router vrrp

See [router vrrp](#) on page 229.

passive-interface

User level: privileged, supervisor.

NOTE:

You can only access these command in the “Router-OSPF” context.

Type **router ospf** at the command prompt to enter the “Router-OSPF” context if necessary.

Use the `passive interface` command to allow interfaces to be flooded into the OSPF domain as OSPF routes and not external routes.

Use the `no passive-interface` command to prevent interfaces from being flooded into the OSPF domain as OSPF routes and not external routes.

NOTE:

An interface becomes passive only if you use the `network` command to enable OSPF to run on the interface.

The syntax for this command is:

```
passive-interface <interface-name/net addr>
```

interface-name / net addr	Name of interface or IP address.
------------------------------	----------------------------------

Example:

```
Router-N# passive-interface FastEthernet 1.10
```

ping

User level: user, privileged, supervisor

Use the `ping` command to send ICMP echo request packets to another node on the network.

NOTE:

You can use this command via the master switch only.

The syntax for this command is:

```
ping <host> [<interval> [<size> [<timeout> [<source address>]]]]
```

host	Host IP address/Internet address of route destination. If missing then the last host IP is used.
interval	Interval between ping commands in seconds (1 to 256)
size	Size of packet in bytes (22 to 66500)
timeout	Timeout in seconds (1 to 10)
source address	IP address of one of the router interfaces

Example: to ping the IP number 149.49.48.1 three times:

```
Marketing-1# ping 149.49.48.1 3

PING 149.49.48.1: 56 data bytes
64 bytes from 149.49.48.1: icmp_seq=0. time=0. ms
64 bytes from 149.49.48.1: icmp_seq=1. time=0. ms
64 bytes from 149.49.48.1: icmp_seq=2. time=0. ms

----149.49.48.1 PING Statistics----
3 packets transmitted, 3 packets received, 0% packet loss
round-trip (ms)  min/avg/max = 0/0/0
```

prompt-length

User level: privileged, supervisor.

Use the CLI prompt length command to set the length of the command prompt that is displayed.

The syntax for this command is:

```
prompt-length <full | prompt-size>
```

full	return the CLI prompt to its full length
prompt-size	size of the CLI prompt in characters

Example:

```
Marketing-1# prompt-length 3
~N>
```

redistribute (OSPF context)

User level: privileged, supervisor.

NOTE:

You can only access these command in the “Router-OSPF” context.
Type **router ospf** at the command prompt to enter the “Router-OSPF” context if necessary.

Use the `redistribute` command to redistribute routing information from other protocols into OSPF.

Use the `no redistribute` command disables redistribution by OSPF.

The syntax for this command is:

`[no] redistribute <protocol>`

protocol	<ul style="list-style-type: none"> • static • conneted • RIP
----------	---

Example:

```
Router-N(configure router:ospf)# redistribute static
```

redistribute (RIP context)

User level: privileged, supervisor.

NOTE:

You can only access these commands in the “Router-RIP” context.
Type **router rip** at the command prompt to enter the “Router-RIP” context if necessary.

Use the `redistribute` command to redistribute routing information from other protocols into RIP.

Use the `no redistribute` command to disable redistribution by RIP.

The default is disabled.

The syntax for this command is:

`[no] redistribute <protocol>`

protocol	Either Static or OSPF
----------	-----------------------

Example:

```
Router-N(configure router:rip)# redistribute ospf
Done!
```

reset

User level: user, privileged, supervisor

Use the `reset` command to restart an individual switch.

The syntax for this command is:

```
reset
```

Example:

```
Marketing-1# reset
This command will force a switch-over to the master module and
disconnect your telnet session.
Do you want to continue (y/n) [n]? y
Connection closed by foreign host.
```

router ospf

User level: privileged, supervisor

NOTE:

If you are at the "privileged" level, you can only access this command in Configure mode. Type **configure** at the command prompt to enter interface mode.

Use the `router ospf` command to enable the OSPF protocol on the system and enter the "router ospf" context.

Use the `no router ospf` command to disable the OSPF one the system.

The default is disabled.

The syntax for this command is:

```
[no] router ospf
```

Example:

```
Router-N(super)# router ospf
Done!
Router-N(super-router:OSPF)#
```

router rip

User level: privileged, supervisor

NOTE:

If you are at the "privileged" level, you can only access this command in Configure mode. Type **configure** at the command prompt to enter interface mode.

Use the `router rip` command to configure the Routing Information Protocol (RIP) and enter the "router rip" context.

Use the `no router rip` command to disable RIP.

The default state is disabled.

The syntax for this command is:

```
[no] router rip
```

Example:

To enable the RIP protocol:

```
Router-N(super)# router rip
Done!
Router-N(super router:rip)#
```

router vrrp

User level: privileged, supervisor.

NOTE:

If you are at the "privileged" level, you can only access this command in Configure mode. Type **configure** at the command prompt to enter configure mode if necessary.

Use the `router vrrp` command to enable VRRP router redundancy globally.

Use the `no router vrrp` command to disable VRRP router redundancy.

The syntax for this command is:

```
[no] router vrrp
```

Example:

```
Router-N(super)# router vrrp
Done!
```

session

User level: user, privileged, supervisor

Use the `session` command to open a session with a specific entity in a switch of the stack. For example, you can open a session with the Routing entity of a P332G-ML switch in the stack.

The syntax for this command is:

```
session [<mod_num> [switch|router|atm|mgp|wan]]
```

mod_num	(optional) The switch number. If you do not specify this parameter, you will get the default entity of the stack (Layer 2 session to the Master)
switch router atm mgp wan	(optional) The entity to which you want to open a session. If you do not specify this parameter, you will get the default entity of the specific module: switch - Layer 2 entity of the switch (see Note below). router - Routing entity. atm - ATM entity. mgp - Media Gateway Processor. wan - WAN access router entity.

**Tip:**

When you use the `session` command the security level stays the same.

Example:

```
Marketing-1# session 2
Marketing-1#
```

**Tip:**

The security level stays the same when you use the `session` command.

set device-mode

User level: privileged, supervisor.

Use the `set device-mode` command to change the basic mode of operation of the switch between Router and Layer 2 modes.

NOTE:

This command is available on C360 switches with L3 licenses only.

The syntax for this command is:

set device-mode <mode>

mode	Router Layer2
------	-----------------

Example:

```
Marketing-1# set device-mode Layer2
This command will RESET the device
*** Reset *** - do you want to continue (Y/N)? y
```

set logout

User level: privileged, supervisor.

Use the `set logout` command to set the time in minutes before the system automatically disconnects an idle session.

The syntax for this command is:

```
set logout [timeout in minutes]
```

timeout in minutes	<p>Time until the system automatically disconnects an idle session.</p> <ul style="list-style-type: none"> Setting the value to 0 disables the automatic disconnection of idle sessions Default value is 15 minutes
--------------------	---

Example:

- To set the time until the system disconnects an idle session automatically to 20 minutes:

```
Router-N# set logout 20
Sessions will be automatically logged out after 20 minutes of idle time.
```

- To disable the automatic disconnection of idle sessions:

```
Router-N# set logout 0
Sessions will not be automatically logged out.
```

set system contact

User level: privileged, supervisor

Use the `set system contact` command to set the system contact MIB variable.

The syntax for this command is:

```
set system contact [string]
```

string	System contact
--------	----------------

Example:

```
Router-N# set system contact "gregory kohll"
Done!
```

NOTE:

If you wish to enter a name which includes spaces, you must enclose the entire name in quotation marks, for example “new york”.

set system location

User level: privileged, supervisor

Use the `set system location` command to set the system location MIB variable

The syntax for this command is:

```
set system location [string]
```

string	System name
--------	-------------

Example:

```
Router-N# set system location "tech doc"
Done!
```

NOTE:

If you wish to enter a name which includes spaces, you must enclose the entire name in quotation marks, for example “new york”.

set system name

User level: privileged, supervisor

Use the `set system name` command to set the mib2 system name MIB variable.

The syntax for this command is:

```
set system name [string]
```

string	<ul style="list-style-type: none"> • The system name string should be typed inside inverted commas. • The name is cleared if you leave this field blank.
--------	--

Example:

```
Router-N# set system name C360-1
Done!
```

NOTE:

If you wish to enter a name which includes spaces, you must enclose the entire name in quotation marks, for example “new york”.

set vlan

User level: privileged, supervisor.

NOTE:

If you are at the “privileged” level, you can only access this command in Configure mode. Type **configure** at the command prompt to enter Configure mode if necessary.

Use the `set vlan` command to create a router Layer 2 interface.

The syntax for this command is:

```
set vlan <vlan-id> name <vlan-name>
```

vlan-id	VLAN number
vlan-name	VLAN name

Example:

```
Router-N# set vlan 2 name vlan2
```

NOTE:

If you wish to enter a name which includes spaces, you must enclose the entire name in quotation marks, for example “new york”.

show copy status

User level: user, privileged, supervisor

Use the `show copy status` command to show the status of the local configuration copy operation.

The syntax for this command is:

```
show copy status
```

Example:

```
Router-1# show copy status
Module #1
=====
Module           : 1
Source file      : .router-startup
Destination file : .router-running
Host             : -
Running state    : Idle
Failure display  : (null)
Last warning     : No-warning
```

show device-mode

User level: user, privileged, supervisor

Use the `show device-mode` command to show the current switch operating mode. Possible modes are Router or Switch.

The syntax for this command is:

```
show device-mode
```

Example:

```
Marketing-1# show device mode
Device mode is router
```

show download status

User level: user, privileged, supervisor

Use the `show download status` command to display a summary of the last software download operation.

The syntax for this command is:

```
show download status [module_number]
```

Example:

```
C360-N>show download status 1
Module #1
=====
Module           : 1
Source file      : c:\session4.txt
Destination file : module-config
Host             : 149.49.75.100
Running state    : Idle
Failure display  : SCP - Server refused
Last warning     : No-warning
Bytes Downloaded : 0
```

show erase status

User level: user, privileged, supervisor

Use the `show erase status` command to view the status of the erase configuration operation.

The syntax for this command is:

```
show erase status
```

Example

```
Router-1# show erase status
```

show fragment

User level: user, privileged, supervisor

Use the `show fragment` command to display information regarding fragmented IP packets that are destined to the router.

NOTE:

The router does not perform reassembly of packets in transit.

This command displays the following information:

Size	Maximum number of packets set by the <code>fragment size</code> command
Chain	Maximum number of fragments for a single packet set by the <code>fragment chain</code> command.
Timeout	Maximum number of seconds set by the <code>fragment timeout</code> command.
Queue	Number of packets currently awaiting reassembly.

Assemble	Number of packets successfully reassembled
Fail	Number of packets which failed to be reassembled
Overflow	Number of packets which overflowed the fragment database.

The syntax for this command is:

```
show fragment
```

Example:

```
Marketing-1# show fragment
Max number of concurrently reassembled packets is 100
Max number of fragments per packet is 64
Fragment timeout is 10 sec
Number of packets waiting to be reassembled is 0
Number of successfully reassembled packets is 11954
Number of packets which failed to be reassembled is 0
Number of packets which overflowed the database is 0
```

show ip access-group

User level: user, privileged, supervisor

Use the `show ip access-group` command to see information about the configured active access list.

The syntax for this command is:

```
show ip access-group
```

Example:

```
Marketing-1# show ip access-group
access-group 100
```

show ip access-list-dscp

User level: user, privileged, supervisor

Use the `show ip access-list-dscp` command to display the DSCP to CoS map of a policy-list.

The syntax for this command is:

```
show ip access-list-dscp <policy-list-number> [<dscp>]
```

policy-list-number	A valid id number for a policy list currently defined for the module (100 to 149, 0 - default list)
dscp	dscp entry (0 - 63)

Example:

```
Marketing-1# show ip access-list-dscp 101
Trust configuration is trust-cos
DSCP      Action          Precedence    Name
-----
0         fwd0              mandatory    DSCP#0
1         fwd0              mandatory    DSCP#1
2         fwd0              mandatory    DSCP#2
3         fwd0              mandatory    DSCP#3
4         fwd0              mandatory    DSCP#4
5         fwd0              mandatory    DSCP#5
6         fwd0              mandatory    DSCP#6
7         fwd0              mandatory    DSCP#7
8         fwd1              mandatory    DSCP#8
9         fwd1              mandatory    DSCP#9
10        fwd1              mandatory    DSCP#10
11        fwd1              mandatory    DSCP#11
```

show ip access-list-summary

User level: user, privileged, supervisor

Use the show ip access-list-summary command to display a list of all configured access lists.

The syntax for this command is:

```
show ip access-list-summary
```

Example:

```
Marketing-1# show ip access-list-summary
The policy lists summary:
default List (0)
```

show ip arp

User level: user, privileged, supervisor

Use the `show ip arp` command to display the Address Resolution Protocol (ARP) cache.

The syntax for this command is:

```
show ip arp [<if-name> | <vlan> | <ip addr> | <ip-mask> static]
```

if-name	Interface name (string up to 32 chars)
vlan	VLAN NAME (string up to 16 chars) or VLAN ID (number)
ip-addr	The IP address of the station(s)
ip-mask	The ip mask of the routes.
static	Display static ip ARP information.

Example:

```
Marketing-1# show ip arp
Showing 3 rows
  Address          MAC Address      Interface  Type      TTL
-----
192.168.54.1      00:40:0d:8c:12:01  mgmt      Dynamic   14360
192.168.2.33      00:40:0d:5c:14:01  loco      Static    Not Aged
192.168.1.111     00:40:0d:5d:72:01  ppp       Static    Not Aged
```

NOTE:

If you wish to enter a name which includes spaces, you must enclose the entire name in quotation marks, for example “new york”.

show ip icmp

User level: user, privileged, supervisor

Use the `show ip icmp ip` command to display the status of ICMP error messages.

The syntax for this command is:

```
show ip icmp
```

Example:

```
Routing-1# show ip icmp

ICMP error messages status is ENABLE
```

show ip interface

User level: user, privileged, supervisor

Use the `show ip interface` command to display information for an IP interface.

The syntax for this command is:

```
show ip interface [<interface>]|<vlan>|<IP addr>]
```

interface	The name of the interface whose information you want to display.
vlan	The name or ID of the VLAN over which there are interfaces you want to display.
ip-address	The IP address of the interface whose information you want to display.

Example:

```
Routing-1# show ip interface
Showing 2 Interfaces
mgmt is administratively up
  On vlan Default
    Internet address is 10.49.54.14    , subnet mask is 255.255.255.0
    Broadcast address is 10.49.54.255
    Directed broadcast forwarding is disabled
    Proxy ARP is disabled

baba is administratively down
  On vlan v2
    Internet address is 192.168.0.14    , subnet mask is 255.255.0.0
    Broadcast address is 192.168.255.255
    Directed broadcast forwarding is disabled
    Proxy ARP is disabled
```

NOTE:

If you wish to enter a name which includes spaces, you must enclose the entire name in quotation marks, for example “new york”.

show ip interface brief

User level: user, privileged, supervisor

Use the `show ip interface brief` command to display brief information for an IP interface.

The syntax for this command is:

```
show ip interface [<interface>|<vlan>|<ip-address>]
```

interface	The name of the interface whose information you want to display - a string of up to 32 characters.
ip-address	The IP address of the interface whose information you want to display.
vlan	The name or ID of the VLAN over which there are interfaces you want to display - a string of up to 32 characters.

Example:

```
Routing-1# show ip interface brief
Showing 1 Interfaces
      Interface           Address           Mask           Status
-----
net                    149.49.54.56    255.255.255.0    up
```

show ip ospf

User level: user, privileged, supervisor

Use the `show ip ospf` command to displays general information about OSPF routing.

The syntax for this command is:

```
show ip ospf
```

Example:

```
Routing-1# show ip ospf
Routing Process OSPF with ID 149.49.75.222
Number of areas in this router is 1
Area 0.0.0.0
Number of Interfaces in this area 0
SPF algorithm executed 1 times
SPF hold time is 3 sec
```

show ip ospf database

User level: user, privileged, supervisor

Displays lists of information related to the OSPF database for a specific router.

The syntax for this command is:

```
show ip ospf database [<ls type>]
```

ls-types:

asbr-summary	Displays information only about the autonomous system boundary router summary LSAs. Optional.
router	Displays information only about the router LSAs. Optional.
network	Displays information only about the network LSAs. Optional.
network-summary	Displays information only about the network LSAs summary. Optional
external	Displays information only about the external LSAs. Optional.

Example:

```
Routing-1# show ip ospf database
Showing 1 rows
-----
```

Area	Type	LSA ID	Router ID	Sequence	Age	Cksm
0.0.0.0	RTR	0.0.0.0	0.0.0.0	80000005	238	7ddf

show ip ospf interface

User level: user, privileged, supervisor

Use the `show ip ospf interface` command to display OSPF-related interface information.

The syntax for this command is:

```
show ip ospf interface [<interface-name>]
```

interface-name	The OSPF interface name.
----------------	--------------------------

Example:

```
Marketing-1# show ip ospf interface
There are no OSPF interfaces
```

NOTE:

If you wish to enter a name which includes spaces, you must enclose the entire name in quotation marks, for example “new york”.

show ip ospf neighbor

User level: user, privileged, supervisor

Displays OSPF-neighbor information on a per-interface basis.

The syntax for this command is: `show ip ospf neighbor`
 [<interface-name>] [<neighbor-id>]

interface-name	The OSPF interface name.
neighbor-id	Neighbor ID.

Example:

```
Routing-1# show ip ospf neighbor
There are no ospf neighbors
```

NOTE:

If you wish to enter a name which includes spaces, you must enclose the entire name in quotation marks, for example “new york”.

show ip protocols

User level: user, privileged, supervisor

Use the `show ip protocols` command to display the IP routing protocol process parameters and statistics.

The syntax for this command is:

```
show ip protocols [<protocol>]
```

protocol (Optional)	RIP OSPF.
---------------------	-------------

Example:

```

Routing-1# show ip protocols
Routing Protocol is "rip"

  Sending updates every 30 seconds, next due in 0 seconds
  Invalid after 180 seconds, flushd after 300
  Redistributing: rip
  Default version control: rip version 1

    Interface                                Version   Key
Routing for Networks:
Routing Information Sources:
  Gateway                                Last Update

```

show ip reverse-arp

User level: user, privileged, supervisor

Use the show ip reverse-arp command to display the IP address of a host, based on a known MAC address.

The syntax for this command is:

```
show ip reverse-arp <mac addr> [<match len>]
```

mac addr	MAC address
match len	The number of bytes in the address to match

Example:

```

Routing-1# sh ip reverse-arp 00:10:a4:98:97:e0

Showing 1 rows

Address          MAC Address      I/F      Type      TTL
-----
149.49.70.68    00:10:a4:98:97:e0  e-70     Dynamic   14355

```

show ip route

User level: user, privileged, supervisor

Use the `show ip route` command to display information about the IP unicast routing table.

The syntax for this command is:

```
show ip route
```

Network	Mask	Interface	Next-Hop	Cost	TTL	Source
0.0.0.0	0.0.0.0	net	149.49.54.1	1	n/a	STAT-LO
149.49.54.0	255.255.255.0	net	149.49.54.56	1	n/a	LOCAL

show ip route best-match

User level: user, privileged, supervisor

Use the `show ip route best-match` command to display a routing table for a destination address.

The syntax for this command is:

```
show ip route best-match <dst addr>
```

dst addr	IP address
----------	------------

Example:

NetworkMask	Interface	Next-Hop	Cost	TTL	Source
199.93.0.0255.255.0.0	e-135new	135.64.76.1	1	n/a	STAT-HI

show ip route static

User level: privileged, supervisor.

Use the `show ip static route` command to display the static routes.

The syntax for this command is:

```
show ip route static [<ip addr> [<mask>] ]
```

ip-address	The IP address of the routes
------------	------------------------------

mask	The ip mask of the routes.
------	----------------------------

Example:

```
Routing-1# sh ip route static
Showing 34 rows
```

Network	Mask	Interface	Next-Hop	Cost	Pref	Active
10.0.8.0	255.255.255.0	e-36	149.49.36.11	1	high	Yes
135.0.0.0	255.0.0.0	e-135new	135.64.76.1	1	high	Yes
135.64.0.0	255.255.0.0	e-135	135.87.164.1	1	high	No
149.49.0.0	255.255.0.0	trial	10.10.254.253	1	low	Yes
149.49.2.0	255.255.255.0	n/a	v-Route-FW 1	1	high	Yes

show ip route summary

User level: user, privileged, supervisor

Use the `show ip route summary` command to display the number of routes known to the switch.

The syntax for this command is:

```
show ip route summary
```

Example:

```
Marketing-1# sh ip route summary
```

Route Source	Networks	Subnets
Local	0	1
Static	0	1
Total	0	2

show ip ssh

User level: supervisor

Use the `show ip ssh` command to display active SSH connections.

The syntax for this command is:

```
show ip ssh
```

Example:

```
C360-N> show ip ssh

Ssh Engine: Enable
Max Sessions: 2
Key Type: DSA , 768 bit
Listen Port: 22
Ciphers List: 3des-cbc
Session-Id  Version  Encryption  User      IP:Port
0x508622f0    2      3des-cbc   root     135.64.100.73:4201
```

show ip traffic

User level: user, privileged, supervisor

Use the `show ip traffic` command to display the IP traffic statistics counters.

The syntax for this command is:

```
show ip traffic
```

Example:

```
Routing-1# show ip traffic
IP statistics:

    Received:
    1365359 total, 45659 local destination
    0 bad hop count, 0 packet header errors
    0 unknown protocol, 136786 address errors
    1182914 discarded

    Fragments:
    0 reassembled, 0 timeouts
    0 couldn't reassemble, 0 fragmented

    Sent:
    19442 generated, 0 forwarded
    0 no route, 0 discarded
ICMP statistics:
    Received:
    881 total, 3 ICMP errors
    0 unreachable, 0 time exceeded
    0 parameter, 0 quench
    861 echo, 17 echo reply
    0 timestamps request, 0 timestamp reply
--type q to quit or space key to continue--
    0 mask requests, 0 mask replies

    0 redirects
    Sent:
    1311 total, 0 ICMP errors
    433 unreachable, 0 time exceeded
    0 parameter, 0 quench
    17 echo, 861 echo reply
    0 timestamps request, 0 timestamp reply
    0 mask requests, 0 mask replies
    0 redirects
```

```

OSPF statistics:
    Received:
    25783 total, 0 checksum errors
    0 hello, 0 database desc
    0 link state req, 0 link state updates
    0 link state acks

    Sent:
    0 total

ARP statistics:
--type q to quit or space key to continue--
    Received:
    2191321 requests, 778439 replies

    Sent:
    443 requests, 340 replies (0 proxy)

DHCP statistics:
    Requests: 0 , Replies: 0

BOOTP statistics:
    Requests: 0 , Replies: 0

```

show ip unicast cache

User level: privileged, supervisor.

Use the `show ip unicast cache` command to list the entries in the hardware unicast cache database.

The syntax for this command is:

```
show ip unicast cache [[<src addr> <src mask>] <dst addr> <dst mask>}
```

src addr	The source IP address.
src mask	The source mask IP address.
dst addr	The destination IP address.
dst mask	The destination mask IP address.

Example:

```

Routing-1# show ip unicast cache
  Showing 6 Sessions.
  Source IP      Destination IP  Next Hop IP    NH MAC          Vlan
  =====
192.168.1.1     29.2.1.1      28.2.0.2      00.00.28.02.00.02  5
192.168.2.1     29.2.2.1      28.2.0.2      00.00.28.02.00.02  5
192.168.2.2     29.2.2.2      28.2.0.2      00.00.28.02.00.02  5
192.168.2.3     29.2.2.3      28.2.0.2      00.00.28.02.00.02  5
192.168.2.4     29.2.2.4      28.2.0.2      00.00.28.02.00.02  5
192.168.2.5     29.2.2.5      28.2.0.2      00.00.28.02.00.02  5

```

show ip unicast cache networks

User level: user, privileged, supervisor

Use the `show ip unicast cache networks` command to display a summary of networks handled by the hardware unicast cache database.

The syntax for this command is:

```
show ip unicast cache networks [<net addr> <net mask>]
```

net addr	The IP address of the network.
net mask	The mask IP address.

Example:

```
Marketing-1# show ip unicast cache networks
Showing 7 rows (5 networks)

Network          Mask Next Hop(s)      Total Hosts
=====
10.0.0.0         16 10.2.0.2           996
71.0.0.0         16 0.0.0.0             1
130.0.0.0        8 192.168.0.130       1124
190.0.0.0        24 10.2.0.2             250
                  192.168.0.130
191.0.0.0        24 10.2.0.2             250
                  192.168.0.130
-----
Total: 2621
```

show ip unicast cache networks detailed

User level: user, privileged, supervisor

Use the `show ip unicast cache networks detailed` command to list the networks and hosts that are handled by the hardware unicast cache database.

The syntax for this command is:

```
show ip unicast cache networks detailed[<net addr> <net mask>]
```

net addr	The IP address of the network.
net mask	The mask IP address.

Example:

```
Routing-1# show ip unicast cache networks detailed 192.168.6.0 24
Showing 3 rows
NetworkMaskIPAddress
=====
192.168.6.024192.168.6.40
    192.168.6.53
    192.168.6.64
```

show ip unicast cache nextHop

User level: privileged, supervisor.

Use the `show ip unicast cache nextHop` command to list the routers that are used as next-hop routers.

The syntax for this command is:

```
show ip unicast cache nextHop
```

Example:

```
Routing-1# show ip unicast cache nextHop
Showing 2 rows
Next Hop
=====
192.168.4.1
192.168.5.1
```

show ip unicast cache summary

User level: user, privileged, supervisor

Use the `show` command to display the number of host networks and next-hops in the module's unicast cache.

The syntax for this command is:

```
show ip unicast cache summary
```

Example:

```
Routing-1# show ip unicast cache summary
Cache Summary
=====
Sessions   : 11056
Hosts      : 2621
Networks   :    5
Next-Hops  :    4
```

show ip vrrp

User level: user, privileged, supervisor

Use the `show vrrp` command to display VRRP information.

The syntax for this command is:

```
show ip vrrp [<vlan> [router-id <vr-id>]][detail]
```

vlan	Filter by VLAN.
router-id	Filter by virtual router ID (1-255)
vr-id	The virtual router ID.
detail	Provide detailed information.

Example:

```

Routing-1# show ip vrrp
VRRP is globally enabled
VLANVRIDIP Address      PriTimer  State      Since
-----
 1 1 192.168.66.23      255 1      MASTER    00:00:00
 1 2 192.168.66.24      100 1      BACKUP    00:00:00

```

show ip vrrp detail

User level: user, privileged, supervisor

Use the `show ip vrrp detail` command to display full VRRP-related information

The syntax for this command is:

```
show ip vrrp detail
```

Example:

```
Routing-1# show ip vrrp detail
VRRP is globally enabled
Virtual Router on VLAN:1
  Router-id:          1
  State:              MASTER
  Priority:            255
  Advertisement Interval: 1
  Last State Change:  00:00:00
  Override Address Ownership Rule: No
  Authentication Type:  None
  Authentication Key:  ""
  Master IP Address    192.168.66.23
  Has 1 IP addresses
  IP addresses:
    192.168.66.23
  Primary IP Address:  192.168.66.23
  Primary IP Address was chosen by default
  Preemption Mode:    enabled
  # of times Master: 2
  # of received Advertisements: 0
  # of transmitted Advertisements: 20
  # of received Advertisements with Security Violations: 0
```

```

Virtual Router on VLAN:      1
  Router-id:                 2
  State:                     BACKUP
  Priority:                   100
  Advertisement Interval:    1
  Last State Change:         00:00:00
  Override Address Ownership Rule: No
  Authentication Type:       None
  Authentication Key:        " "
  Master IP Address          0.0.0.0
  Has 1 IP addresses
  IP addresses:
    192.168.66.24
  Primary IP Address:        192.168.66.23
  Primary IP Address was chosen by default
  Preemption Mode:           enabled
  # of times Master:         1
  # of received Advertisements: 0
  # of transmitted Advertisements: 13
  # of received Advertisements with Security Violations: 0
Marketing-1#

```

show running-config

User level: user, privileged, supervisor

Use the `show running-config` command to show the current router and policy configuration.

The syntax for this command is:

```
show running-config
```

Example:

```

c360-1(super)# sh running-config
c360-1(super)#
#!#$@ DO NOT REMOVE THIS LINE - Avaya Inc. C360 Switch - Router configuration

! Avaya Inc. C360 Switch - Router configuration
! version 4.3.2
hostname "c360"
!#
!# End of Configuration File

```

show startup-config

User level: user, privileged, supervisor

Use the `show startup-config` command to show the configuration loaded at startup.

The syntax for this command is:

```
show startup-config
```

Example:

```
Routing-1# show startup-config
c360-1(super)#
#!#$$@ DO NOT REMOVE THIS LINE - Avaya Inc. C360 Switch - Router
configuration

! Avaya Inc. C360 Switch - Router configuration
! version 4.3.2
!#
!# End of Configuration File
```

show system

User level: user, privileged, supervisor

Use the `show system` command to display the up time, system name, location, and contact person.

The syntax for this command is:

```
show system
```

Example:

```

Routing-1# show system
Uptime d,h:m:s
-----
0,2:40:55

System Name          System Location      System Contact
-----
C360_version-4.3.2  R&D                  Gregory Kohll

Switch MAC address
-----
00 40 0d 8a 04 b4

```

show upload status

User level: user, privileged, supervisor

Use the `show upload status` commands to display the status of the current configuration file copy process from the device.

The syntax for this command is:

```
show upload status [<mod_num>]
```

mod_num (Optional)	Number of the module. If you do not specify a number, upload statuses for all modules in the stack are shown.
-----------------------	---

Example:

```

Routing-1# show upload status 1
Module          : 1
Source file     : stack-config
Destination file : c:\conf.cfg
Host           : 149.49.36.200
Running state   : Executing
Failure display : (null)
Last warning    : No-warning

```

show vlan

User level: user, privileged, supervisor

Use the `show vlan` command to display router Layer 3 interfaces.

The syntax for this command is:

```
show vlan
```

Example:

```
Routing-1# show vlan
VLAN NAME          VLAN ID  VLAN MAC
-----
Default            1  02:e0:3b:1d:f9:01
```

tech

User level: supervisor

Use the `tech` command to enter tech mode.

NOTE:

This command is reserved for service personnel use only.

terminal length

User level: user, privileged, supervisor

Use the `terminal length` command to display or set the length screen length in characters.

The syntax for this command is:

```
terminal length [<screen-length>]
```

screen-length	<ul style="list-style-type: none"> • none – display the current value • length: 3 to 200
---------------	--

Example:

```
Router-N> terminal length 24
terminal length: 24
```

terminal width

User level: user, privileged, supervisor

Use the `terminal width` command to display or set the screen width.

The syntax for this command is:

`terminal length [<screen-width>]`

screen-width	<ul style="list-style-type: none"> • none – display the current value • width: 10 to 200
--------------	--

Example:

```
C360-N> terminal width
terminal width: 80 (auto-detected)
```

timers basic

NOTE:

You can only access these commands in the “Router-RIP” context.

Type `router rip` at the command prompt to enter the “Router-RIP” context if necessary.

Use the `timers basic` command to configure the route timer.

Use the `no timers basic` command to restore the timers to their default values.

The syntax for this command is:

`timers basic <update><invalid>`

update	RIP update timer in seconds (minimum = 30; default = 30)
invalid	RIP invalid route timer in seconds (minimum =30; default = 180)

NOTE:

The Invalid Route Timer value must be larger than the Update Timer value. It is recommended that it be at least three times greater.

In any configuration all adjacent routers must have the same values for each of the timer parameters. It is possible to have different values for the timers on two adjacent routers, provided the Invalid Timer value is at least three times greater on one of the routers than the Update Timer value on the other router.

Example:

```
Router-N(configure router:rip)# timers basic 30 180
```

timers spf

User level: privileged, supervisor.

NOTE:

You can only access these command in the “Router-OSPF” context.

Type **router ospf** at the command prompt to enter the “Router -OSPF” context if necessary.

Use the `timers spf` command to configure the delay between runs of OSPF’s SPF calculation. Use the `no` form of this command to restore the default (3 seconds).

The syntax for this command is:

```
[no] timers spf <spf-holdtime>
```

spf-holdtime	The time in seconds of the delay between runs of OSPF’s SPF calculation.
--------------	--

Example:

```
Router-N(configure router:rip)# timers spf 5
Done!
```

traceroute

User level: user, privileged, supervisor

Use the `traceroute` command to initiate a traceroute to a remote host.

The syntax for this command is:

```
traceroute <host>
```

host	IP address.
------	-------------

Example:

```
Marketing-1# traceroute 192.168.50.13
```

tree

User level: user, privileged, supervisor

Use the `tree` command to display a list of CLI commands available at the current user level.

The syntax for this command is:

```
tree [<depth>]
```

depth	Depth of CLI commands displayed
-------	---------------------------------

Example:

```

Router-N> tree 1
> arp
> arp timeout
> clear arp-cache
> clear fragment
> clear screen
> clear vlan
> configure
> disconnect ssh
> erase startup-config
> fragment chain
> fragment size
> fragment timeout
> hostname
> icmp in-echo-limit
> interface
  interface > default-metric
> ip access-default-action
> ip access-group
> ip access-list
> ip access-list-cookie
> ip access-list-copy
> ip access-list-name
> ip access-list-owner
--type q to quit or space key to continue--

```

validate-group

User level: privileged, supervisor.

Use the `validate-group` command to verify that all the rules in a policy list are valid.

If there is a configuration problem with a specific rule, or with a number of rules, detailed error messages will be given.

The syntax for this command is:

```
validate-group <policy-list-number>[quiet]
```

quiet	does not display error messages
-------	---------------------------------

Example:

```
Router-N(configure)# validate-group 101  
List 101 is valid
```



Tip:

The validation process may take some time to complete.

4 Avaya C360 Layer 3 CLI Commands

This chapter lists the Layer 3 CLI (Command Line Interface) by context.

interface context

- [no] [default-metric](#)
- [enable vlan commands](#)
- [ip address](#)
- [ip admin-state](#)
- [no] [ip bootp-dhcp network](#)
- [no] [ip bootp-dhcp server](#)
- [ip broadcast-address](#)
- [no] [ip directed-broadcast](#)
- [no] [ip netbios-rebroadcast](#)
- [no] [ip ospf authentication-key](#)
- [no] [ip ospf cost](#)
- [no] [ip ospf dead-interval](#)
- [no] [ip ospf hello-interval](#)
- [no] [ip ospf priority](#)
- [no] [ip proxy-arp](#)
- [no] [ip redirects](#)
- [no] [ip rip authentication key](#)
- [no] [ip rip authentication mode](#)
- [no] [ip rip default-route-mode](#)
- [no] [ip rip poison-reverse](#)
- [ip rip rip-version](#)
- [no] [ip rip send-receive-mode](#)
- [no] [ip rip split-horizon](#)
- [ip routing-mode](#)
- [no] [ip vlan/ip vlan name](#)
- [no] [ip vrrp](#)

ospf context

- [no] [area](#)

- [no] [network \(OSPF context\)](#)
- [no] [passive-interface](#)
- [no] [redistribute \(OSPF context\)](#)
- [no] [timers spf](#)

rip context

- [no] [network \(RIP context\)](#)
- [no] [redistribute \(RIP context\)](#)
- [no] [timers basic](#)